

Operator's Manual

Ride-On Roller

RD12 RD12A RD16



Type

RD12, RD12A, RD16

Document

5200022654

Date

0217

Version

07

Language

EN



Copyright notice

© Copyright 2017 by Wacker Neuson Production Americas LLC

All rights, including copying and distribution rights, are reserved.

This publication may be photocopied by the original purchaser of the machine. Any other type of reproduction is prohibited without express written permission from Wacker Neuson Production Americas LLC.

Any type of reproduction or distribution not authorized by Wacker Neuson Production Americas LLC represents an infringement of valid copyrights. Violators will be prosecuted.

Trademarks

All trademarks referenced in this manual are the property of their respective owners.

Manufacturer

Wacker Neuson Production Americas LLC

N92W15000 Anthony Avenue

Menomonee Falls, WI 53051 U.S.A.

Tel: (262) 255-0500 · Fax: (262) 255-0550 · Tel: (800) 770-0957

www.wackerneuson.com


Original instructions

This Operator's Manual presents the original instructions. The original language of this Operator's Manual is American English.

Foreword

SAVE THESE INSTRUCTIONS—This manual contains important instructions for the machine models below. These instructions have been written expressly by Wacker Neuson Production Americas LLC and must be followed during installation, operation, and maintenance of the machines.

| Machine | Item Number |
|-----------|--|
| RD 16 | 5000620060, 5000620402 5000620798, 5000620799 |
| RD 16 IRH | 5000620127 |
| RD 12 | 5000620059, 5000620321 |
| RD 12A | 5000620058, 5100013933 5000620320, 5000620369 |



wc_gr010237

Machine identification

A nameplate listing the model number, item number, revision number, and serial number is attached to this machine. The location of the nameplate is shown above.

Serial number (S/N)

For future reference, record the serial number in the space provided below. You will need the serial number when requesting parts or service for this machine.

Serial Number:

Machine documentation

- From this point forward in this documentation, Wacker Neuson Production Americas LLC will be referred to as Wacker Neuson.
- Keep a copy of the Operator's Manual with the machine at all times.
- Use the separate Parts Book supplied with the machine to order replacement parts.
- If you are missing any of these documents, please contact Wacker Neuson to order a replacement or visit www.wackerneuson.com.
- When ordering parts or requesting service information, be prepared to provide the machine model number, item number, revision number, and serial number.

Expectations for information in this manual

- This manual provides information and procedures to safely operate and maintain the above Wacker Neuson model(s). For your own safety and to reduce the risk of injury, carefully read, understand, and observe all instructions described in this manual.
- Wacker Neuson expressly reserves the right to make technical modifications, even without notice, which improve the performance or safety standards of its machines.
- The information contained in this manual is based on machines manufactured up until the time of publication. Wacker Neuson reserves the right to change any portion of this information without notice.
- The illustrations, parts, and procedures in this manual refer to Wacker Neuson factory-installed components. Your machine may vary depending on the requirements of your specific region.

CALIFORNIA Proposition 65 Warning

Engine exhaust, some of its constituents, and certain vehicle components contain or emit chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

Laws pertaining to spark arresters

NOTICE: State Health Safety Codes and Public Resources Codes specify that in certain locations spark arresters be used on internal combustion engines that use hydrocarbon fuels. A spark arrester is a device designed to prevent accidental discharge of sparks or flames from the engine exhaust. Spark arresters are qualified and rated by the United States Forest Service for this purpose. In order to comply with local laws regarding spark arresters, consult the engine distributor or the local Health and Safety Administrator.

Manufacturer's approval

This manual contains references to *approved* parts, attachments, and modifications. The following definitions apply:

- **Approved parts or attachments** are those either manufactured or provided by Wacker Neuson.
- **Approved modifications** are those performed by an authorized Wacker Neuson service center according to written instructions published by Wacker Neuson.
- **Unapproved parts, attachments, and modifications** are those that do not meet the approved criteria.

Unapproved parts, attachments, or modifications may have the following consequences:

- Serious injury hazards to the operator and persons in the work area
- Permanent damage to the machine which will not be covered under warranty

Contact your Wacker Neuson dealer immediately if you have questions about approved or unapproved parts, attachments, or modifications.



EC Declaration of Conformity

Manufacturer

Wacker Neuson Production Americas LLC, N92W15000 Anthony Avenue,
Menomonee Falls, Wisconsin 53051 USA

Product

| | |
|------------------------------|------------------------------------|
| Product | RD16-90, RD16 IRH-90, RD16-100 |
| Product category | Ride-On Roller |
| Product function | To compact asphalt |
| Item number | 5000620799, 5000620127, 5000620798 |
| Net installed power | 16.8 kW |
| Measured sound power level | 104 dB(A) |
| Guaranteed sound power level | 106 dB(A) |

Conformity Assessment Procedure

According to 2000/14/EC ANNEX VIII

Notified Body

Lloyds Register Verification Limited (Notified Body No 0038)
71 Fenchurch Street, London EC3M 4BS, United Kingdom

Directives and Standards

We hereby declare that this product meets and complies with the relevant regulations and requirements of the following directives and standards:

2006/42/EC, 2000/14/EC, 2014/30/EU, EN 500-1, EN 500-4

Authorized Person for Technical Documents

Robert Raethsel, Wacker Neuson Produktion GmbH & Co. KG, Wackerstrasse 6, 85084
Reichertshofen, Germany

Menomonee Falls, WI, USA, 01.06.16

Keith Herr
Vice President and Managing Director
For Wacker Neuson

Jeff Volden
Director, Product Engineering
For Wacker Neuson

Paul Sina
Manager, Product Engineering
For Wacker Neuson

| | |
|--|-----------|
| Foreword | 3 |
| EC Declaration of Conformity | 5 |
| 1 Safety Information | 13 |
| 1.1 Signal Words Used in this Manual | 13 |
| 1.2 Machine Description and Intended Use | 14 |
| 1.3 Safety Guidelines for Operating the Machine | 15 |
| 1.4 Operating the Machine in Electrical Storms | 17 |
| 1.5 Service Safety | 18 |
| 1.6 Operator Safety while Using Internal Combustion Engines | 20 |
| 1.7 Hydraulic Fluid Safety | 21 |
| 1.8 Safety Guidelines for Lifting and Transporting the Machine | 21 |
| 2 Labels—RD 16 | 22 |
| 2.1 Label Locations | 22 |
| 2.2 Label Meanings | 23 |
| 3 Labels—RD 12, RD 12A | 32 |
| 3.1 Label Locations | 32 |
| 3.2 Label Meanings | 33 |
| 4 Lifting and Transporting | 39 |
| 4.1 Locking and Unlocking the Articulated Joint | 39 |
| 4.2 Lifting the Machine | 40 |
| 4.3 Tying Down and Transporting the Machine | 42 |
| 4.4 Towing the Machine | 43 |
| 4.5 Manually Releasing the Parking Brake | 44 |
| 4.6 Towing Bypass Valve | 46 |
| 5 Controls — RD 16 | 48 |
| 5.1 Features and Controls | 48 |
| 5.2 Control Panel and Indicator Lights | 50 |
| 5.3 Auxiliary Battery Positive Terminal | 53 |

| | | |
|----------|---|-----------|
| 6 | RD 12 and RD 12A Controls | 54 |
| 6.1 | Features and Controls | 54 |
| 6.2 | Control Panel and Indicator Lights | 56 |
| 6.3 | Auxiliary Battery Positive Terminal | 57 |
| 7 | Operation | 58 |
| 7.1 | Preparing the Machine for First Use | 58 |
| 7.2 | Position of the Operator | 58 |
| 7.3 | Mounting and Dismounting the Machine | 58 |
| 7.4 | Fire Extinguisher Requirement | 59 |
| 7.5 | Roll Over Protection Structure (ROPS) | 60 |
| 7.6 | Rotating Beacon (if equipped) | 62 |
| 7.7 | Operator Presence System | 63 |
| 7.8 | Recommended Fuel—Diesel | 64 |
| 7.9 | Recommended Fuel—Gasoline | 64 |
| 7.10 | Refueling the Machine | 65 |
| 7.11 | Positioning the Scrapers | 66 |
| 7.12 | Using the Seat Belt | 67 |
| 7.13 | Using the Forward / Reverse Lever | 68 |
| 7.14 | Using the Vibration System | 69 |
| 7.15 | Using the Water Spray System | 70 |
| 7.16 | Using the Backup Alarm | 71 |
| 7.17 | Using the Parking Brakes—RD 16 | 72 |
| 7.18 | Using the Manual Parking Brake—RD 12 / 12A | 73 |
| 7.19 | Parking Brake Adjustment — RD 12 / 12A | 74 |
| 7.20 | Avoiding the Danger Zone | 75 |
| 7.21 | Adding Ballast to Rear Drum — RD 12 / 12A only | 76 |
| 7.22 | Preliminary Checks | 77 |
| 7.23 | Starting, Operating, and Stopping the Machine—RD 16 | 78 |
| 7.24 | Emergency Shut-down Procedure (RD 16) | 81 |
| 7.25 | Starting, Operating, and Stopping the Machine—RD 12 / 12A | 82 |
| 7.26 | Emergency Shutdown Procedure (RD 12 / 12A) | 85 |
| 7.27 | Machine Stability | 86 |
| 7.28 | Operating on Slopes | 87 |
| 7.29 | Anti-Vandalism Protection and Machine Access | 88 |
| 8 | General Maintenance | 90 |
| 8.1 | Maintaining the Emission Control System | 90 |
| 8.2 | Periodic Maintenance Schedule | 91 |
| 8.3 | Rear Frame Access | 92 |

| | | |
|-----------|---|------------|
| 8.4 | Safety-Related Spare Parts | 94 |
| 8.5 | Maintaining the Seat and Seat Belt | 100 |
| 8.6 | Hydraulic Oil Level | 101 |
| 8.7 | Checking the Water Filter | 102 |
| 8.8 | Cleaning the Water Filter | 103 |
| 8.9 | Grease Fittings—RD 16 | 104 |
| 8.10 | Grease Fittings—RD 12 / 12A | 105 |
| 8.11 | Battery | 106 |
| 8.12 | Hydraulic System Cleanliness | 107 |
| 8.13 | Hydraulic Oil Requirements | 107 |
| 8.14 | Checking and Cleaning the Hydraulic Tank Breather | 108 |
| 8.15 | Changing the Hydraulic Oil and Filter | 109 |
| 8.16 | Bleeding the Hydraulic System | 110 |
| 8.17 | Checking the Neutral Switch | 111 |
| 8.18 | Inspecting the Seat Belt | 112 |
| 8.19 | Cleaning the Spray Bars | 113 |
| 8.20 | Testing the Brake System | 114 |
| 8.21 | Long-Term Storage | 115 |
| 8.22 | Machine Disposal and Decommissioning | 116 |
| 9 | Engine Maintenance: Kohler (T4f) | 117 |
| 10 | Engine Maintenance—Wacker Neuson/Robin | 122 |
| 11 | Engine Maintenance—Honda GX630 | 124 |
| 12 | Troubleshooting | 126 |
| 13 | Technical Data—RD 16 | 128 |
| 13.1 | Engine | 128 |
| 13.2 | Roller | 129 |
| 13.3 | Lubrication | 129 |
| 13.4 | Hydraulic Pressures | 130 |
| 13.5 | Sound Measurements | 130 |
| 13.6 | Measurements of Operator Exposure to Vibration | 131 |
| 13.7 | Dimensions | 132 |

| | | |
|-----------|---|------------|
| 14 | Technical Data—RD12 | 133 |
| 14.1 | Engine | 133 |
| 14.2 | Roller | 134 |
| 14.3 | Lubrication | 134 |
| 14.4 | Hydraulic Pressures | 135 |
| 14.5 | Sound Measurements | 135 |
| 14.6 | Measurements of Operator Exposure to Vibration | 135 |
| 14.7 | Dimensions | 136 |
| 15 | Technical Data—RD 12A | 137 |
| 15.1 | Engine | 137 |
| 15.2 | Roller | 138 |
| 15.3 | Lubrication | 138 |
| 15.4 | Hydraulic Pressures | 139 |
| 15.5 | Sound Measurements | 139 |
| 15.6 | Measurements of Operator Exposure to Vibration | 139 |
| 15.7 | Dimensions | 140 |
| 16 | Emission Control Systems Information and Warranty—Gasoline | 141 |
| 16.1 | Emission Control System Background Information | 141 |
| 16.2 | Limited Defect Warranty for Exhaust Emission Control System | 142 |
| 16.3 | Limited Defect Warranty for Wacker Neuson Evaporative Emission Control Systems | 142 |
| 17 | Emission Control Systems Information and Warranty—Diesel | 145 |
| 17.1 | Emission Control System Background Information | 145 |
| 17.2 | Limited Defect Warranty for Exhaust Emission Control System | 146 |
| 17.3 | Limited Defect Warranty for Wacker Neuson Emission Control Systems | 146 |
| 18 | AEM Safety Manual | 149 |



| | | |
|-----------|--|------------|
| 19 | Schematics—RD 16 | 171 |
| 19.1 | Electrical Schematic—Complete | 172 |
| 19.2 | Electrical Schematic Components | 173 |
| 19.3 | Electrical Schematic Section A | 174 |
| 19.4 | Electrical Schematic Components | 175 |
| 19.5 | Electrical Schematic Section B | 176 |
| 19.6 | Electrical Schematic Components | 177 |
| 19.7 | Electrical Schematic Section C | 178 |
| 19.8 | Electrical Schematic Components | 179 |
| 19.9 | Electrical Schematic Section D | 180 |
| 19.10 | Electrical Schematic Components | 181 |
| 19.11 | Electrical Schematic—Complete RD 16IRH | 182 |
| 19.12 | Electrical Schematic Components RD 16IRH | 183 |
| 19.13 | Electrical Schematic Section A RD 16IRH | 184 |
| 19.14 | Electrical Schematic Components RD 16IRH | 185 |
| 19.15 | Electrical Schematic Section B RD 16IRH | 186 |
| 19.16 | Electrical Schematic Components RD 16IRH | 187 |
| 19.17 | Electrical Schematic Section C RD 16IRH | 188 |
| 19.18 | Electrical Schematic Components RD 16IRH | 189 |
| 19.19 | Electrical Schematic Section D RD 16IRH | 190 |
| 19.20 | Electrical Schematic Components RD 16IRH | 191 |
| 19.21 | Hydraulic Schematic | 192 |
| 19.22 | Hydraulic Schematic Components | 193 |
| | | |
| 20 | Schematics—RD 12 | 194 |
| 20.1 | Hydraulic Schematic | 194 |
| 20.2 | Hydraulic Schematic Components | 195 |
| 20.3 | Electrical Schematic | 196 |
| 20.4 | Electrical Schematic Components | 197 |
| | | |
| 21 | Schematics—RD 12A | 198 |
| 21.1 | Electrical Schematic | 198 |
| 21.2 | Electrical Schematic Components | 199 |
| 21.3 | Hydraulic Schematic | 200 |
| 21.4 | Hydraulic Schematic Components | 201 |

1 Safety Information

1.1 Signal Words Used in this Manual

This manual contains DANGER, WARNING, CAUTION, *NOTICE*, and NOTE signal words which must be followed to reduce the possibility of personal injury, damage to the equipment, or improper service.



This is the safety alert symbol. It is used to alert you to potential personal hazards.

- Obey all safety messages that follow this symbol.



DANGER

DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.

- To avoid death or serious injury from this type of hazard, obey all safety messages that follow this signal word.



WARNING

WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.

- To avoid possible death or serious injury from this type of hazard, obey all safety messages that follow this signal word.



CAUTION

CAUTION indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

- To avoid possible minor or moderate injury from this type of hazard, obey all safety messages that follow this signal word.

NOTICE: Used without the safety alert symbol, NOTICE indicates a situation which, if not avoided, could result in property damage.

Note: A Note contains additional information important to a procedure.

1.2 Machine Description and Intended Use

This machine is a dual drum, ride-on roller. The Wacker Neuson Ride-On Roller consists of an articulated frame onto which is mounted a gasoline or diesel engine, a fuel tank, a hydraulic tank, a water tank, a hydrostatic drive system, two steel drums containing internal eccentric weights, and an operator's platform with a ROPS (Roll Over Protective Structure). The engine powers the hydraulic systems that provide machine movement and drum vibration. The vibrating drums smooth and compact the work surface as the machine moves. Machine speed, direction, and vibration are controlled by the operator from the operator's seat on the platform.

The machine is designed as a lightweight roller to be used in the compaction of sublayers and finish layers of asphalt on roads, driveways, parking lots, and other types of asphalt-covered surfaces.

This machine has been designed and built strictly for the intended use described above. Using the machine for any other purpose could permanently damage the machine or seriously injure the operator or other persons in the area. Machine damage caused by misuse is not covered under warranty.

The following are some examples of misuse:

- Using the machine as a ladder, support, or work surface
 - Using the machine to carry or transport passengers or equipment
 - Using the machine to tow other machines
 - Using the machine to spray liquids other than water (i.e., diesel fuel on asphalt)
 - Operating the machine outside of factory specifications.
 - Operating the machine in a manner inconsistent with all warnings found on the machine and in the Operator's Manual.
-

This machine has been designed and built in accordance with the latest global safety standards. It has been carefully engineered to eliminate hazards as far as practicable and to increase operator safety through protective guards and labeling. However, some risks may remain even after protective measures have been taken. They are called residual risks. On this machine, they may include exposure to:

- Heat, noise, exhaust, and carbon monoxide from the engine
- Burns from hot hydraulic fluid
- Fire hazards from improper refueling techniques
- Fuel and its fumes
- Personal injury from improper lifting techniques
- Crushing hazards from improper operation (feet, legs, or arms extending outside of the operator work station) and for other persons in the work zone
- Line of sight blockage by the ROPS

To protect yourself and others, make sure you thoroughly read and understand the safety information presented in this manual before operating the machine.

1.3 Safety Guidelines for Operating the Machine

Operator training

Before operating the machine:

- Read and understand the operating instructions contained in all manuals delivered with the machine.
- Familiarize yourself with the location and proper use of all controls and safety devices.
- Contact Wacker Neuson for additional training if necessary.

When operating this machine:

- Do not allow improperly trained people to operate the machine. People operating the machine must be familiar with the potential risks and hazards associated with it.

Operator qualifications

Only trained personnel are permitted to start, operate, and shut down the machine. They also must meet the following qualifications:

- have received instruction on how to properly use the machine
- are familiar with required safety devices

The machine must not be accessed or operated by:

- children
- people impaired by alcohol or drugs

Application area

Be aware of the application area.

- Keep unauthorized personnel, children, and pets away from the machine.
- Remain aware of changing positions and the movement of other equipment and personnel in the application area/job site.
- Remain aware of changing surface conditions and use extra care when operating over uneven ground, on hills, or over soft or coarse material. The machine could shift or slide unexpectedly.
- Use caution when operating the machine near the edges of pits, trenches or platforms. Check to be sure that ground surface is stable enough to support the weight of the machine with operator and that there is no danger of the roller sliding, falling or tipping.

Be aware of the application area.

- Do not operate the machine in areas that contain flammable objects, fuels, or products that produce flammable vapors.
- Keep the area around the muffler free of debris such as leaves, paper, cartons, etc. A hot muffler could ignite the debris and start a fire.

Safety devices, controls, and attachments

Only operate the machine when:

- All safety devices and guards are in place and in working order.
- All controls operate correctly.
- The machine is set up correctly according to the instructions in the Operator's Manual.
- The machine is clean.
- The machine's labels are legible.

To ensure safe operation of the machine:

- Do not operate the machine if any safety devices or guards are missing or inoperative.
- Do not modify or defeat the safety devices.
- Only use accessories or attachments that are approved by Wacker Neuson.

Safe operating practices

When operating this machine do:

- Remain aware of the machine's moving parts. Keep hands, feet, and loose clothing away from the machine's moving parts
- Always remain seated and wear the seat belt at all times while operating the machine.
- Keep clear of the articulated steering joint between the front and rear frames.
- Always disengage and stow the locking bar for the articulated steering joint before operating the machine. The machine cannot be steered when the locking bar is engaged.

When operating this machine:

- Do not operate a machine in need of repair.
- Do not drive over curbs or other uneven objects that will result in the machine and operator being shaken.
- Do not attempt to start the machine when standing alongside it. Only start the engine when seated in the driver's seat and with the forward/reverse control in the neutral position.
- Do not leave the machine running unattended.
- Do not use a cellphone or send text messages while operating this machine.
- Do not consume the operating fluids used in this machine. Depending on your machine model, these operating fluids may include water, wetting agents, fuel (gasoline, diesel, kerosene, propane, or natural gas), oil, coolant, hydraulic fluid, heat transfer fluid (propylene glycol with additives), battery acid, or grease.

Personal Protective Equipment (PPE)

Wear the following Personal Protective Equipment (PPE) while operating this machine:

- Close-fitting work clothes that do not hinder movement
- Safety glasses with side shields
- Hearing protection
- Safety-toed footwear



After use

- Stop the engine when the machine is not being operated.
- Close the fuel valve on engines equipped with one when the machine is not being operated.
- Ensure that the machine will not tip over, roll, slide, or fall when not being operated.
- Store the machine properly when it is not being used. The machine should be stored in a clean, dry location out of the reach of children.

1.4 Operating the Machine in Electrical Storms

**WARNING**

Operating this machine in an electrical storm can be hazardous. You can be injured or killed by lightning.

- ▶ Be aware of deteriorating weather conditions and approaching electrical storms.
- ▶ Stop work and get to a safe shelter before lightning strikes occur.

Reducing risk of injury

If lightning strikes occur in the vicinity of the work area, there are two methods of reducing risk of injury:

1. If you are on the ground:
 - ▶ Stay away from the machine.
 - ▶ Do not attempt to climb onto the machine or into the operator's seat.
2. If you are in the operator's seat:
 - ▶ Remain in the operator's seat.
 - ▶ Do not attempt to climb off the machine.

1.5 Service Safety

Service training

Before servicing or maintaining the machine:

- Read and understand the instructions contained in all manuals delivered with the machine.
- Familiarize yourself with the location and proper use of all controls and safety devices.
- Only trained personnel shall troubleshoot or repair problems occurring with the machine.
- Contact Wacker Neuson for additional training if necessary.

When servicing or maintaining this machine:

- Do not allow improperly trained people to service or maintain the machine. Personnel servicing or maintaining the machine must be familiar with the associated potential risks and hazards.

Precautions

When servicing or maintaining the machine:

- Read and understand the service procedures before performing any service to the machine.
- All adjustments and repairs must be completed before operating the machine. Do not operate the machine with a known problem or deficiency.
- All repairs and adjustments shall be completed by a qualified technician.
- Turn off the machine before performing maintenance or making repairs.
- Remain aware of the machine's moving parts. Keep hands, feet, and loose clothing away from the machine's moving parts.
- Re-install the safety devices and guards after repair and maintenance procedures are complete.

Machine modifications

When servicing or maintaining the machine:

- Use only accessories/attachments that are approved by Wacker Neuson.

When servicing or maintaining the machine:

- Do not defeat safety devices.
- Do not modify the machine without the express written approval of Wacker Neuson.

Replacing parts and labels

- Replace worn or damaged components.
- Replace all missing and hard-to-read labels.
- When replacing electrical components, use components that are identical in rating and performance to the original components.
- When replacement parts are required for this machine, use only Wacker Neuson replacement parts or those parts equivalent to the original in all types of specifications, such as physical dimensions, type, strength, and material.

Cleaning

When cleaning and servicing the machine:

- Keep the machine clean and free of debris such as leaves, paper, cartons, etc.
- Keep the labels legible.

When cleaning the machine:

- Do not clean the machine while it is running.
 - Never use gasoline or other types of fuels or flammable solvents to clean the machine. Fumes from fuels and solvents can become explosive.
-

**Personal
Protective
Equipment
(PPE)**

Wear the following Personal Protective Equipment (PPE) while servicing or maintaining this machine:

- Close-fitting work clothes that do not hinder movement
- Safety glasses with side shields
- Hearing protection
- Safety-toed footwear

In addition, before servicing or maintaining the machine:

- Tie back long hair
- Remove all jewelry (including rings)

1.6 Operator Safety while Using Internal Combustion Engines



WARNING

Internal combustion engines present special hazards during operation and fueling. Failure to follow the warnings and safety standards could result in severe injury or death.

- Read and follow the warning instructions in the engine owner's manual and the safety guidelines below.



DANGER

Exhaust gas from the engine contains carbon monoxide, a deadly poison. Exposure to carbon monoxide can kill you in minutes.

- NEVER operate the machine inside an enclosed area, such as a tunnel, unless adequate ventilation is provided through such items as exhaust fans or hoses.

Operating safety

When running the engine:

- Keep the area around the exhaust pipe free of flammable materials.
- Check the fuel lines and the fuel tank for leaks and cracks before starting the engine. Do not run the machine if fuel leaks are present or the fuel lines are loose.

When running the engine:

- Do not smoke while operating the machine.
- Do not run the engine near sparks or open flames.
- Do not touch the engine or muffler while the engine is running or immediately after it has been turned off.
- Do not operate a machine when its fuel cap is loose or missing.
- Do not start the engine if fuel has spilled or a fuel odor is present. Move the machine away from the spill and wipe the machine dry before starting.

Refueling safety

When refueling the engine:

- Clean up any spilled fuel immediately.
- Refill the fuel tank in a well-ventilated area.
- Re-install the fuel tank cap after refueling.
- Use suitable tools for refueling (for example, a fuel hose or funnel).

When refueling the engine:

- Do not smoke.
- Do not refuel a hot or running engine.
- Do not refuel the engine near sparks or open flames.

1.7 Hydraulic Fluid Safety



WARNING

Possibility of severe injury. Hydraulic fluid is under high pressure and becomes very hot during operation.

- To avoid injury, obey the safety instructions listed below.

Safety instructions

- Inspect the hydraulic system thoroughly before operating the machine.
- Do not touch hydraulic fluid or hydraulic components while the machine is operating. Wait until the machine is cool.
- Before disconnecting hydraulic fittings or hoses, ensure that all pressure has been bled from the circuit. Set all controls in neutral, turn engine off, and allow the fluids to cool before loosening hydraulic fittings or attaching test gauges.
- Hydraulic fluid escaping under high pressure may penetrate the skin, cause burns, blind, or cause other serious injuries or infections. Contact a physician immediately for treatment if your skin has been penetrated by hydraulic fluid, even if the wound seems minor.
- Fluid leaks from small holes are often practically invisible. Do not use your bare hands to check for leaks. Check for leaks using a piece of cardboard or wood.
- Hydraulic fluid is extremely flammable. Stop the engine immediately if a hydraulic leak is detected.
- After servicing the hydraulics, make sure all components are reconnected to the proper fittings. Failure to do so may result in damage to the machine and/or injury to a person on or near the machine.

1.8 Safety Guidelines for Lifting and Transporting the Machine

When lifting the machine:


- Make sure slings, chains, hooks, ramps, jacks, forklifts, cranes, hoists, and any other type of lifting device used is attached securely and has enough weight-bearing capacity to lift or hold the machine safely. See chapter *Technical Data* for machine weight.
- Remain aware of the location of other people when lifting the machine.
- Only use the lifting points and tie-downs described in the Operator's Manual.
- Make sure the transporting vehicle has sufficient load capacity and platform size to safely transport the machine.

To reduce the possibility of injury:

- Do not stand under or get onto the machine while it is being lifted or moved.







2 Labels—RD 16








2.1 Label Locations











wc_gr002973






2.2 Label Meanings






| | | |
|-----------------|---|--|
| <p>A</p> |  <p>150349</p>  <p>178714</p> | <p>Read and understand the supplied Operator's Manual before operating the machine. Failure to do so increases the risk of injury to yourself and others.</p> |
| <p>B</p> |  <p>0178715</p> | <p>DANGER Asphyxiation hazard</p> <ul style="list-style-type: none"> Engines emit carbon monoxide. Do not run the machine indoors or in an enclosed area unless adequate ventilation, through such items as exhaust fans or hoses, is provided. Read the Operator's Manual. No sparks, flames, or burning objects near the machine. Stop the engine before refueling. <p>Use only clean, filtered diesel fuel.</p> |
| <p>C</p> |  <p>113726</p> | <p>Tie-down point</p> |
| <p>D</p> |  <p>110164</p>  <p>178711</p> | <p>WARNING Pressurized contents. Do not open when hot!</p> |




| | | |
|----------|--|---|
| E |  <p>0117045</p>  <p>178714</p> | <p>CAUTION Read and understand the supplied Operator's Manual before operating this machine. Failure to do so increases the risk of injury to yourself and others.</p> |
| F |  <p>110178</p>  <p>178710</p> | <p>WARNING Pinch point.</p> |
| G |  <p>117039</p>  <p>178713</p> | <p>WARNING Hot surface</p> |
| I |  | <p>Hydraulic oil reservoir fill Torque nuts to 13.6-14.7 Nm (120-130 in.lbs.) maximum.</p> |








| | | |
|---|---|--|
| J |  <p>0176110 178709</p> | <p>NOTICE Lifting point</p> |
| K |  <p>114789 0178714</p> | <p>WARNING To reduce the risk of hearing loss, always wear hearing protection when operating this machine.</p> |
| L |  <p>154657 178717</p> | <p>WARNING Entanglement hazard. Rotating machinery. Do not reach inside machine when engine is running.</p> |
| M |  <p>161701 178707</p> | <p>WARNING Disconnect battery before servicing. Read Repair Manual for instructions. Battery contains caustic acid and potentially explosive hydrogen gas.</p> |




| | | |
|----------|---|--|
| <p>N</p> |  | <p>WARNING</p> <p>Always wear seat belt when operating roller.</p> |
| <p>O</p> |  | <p>WARNING</p> <p>Avoid crushing area.</p> |
| <p>P</p> |  | <p>WARNING</p> <p>Entanglement hazard. Rotating machinery. Do not reach inside machine when engine is running.</p> |
| <p>Q</p> |  | <p>Parking brake is disengaged.</p> <p>Parking brake is engaged.</p> |

| | | |
|---|---|---|
| R |  | Be sure the machine is on a firm, level surface and will not tip, roll, slide, or fall while operating. |
| S | <div data-bbox="289 468 615 678"> <p>COOLANT OVERFLOW BOTTLE ONLY, NOT A RETURN SYSTEM</p> <p>NUR KÜHLMITTELÜBERLAUFFLASCHÉ -- KEIN RÜCKHÖLSSYSTEM!</p> <p>BOTELLA DE REBÓSE DEL ENFRIADOR -- NO ES UN SISTEMA DE RETORNO</p> <p>BOUEILLE DE TROP-PLEIN DE L'AGENT REFRIGÉRANT SEULEMENT; CE N'EST PAS UN SYSTÈME DE RETOUR</p> </div> <div data-bbox="293 680 358 699">0164979</div>  | Coolant overflow bottle only, not a return system. |
| T |   | Engine oil drain |
| U |  | Grease points: Inspect and lubricate every 100 hours of operation. |

| | | |
|----------|---|--|
| <p>V</p> |   | <p>WARNING Avoid crushing area. Articulated steering joint locking location. Lock the articulated steering joint before servicing the machine. Read Repair Manual.</p> |
| <p>X</p> |  | <p>Guaranteed sound power level in dB(A)</p> |
| <p>Z</p> |   | <p>CAUTION No lift point</p> |


| | | |
|----|--|---|
| AA |  <p>0165018</p> | Disconnect battery before servicing. |
| BB |  <p>165019</p> | <p>Lifting of machine to be done with spreader bar only!</p> <ul style="list-style-type: none"> ■ Lock the articulated joint. ■ Attach a lifting hook to the lifting eye at the top of the spreader bar. ■ Attach the lifting chains to the ends of the spreader bar. ■ Do not use inappropriate lifting equipment. |
| CC |  <p>0165584</p> <p>0178702</p> | CAUTION! Electric shock hazard at auxiliary battery positive terminal. Never touch this terminal and a metal portion of the machine simultaneously. |

| | | |
|----|--|--|
| DD |  <p>0113831</p>  <p>178714</p> | Read and understand the supplied Operator's Manual before operating the machine. Failure to do so increases the risk of injury to yourself and others. |
| EE |  <p>172281</p>  <p>178706</p> | Water tank fill |
| FF |  | This machine may be covered by one or more patents. |
| GG |  <p>180563</p>  | Low sulfur fuel or ultra low sulfur fuel only. |

| | | |
|----|---|---|
| HH |  <p>Operation of This Equipment May Create Sparks That Can Start Fires Around Dry Vegetation. A Spark Arrestor May be Required. The Operator Should Contact Local Fire Agencies For Laws or Regulations Relating to Fire Prevention Requirements. Per CAL. PRC. CODE</p> | <p>WARNING</p> <p>Operation of this equipment may create sparks that can start fires around dry vegetation. A spark arrester may be required. The operator should contact local fire agencies for laws or regulations relating to fire prevention requirements.</p> |
| JJ |  <p>5200005890</p> | <p>WARNING</p> <p>Explosion hazard.</p> <ul style="list-style-type: none"> ■ Do not use evaporative starting fluids such as ether on this engine. ■ The engine is equipped with a cold starting aid. Using evaporative starting fluids can cause an explosion which can cause engine damage, personal injury, or death. ■ Read and follow the engine starting instructions in this Operator's Manual. |
| KK |  <p>0183189</p> | <p>WARNING</p> <ul style="list-style-type: none"> ■ Keep all sparks and open flames away from the battery. ■ Wear eye protection. ■ Keep away from children. ■ Battery acid is poisonous and corrosive. ■ Read the Operator's Manual. ■ Explosion hazard. <p>Dispose of waste batteries in accordance with local environmental regulations. Battery contains mercury (Hg), cadmium (Cd), or lead (Pb).</p> |






3 Labels—RD 12, RD 12A







3.1 Label Locations












wc_gr002988







3.2 Label Meanings



| | | |
|---|--|---|
| A |  <p>150349</p> | <p>Read and understand the supplied Operator's Manual before operating the machine. Failure to do so increases the risk of injury to yourself and others.</p> |
| B |  <p>117034</p> | <p>DANGER Asphyxiation hazard</p> <ul style="list-style-type: none"> Engines emit carbon monoxide. Do not run the machine indoors or in an enclosed area unless adequate ventilation, through such items as exhaust fans or hoses, is provided. Read the Operator's Manual. No sparks, flames, or burning objects near the machine. Stop the engine before refueling. <p>Use only clean, filtered diesel fuel.</p> |
| C |  <p>113726</p> | <p>Tie-down point</p> |
| E |  <p>0117045</p> | <p>CAUTION Read and understand the supplied Operator's Manual before operating this machine. Failure to do so increases the risk of injury to yourself and others.</p> |
| F |  <p>110176</p> | <p>WARNING Pinch point.</p> |

| | | |
|---|---|--|
| G |  <p>117039</p> | WARNING Hot surface |
| H |  <p>117037</p> | WARNING Hot surface |
| I |  | Hydraulic oil reservoir fill Torque nuts to 13.6-14.7 Nm (120-130 in.lbs.) maximum. |
| J |  <p>0176110</p> | NOTICE Lifting point |
| K |  <p>114789</p> | WARNING To reduce the risk of hearing loss, always wear hearing protection when operating this machine. |
| M |  <p>151701</p> | WARNING Disconnect battery before servicing. Read Repair Manual for instructions. Battery contains caustic acid and potentially explosive hydrogen gas. |

| | | |
|---|--|---|
| N |  <p>118362</p> | <p>WARNING Always wear seat belt when operating roller.</p> <p>Read the Operator's Manual for machine information.</p> |
| T |  <p>111849</p> | <p>Choke: O = Open</p> <p>I = Closed</p> |
| U |  | <p>Grease points: Inspect and lubricate every 100 hours of operation.</p> |
| V |  <p>0165014</p> | <p>WARNING Avoid crushing area. Articulated steering joint locking location. Lock the articulated steering joint before servicing the machine. Read Repair Manual.</p> |

| | | |
|----|---|---|
| W |  <p>0165001</p> | Engine will stop without operator seated. |
| X |  | Guaranteed sound power level in dB(A) |
| Z |  <p>0165020</p> | CAUTION No lift point |
| AA |  <p>5200000025</p> | WARNING Do not drill or weld the ROPS. Read the Operator's Manual. |
| CC |  <p>0165584</p> | CAUTION! Electric shock hazard at auxiliary battery positive terminal. Never touch this terminal and a metal portion of the machine simultaneously. |

| | | |
|----|--|--|
| DD |  <p>0113831</p> | Read and understand the supplied Operator's Manual before operating the machine. Failure to do so increases the risk of injury to yourself and others. |
| EE |  <p>172281</p> | Water tank fill |
| FF |  | This machine may be covered by one or more patents. |
| GG |  <p>119319</p> | WARNING Avoid crushing area. |
| HH |  | Emission Control Information This equipment meets U.S. EPA EVAP standards. Evaporative Family: CW1XPNEQCL2 Exempt from tank permeation standards under 40 CFR 1054.145. |
| JJ |  | WARNING Operation of this equipment may create sparks that can start fires around dry vegetation. A spark arrester may be required. The operator should contact local fire agencies for laws or regulations relating to fire prevention requirements. |

| | | |
|-----------|---|---|
| KK |  | <p>WARNING</p> <ul style="list-style-type: none"> ■ Keep all sparks and open flames away from the battery. ■ Wear eye protection. ■ Keep away from children. ■ Battery acid is poisonous and corrosive. ■ Read the Operator's Manual. ■ Explosion hazard. <p>Dispose of waste batteries in accordance with local environmental regulations. Battery contains mercury (Hg), cadmium (Cd), or lead (Pb).</p> |
| LL |  | <p>NOTICE</p> <p>Lifting point</p> <ul style="list-style-type: none"> ■ Lock articulated joint. ■ Attach chains to the lifting eyes on machine. ■ Attach chains to hook on lifting equipment. |

4 Lifting and Transporting

4.1 Locking and Unlocking the Articulated Joint

Description A lockarm located below the articulated joint is provided to fasten the front and rear halves of the roller together. Once secured, the lockarm prevents the two halves from swinging together.


**WARNING**

Pinching / crushing hazards.

- Always install the lockarm before you lift the machine, transport the machine, or perform maintenance near the center of the machine.

Locking

Move the lockarm **(a)** to the LOCKED position **(1)**. Fasten the lockarm in place with the retaining pin **(b)**.



wc_gr010278

Unlocking

Remove the retaining pin and move the lockarm to the UNLOCKED position **(2)** before you operate the machine. Re-insert the retaining pin in the lockarm.

NOTICE: Attempting to steer the machine with the lockarm in the locked position may damage the steering cylinder and locking mechanism.

4.2 Lifting the Machine

- Requirements**
- Lifting equipment (crane or hoist) capable of supporting the machine's weight. See the *Technical Data Chapter* for your machine.
 - Lifting devices (hooks, chains, and shackles) capable of supporting the machine's weight.
 - Engine stopped.
 - All access covers closed and secured.



WARNING

Crushing hazard. You may be crushed if the lifting devices fail.

- Never stand under, or get onto, the machine while it is being lifted or moved.



WARNING



Crushing hazard. The machine can drop if it is lifted by the ROPS or any other part of the frame. These components are not designed to support the weight of the machine.

- Use only the designated lifting points to lift the machine.

Procedure

Perform the procedure below to lift the machine.

1. Stop the engine.
2. Engage the parking brake.
3. Lock the articulated steering joint **(a)**.
4. For the RD 16, get the spreader bar from the storage location **(c)**.
5. For the RD 16, attach a lifting hook to the lifting eye at the top of the spreader bar.




wc_gr012216

6. For the RD 16, attach the lifting chains to the ends of the spreader bar.

This procedure continues on the next page.

Continued from the previous page.

7. There are two lifting eyes (**b**) per side. Attach one lifting chain to each lifting eye.



wc_gr012269

8. For the RD 12, attach the chains to the hook (**d**) of the lifting equipment.
9. Lift the machine a small distance.



WARNING

Crushing hazard. An unstable machine may cause the lifting device to fail. You may be crushed if the lifting device fails.

- Check for machine stability before continuing.


10. Check for stability. If necessary, lower the machine, reposition the lifting devices, and lift the machine a small distance again.
11. Continue lifting the machine only when it is stable.

4.3 Tying Down and Transporting the Machine

- Requirements**
- Engine shut down
 - Parking brake ON

Procedure Perform the procedure below to tie down the machine.

1. Make sure that the transport vehicle is capable of handling the weight and size of the machine. See *Technical Data* for dimensions and operating weight.
2. Lock the articulated steering joint **(a)**.



wc_gr010685

3. Block or chock the drums as shown.
4. Attach steel ropes or chains to each of the two tie down bars **(b)** on the front and rear of the machine.
5. Attach the other end of the chains to the transport vehicle.

NOTICE

- Do not position ropes or chains across the machine frame or the articulated joint when tying down the machine. Damage to the machine may occur.
- Do not completely compress the shock mounts when tying down the machine. Damage to the shock mounts may occur.
- Do not leave the machine tied down for extended periods of time (except when transporting). Damage to the shock mounts may occur.

4.4 Towing the Machine

- Requirements**
- Second machine of greater size and rigid towing equipment, or
 - Two machines of equal size to towed machine if non-rigid towing equipment is being used
 - Shielding for all machines being used
- Note:** *The strength of the towing line or the tow bar should be at least 150 percent of the gross weight of the towing machine.*
-

- Limitations**
- The following limitations must be followed:
- Limit towing to emergency situations only
 - Limit towing to short distances
 - Limit towing speed to 2 km/h (1.2 mph)
 - Limit tow line angle to 30°
-

- Procedure**
- Perform the procedure below to tow the machine.
- Note:** *If the engine runs and the steering system and/or braking system functions, an operator may be allowed to ride on and steer the machine being towed. In all other cases, do not ride on the machine when it is being towed.*
1. Attach shielding to the machines to protect the operators if the towing equipment breaks.
 2. Block the drums so that the machine cannot move.
 3. Open the engine compartment.
 4. Manually disengage the SAHR brakes. (See topic *Manually Releasing The Parking Brake*.)
 5. Attach the tow line to the machine at the tow points.
 6. Attach the tow line to the towing vehicle(s).
 7. Remove the blocks from the drums.
 8. Tow the disabled machine at a slow rate of speed to the desired location.
 9. Once the machine is at the desired location, securely block the drums. This will prevent movement of the machine.
 10. Close the bypass valve.
 11. For the RD 12 machines, manually re-engage the parking brake.
 12. Remove the tow lines.

4.5 Manually Releasing the Parking Brake


There are two drive motors on the roller—one on each drum. Each drive motor includes a parking brake that is spring activated and hydraulically released (SAHR).

NOTICE: To avoid damaging the internal mechanism, do not use power tools to release or reactivate the brakes.

Note: *This procedure must be performed on both drums.*

To manually release the brakes:

1. Chock each drum to prevent the machine from moving.
2. Lock the articulated steering joint. See section *Articulation Joint Lockarm*.
3. Using an 8mm Allen wrench, remove the plugs **(a)** in order to access the release screws **(b)**.



4. Using a 6mm Allen wrench, press and turn each release screw in until its threads catch in the brake plate **(d)**. Tighten each release screw alternately until the spring **(c)** on each is fully compressed. You will feel a substantial difference in the amount of torque required to turn the screw once its spring is fully compressed.
5. Continue to tighten (turn clockwise) the two release screws to compress the brake plate springs. Alternate back-and-forth between the two screws, turning approximately 45° at a time, until the drums are no longer held by the brake plate. The brake plate should release after turning each screw approximately two (2) turns.

This procedure continues on the next page.

Continued from the previous page.

NOTICE: Maximum torque for the release screws is 33 Nm (24.3 ft.lbs.). Overtightening the release screws can destroy the internal mechanism.

6. Manually turn the drum to test if the brake is released.
7. Replace the plugs, tightening them to a maximum torque of 60 ± 6 Nm (44.2 ± 4.4 ft.lbs.).

To reactivate the brakes, carry out the following procedure on both drums.

8. Remove the plugs **(a)**.
9. Alternating between the two release screws **(b)**, completely loosen them until the brake plate is disengaged.
10. Replace the plugs, tightening them to a maximum torque of 60 ± 6 Nm (44.2 ± 4.4 ft.lbs.).


Note: After repair, ensure that the releasing screws are back in the normal operating position.

Note: Replacement drive motors come with the brakes in the ON position.

4.6 Towing Bypass Valve

The drive circuit is equipped with a towing valve (43) to allow oil to bypass the drive motors and let the roller freewheel for towing.

The towing valve should be used in emergency cases where the machine has become bogged down in loose or muddy soil, or cannot be driven due to an engine or hydraulic system failure.



WARNING

With the towing valve open, the drive circuit has no braking action and the machine will roll freely.

- ▶ Apply the brake or attach the towing device before opening the towing valve.
 - ▶ Close the towing valve immediately after the towing operation is complete to prevent the machine from rolling unexpectedly.
-


Procedure

1. To open the bypass, shut the engine off and rotate the shaft on the towing valve counter-clockwise.
2. To close the bypass, rotate the shaft on the towing valve clockwise.

Notes

5 Controls — RD 16

5.1 Features and Controls




wc_gr010748



| Ref. | Description | Ref. | Description |
|------|--|------|---------------------------------------|
| 1 | Air cleaner | 22 | Water tank fill cap |
| 2 | Articulated joint | 23 | Lockarm |
| 3 | Hand holds | 24 | Operator's platform |
| 4 | Control panel | 25 | Engine oil filter |
| 5 | Dipstick | 27 | Rear drum |
| 6 | Drain hose—hydraulic tank | 28 | Scraper bar (4 places) |
| 7 | Drive motor (2) | 29 | Sightglass—hydraulic tank |
| 8 | Drive pump | 30 | Sprinkler tube (2) |
| 9 | Engine hood | 31 | Steering wheel |
| 10 | Vibration control button | 32 | Steering cylinder (under floor panel) |
| 11 | Exciter motor (2) | 33 | Tiedown (2 places) |
| 12 | Exciter/Steering pump | 34 | Rotating beacon |
| 13 | Hydraulic filter—return line | 35 | Battery (under floor panel) |
| 14 | Hydraulic strainer—suction line | 36 | Hydraulic suction line |
| 15 | Forward/Reverse control | 37 | Grease fitting—exciter (4 places) |
| 16 | Front drum | 38 | Lifting eye (4 places) |
| 17 | Fuel tank fill cap | 39 | ROPS |
| 18 | Fuel filter | 40 | Adjustable seat with seat belt |
| 19 | Grease fittings—articulated joint (4 places) | 41 | Water drain |
| 20 | Hydraulic tank fill port | 42 | Parking brake button |
| 21 | Hydraulic manifold block | 45 | Auxiliary battery positive terminal |

5.2 Control Panel and Indicator Lights


RD 16 IRH



wc_gr004113

RD 16-90
RD 16-100

wc_gr010747

| Ref. | Item | Description |
|------|---|--|
| 46 | Turn signal switch (if equipped) | This switch activates the turn signal, either right or left. |
| 47 | Hour meter | This instrument meters machine usage. |
| 48 | Engine coolant temperature indicator | This light illuminates to indicate that the engine has overheated. <i>NOTICE:</i> Trace the cause of overheating and rectify the situation before operating the machine. |
| 49 | Low oil pressure indicator | This light illuminates when the ignition switch (55) is in the on position and the engine is not running; it goes out once the engine has started. If the light illuminates when the engine is running, it indicates that the oil pressure is low. Possible causes for the light to illuminate: <ul style="list-style-type: none"> ■ Oil level is too low. ■ Incorrect oil viscosity for the time of year. ■ Fault in the oil circuit. Do not operate the machine if the light is illuminated. |
| 50 | Vibration ON indicator | This indicator light illuminates to indicate that the vibration is on. |
| 51 | Hazard lights switch | This switch activates the hazard lights, either on or off. |
| 52 | Light switch (if equipped)  | This switch controls power to the lights. A: Parking lights ON B: Front work lights ON C: Rear work light ON D: All lights OFF |
| 53 | Turn signal indicator | This indicator will flash to indicate that the turn signal has been activated. |
| 54 | Throttle switch | This switch sets the position of the throttle, either high or low. |
| 55 | Start switch | This switch starts or stops the engine. |
| 56 | Low fuel indicator | This indicator light illuminates to indicate that the fuel level is low. |

| Ref. | Item | Description |
|------|---|---|
| 57 | Air filter restriction indicator | This indicator light illuminates to indicate that the air cleaner needs to be changed. |
| 58 | Glow plugs indicator | This indicator light illuminates to indicate that the glow plugs are on. |
| 59 | Parking brake indicator | This indicator light illuminates to indicate that the parking brake button is activated. |
| 60 | Battery indicator | This indicator light illuminates when the battery is not charging. |
| 61 | Water spray switch | This switch turns the water pump on and off. |
| 62 | Water spray dial | This switch sets the frequency at which the water pump turns on and off when in the automatic mode. |
| 63 | Vibration switch—Both drums and front drum only | This switch selects vibration in either the front drum or both drums. |
| 64 | Horn button | Push this button to sound the horn. |
| 65 | 12V power outlet | Auxiliary power outlet |
| 66 | Work lights indicator (if equipped) | This indicator light illuminates to indicate that the work lights are on. |
| 67 | Hazard lights indicator (if equipped) | This indicator light illuminates to indicate that the hazard lights are on. |

5.3 Auxiliary Battery Positive Terminal

This machine is equipped with an auxiliary battery positive terminal **(45)** located on top of the hydraulic tank. The auxiliary terminal is a convenient location for accessing the battery if it ever needs to be jumped.

**CAUTION**

Electric shock hazard.


- Do not touch this terminal and a metal portion of the machine simultaneously.



wc_gr004357

6 RD 12 and RD 12A Controls


6.1 Features and Controls



wc_gr002946

| Ref. | Description | Ref. | Description |
|------|--|------|---------------------------------------|
| 1 | Air cleaner | 24 | Operator's platform |
| 2 | Articulated joint | 25 | Engine oil filter |
| 3 | Hand holds | 26 | Rear drum fill/drain plug |
| 4 | Control panel | 27 | Rear drum—static |
| 5 | Dipstick | 28 | Scraper bar (4 places) |
| 6 | Drain hose—hydraulic tank | 29 | Sightglass—hydraulic tank |
| 7 | Drive motor | 30 | Sprinkler tube (2) |
| 8 | Drive pump | 31 | Steering wheel |
| 9 | Engine hood | 32 | Steering cylinder (under floor panel) |
| 10 | Vibration control button | 33 | Tiedown (2 places) |
| 11 | Exciter motor | 34 | Beacon light (optional) |
| 12 | Exciter/Steering pump | 35 | Battery (under floor panel) |
| 13 | Hydraulic filter—return line | 36 | Hydraulic suction line |
| 14 | Hydraulic strainer—suction line | 37 | Grease fitting—exciter (2 places) |
| 15 | Forward / Reverse control | 38 | Lifting eye (4 places) |
| 16 | Front drum—vibratory | 39 | ROPS |
| 17 | Fuel tank fill cap | 40 | Seat with seatbelt |
| 18 | Fuel filter | 41 | Water drain |
| 19 | Grease fittings—articulated joint (4 places) | 42 | Parking brake |
| 20 | Hydraulic tank fill port | 43 | Tow valve |
| 21 | Hydraulic manifold block | 44 | Choke lever |
| 22 | Water tank fill cap | 45 | Auxiliary battery positive terminal |
| 23 | Lockarm | — | — |

6.2 Control Panel and Indicator Lights



wc_gr004114

| Ref. | Item | Function |
|------|-----------------------------|---|
| 47 | Hour meter | This instrument meters machine usage. |
| 50 | Vibration on indicator | This indicator light illuminates to indicate that the vibration is on. |
| 53 | Lights switch (if equipped) | This switch controls power to the lights. |
| 54 | Throttle switch | This switch sets the position of the throttle, either high or low. |
| 55 | Ignition switch | This switch starts or stops the engine. |
| 56 | Low fuel indicator | This indicator light illuminates to indicate that the fuel level is low. |
| 61 | Water spray switch | This switch turns the water pump on and off. |
| 62 | Water spray dial | This switch sets the frequency at which the water pump turns on and off when in the automatic mode. |
| 63 | Emergency stop switch | This switch shuts down the engine in an emergency. Pull the switch up to de-activate the switch. |

6.3 Auxiliary Battery Positive Terminal

This machine is equipped with an auxiliary battery positive terminal **(45)** located on top of the hydraulic tank. The auxiliary terminal is a convenient location for accessing the battery if it ever needs to be jumped.

**CAUTION**

Electric shock hazard.

- Do not touch this terminal and a metal portion of the machine simultaneously.



wc_gr004357

7 Operation

7.1 Preparing the Machine for First Use

1. Make sure all loose packaging materials have been removed from the machine.
2. Check the machine and its components for damage. If there is visible damage, do not operate the machine! Contact your Wacker Neuson dealer immediately for assistance.
3. Take inventory of all items included with the machine and verify that all loose components and fasteners are accounted for.
4. Attach component parts not already attached.
5. Add fluids as needed and applicable, including fuel, engine oil, and battery acid.
6. Move the machine to its operating location.

7.2 Position of the Operator

Safe and efficient use of this machine is the operator's responsibility. Full control of the machine is not possible unless the operator maintains the proper working position at all times.

While operating this machine, the operator must:

- be seated in the operator's seat facing forward
- wear the seat belt, properly adjusted and latched
- have both feet on the control deck
- have one hand on the steering wheel at all times
- have the other hand free to operate the controls as needed

7.3 Mounting and Dismounting the Machine


When climbing on and off the machine, maintain a three-point contact with the steps and the handholds.

Three-point contact can be:

- two feet and one hand
- one foot and two hands

NOTICE: Do not use the control lever when mounting or dismounting the machine. Use only the designated handholds on the ROPS and on the control column.

7.4 Fire Extinguisher Requirement

| | |
|---|---|
| Overview | A fire extinguisher is not supplied with this machine. However, a fire extinguisher must be mounted on the machine and made available for use according to local and national regulations. |
| Type | Select a fire extinguisher classified for use on engine-powered construction equipment. Contact organizations such as the U.S. National Fire Protection Agency (NFPA), International Code Council (ICC), or the American National Standards Institute (ANSI) for information about fire extinguisher classifications. |
| Installation | <p>Install the fire extinguisher according to the manufacturer's instructions. The installation must be performed by an authorized Wacker Neuson dealer or service center.</p> <p>Recommended mounting locations for the fire extinguisher on this machine are:</p> <ul style="list-style-type: none">■ Attached to the panel at the feet of the operator, adjacent to the control column■ Strapped to the ROPS |
|  | <p>WARNING</p> <p>Possibility of injury and equipment damage. Mounting the fire extinguisher improperly can weaken the ROPS or the water tank.</p> <ul style="list-style-type: none">► Do not drill into the ROPS or modify the structure in any way.► Do not drill into the operator pedestal except in the area adjacent to the control column. The water tank is directly beneath the operator pedestal. |
| Safety information | <ul style="list-style-type: none">■ Check the fire extinguisher at regular intervals to make sure that the unit is fully charged and operational.■ Before each use of the machine, make sure that the fire extinguisher is securely mounted in place and fasteners are tight. |

7.5 Roll Over Protection Structure (ROPS)

Background The machine is equipped with a Roll Over Protection Structure (ROPS). The ROPS is designed to protect the operator in a rollover accident. Depending on the machine model, the ROPS is either fixed (stationary) or foldable.

A foldable ROPS is equipped with two sets of hinge pins, or loking pins. This enables the ROPS to be folded either forward or backward as required for transportation or storage.



WARNING

Crushing hazard. Without a ROPS, you may be crushed if the machine rolls or tips.

- ▶ Never operate the machine without the ROPS in place and securely fastened in the upright position.
-



WARNING

Crushing / machine damage hazards. The ROPS is intended strictly to protect the operator during a rollover or tip-over incident and must not be used to lift the machine.

- ▶ Use only the designated lifting eyes to lift the machine. See *Lifting the Machine*.
-



WARNING

Personal injury hazard. The ROPS is not a handhold for passengers. Passengers can be seriously injured or killed from falls, tip-overs, or roll-over incidents.

- ▶ Do not allow anyone to ride on any part of the machine.
-

Checking ROPS condition

Each month, check:

- ☐ the torque on all of the screws holding the ROPS in place
 - ☐ the ROPS frame for rust, cracks, and any other damage
-

Rules for re-installing

When reinstalling the ROPS:

- Use the original nuts and bolts.
- Tighten the bolts to the specified torques.

NOTICE: Do not weld or drill into the ROPS. Drilling or welding on the ROPS will nullify the ROPS certification.

Raising the ROPS

Follow the procedure below to raise the ROPS.




WARNING

Pinching / crushing hazard.

- ▶ Keep fingers and extremities away from the pivot points when raising or lowering a foldable ROPS.
-

This procedure continues on the next page.

Continued from the previous page.



wc_gr012560

1. Support the upper half of the ROPS (3) using a crane and suitable rigging capable of supporting 19 kg (42 lbs.).



WARNING

Crushing hazard.

- Do not remove all cotter pins and locking pins from each side of the ROPS at the same time. One set of cotter pins and locking pins must always remain installed on each side of the ROPS during the lifting process.

2. Each side of the ROPS is equipped with two locking pins (1) held in place with two cotter pins (2). Remove the appropriate cotter pins (2) and pull out the corresponding locking pins (1).
3. Lift the ROPS into the upright position.
4. Insert the locking pins and secure them with the washers (5) and cotter pins.
5. Tighten the adjusting handle (screw) (4) to reduce vibration.

The ROPS is now in position and ready for service.

Lowering the ROPS

Follow the procedure below to lower the ROPS.

1. Support the upper half of the ROPS (3) using a crane and suitable rigging capable of supporting 19 kg (42 lbs.).
2. Remove the appropriate cotter pins (2) and pull out the corresponding locking pins (1).
3. Gently lower the upper half of the ROPS.

NOTICE: When lowering the ROPS, do not drop the upper frame. Sudden impacts can weaken or damage the ROPS.


4. Insert the locking pins and secure them with the washers (5) and cotter pins.

7.6 Rotating Beacon (if equipped)

The rotating beacon (a) powers up when the ignition switch is turned to the ON position. The beacon illuminates and rotates when powered up.

To install the beacon:

1. Slide the rotating beacon onto the light staff.
2. Tighten the wing nut on the base of the light.



wc_gr012267

7.7 Operator Presence System

The machine is equipped with an “operator presence system”. This system is part of the seat and senses the weight of an operator in the seat. During operation, if the operator leaves the seat:


- RD 12 / 12A—the engine will shut down
- RD 16—the brakes will activate and the engine will not shut down

When the operator sits down again, the forward/reverse control must be placed in the neutral position before the roller can be moved or the vibration can be started. The RD 12 / 12A engine will need to be restarted to continue operation.

Note: A one-half second delay keeps the system from tripping when the roller passes over a bump.

If the roller is supplied with an adjustable seat, it can be adjusted as follows:

- Knob **(a)** for adjusting the seat tension to the operator's weight.
- Lever **(b)** for adjusting the distance from the seat to the controls.



wc_gr002962

Note: Do not change position of the operator's seat while the machine is moving. The “OPERATOR PRESENCE” safety device will prevent all machine movements if an operator is not seated.



WARNING

Possibility of injury.

- Always wear the seat belt provided when operating the roller.

7.8 Recommended Fuel—Diesel

Low temperatures cause diesel fuel to gel. Always use the proper fuel for the conditions. Follow the guidelines in the table below.

| Lowest expected ambient temperature °F (°C) | Recommended fuel |
|---|--|
| Above 25 (-4) | #2 diesel plus additives (ultra low sulfur fuel only) |
| 5 to 25 (-15 to -4) | |
| Below 5 (-15) | Winter-blend diesel (ultra low sulfur fuel only) |

NOTICE: Do not use B20 or any other type of biodiesel fuel in this machine.



CAUTION

Fire hazard.

- Do not use gasoline, crankcase oil, or any oil containing gasoline.

7.9 Recommended Fuel—Gasoline

The engine requires regular grade unleaded gasoline. Use only fresh, clean gasoline. Gasoline containing water or dirt will damage the fuel system. Consult the engine owner's manual for complete fuel specifications.

Use of oxygenated fuels

Some conventional gasolines are blended with alcohol. These gasolines are collectively referred to as oxygenated fuels. If you use an oxygenated fuel, be sure it is unleaded and meets the minimum octane rating requirement.

Before using an oxygenated fuel, confirm the fuel's contents. Some states and provinces require this information to be posted on the fuel pump.

The following is the Wacker Neuson approved percentage of oxygenates:

ETHANOL - (ethyl or grain alcohol) 10% by volume. You may use gasoline containing up to 10% ethanol by volume (commonly referred to as E10). Gasoline containing more than 10% ethanol (such as E15, E20, or E85) may not be used because it could damage the engine.

If you notice any undesirable operating symptoms, try another service station, or switch to another brand of gasoline.

Fuel system damage or performance problems resulting from the use of an oxygenated fuel containing more than the percentages of oxygenates mentioned above are not covered under warranty.

7.10 Refueling the Machine

- Requirements**
- Machine shut down
 - Engine cool
 - Machine/fuel tank level with the ground
 - Fresh, clean fuel supply

Procedure Perform the procedure below to refuel the machine.



WARNING

Fire hazard. Fuel and its vapors are extremely flammable. Burning fuel can cause severe burns.

- ▶ Keep all sources of ignition away from the machine while refueling.
 - ▶ Do not refuel if the machine is positioned in a truck fitted with a plastic bed liner. Static electricity can ignite the fuel or fuel vapors.
 - ▶ Refuel only when the machine is outdoors.
 - ▶ Clean up spilled fuel immediately.
-

1. Remove the fuel cap.
 2. Fill the fuel tank until the fuel level reaches the bottom of the fuel tank neck.
-



CAUTION

Fire and health hazard. Fuel expands when heated. Expanding fuel in an over-filled tank can lead to spills and leaks.

- ▶ Do not overfill the fuel tank.
-


3. Re-install the fuel cap.
-

Result The procedure to refuel the machine is now complete.

7.11 Positioning the Scrapers

- Requirements**
- Machine shut down
 - Parking brake engaged

Positions Each drum has two scrapers (**a**, **b**). Scrapers prevent dirt and asphalt from sticking to and accumulating on the drum surface. They are spring loaded, and may be set in the travel position (**1**) or the scraping position (**2**) by moving the bar up or down.




wc_gr010268

7.12 Using the Seat Belt

Precaution Always use the seat belt when operating the machine.

To use To use the seat belt:

1. Pull seat belt **(c)** out of the retractor in a continuous motion.



wc_gr002238

2. Fasten seat belt catch **(b)** into buckle **(a)**.
3. Position the seat belt low across the lap of the operator. The retractor will adjust the belt length and the retractor will lock in place.
4. Push the release button **(d)** on the buckle in order to release the seat belt. The seat belt will automatically retract into the retractor.



CAUTION


Possibility of injury. A worn seat belt may not protect the operator in an emergency.

- Replace the seat belt every three years.

7.13 Using the Forward / Reverse Lever

Background Both roller drums are driven. An infinitely variable displacement pump drives the hydraulic motors fitted to each drum. The machine moves forward or reverse by using the forward/reverse lever located to the side of the operator's seat.

Travel direction Move the forward/reverse lever into FORWARD (**f**) or REVERSE (**r**) according to the direction of travel desired.



wc_gr010750

To change direction of travel from FORWARD to REVERSE or vice versa:

1. Move the forward/reverse lever to the "N" NEUTRAL position (**n**).
2. Allow the machine to come to a complete stop.
3. Move the forward/reverse lever in the direction desired.

Note: In order to comply with safety standards, the machine has a device which only enables starting of the engine when the forward/reverse lever is in the neutral position.

Travel speed

- Travel speed varies from "ZERO" to a permitted maximum of 10 kph (6.2 mph).
- The farther forward or reverse the forward/reverse lever is positioned, the faster the roller will travel.
- Travel speed is the same in both FORWARD and REVERSE.

Note: When negotiating slopes, keep the forward/reverse lever at minimum travel speed.

Braking The forward/reverse lever can be used as an engine brake. Shifting the forward/reverse lever to the neutral position stops the machine.

Operator present system The machine is equipped with an operator present system. The system prevents the machine from moving forward or reverse unless the operator is seated. The operator should remain seated at all times.

7.14 Using the Vibration System

Background The machine has an exciter on each drum. The exciters are driven by gear-type hydraulic motors. The exciter motors are fed by a fixed-displacement, gear-type hydraulic pump.

Starting and stopping vibration


To start vibration, press button **(a)**.

When vibration is active, the vibration ON indicator **(c)** will illuminate.

Press the vibration selector switch **(b)** to choose vibration in either the front drum or both drums.

Vibration can be activated while operating in either forward or reverse, and will remain active until button **(a)** is pressed again.

To stop vibration, press button **(a)** again.



wc_gr010749

Using vibration


- Vibration remains active even when the forward / reverse control is in NEUTRAL.
- To keep the surface finish smooth when operating on asphalt, stop vibration before stopping the engine.
- If vibration is not stopped before the engine is stopped, vibration will resume immediately when the engine is started. Therefore, be ready to stop vibration as soon as the engine cranks.

7.15 Using the Water Spray System

Water spray controls

Water from the tank is fed to the spray nozzles by an electric pump. A water spray switch **(c)** controls the water pump motor. A water spray dial **(d)** controls the water flow.

To operate the water spray controls:




Guidelines when using

When using the water spray system:

- Check that the tank is full of water.
- Use only clean water. Dirty water, even when filtered, can clog the system.
- Keep the water system clean and well maintained. See *Maintenance*.
- If spray does not begin immediately when the system is turned on, it may be necessary to clean the spray bars. See *Maintenance*.

7.16 Using the Backup Alarm

Location The backup alarm (a) is located on the rear of the machine.



wc_gr010273

Operation Start the engine and move the forward-reverse lever to the reverse position. The backup alarm should sound immediately. The backup alarm will continue to sound until the forward-reverse lever is moved to the neutral position or to the forward position.


Note: *If the backup alarm does not sound, make the necessary repairs before using the roller.*

7.17 Using the Parking Brakes—RD 16

Background To aid in holding the machine in a stopped position (parked), there is a mechanical parking brake on each drum drive motor. The mechanical parking brakes are spring-activated and hydraulically released (SAHR) type brakes.

The parking brakes are applied when any of the following conditions exist:

- The engine is not running.
- The engine is running, but the operator leaves the seat.
- The parking brake button is pushed.



wc_gr010751

Engaging and releasing Pushing the button engages **(b)** the parking brakes. The “Brakes On” indicator **(a)** illuminates.

Pulling the button up allows the release of the parking brakes.

Note: All of the following conditions must be met for the parking brakes to release:

- The engine must be running.
- The forward/reverse lever must be in the neutral position.
- The operator must be seated.

Emergency use

NOTICE: Do not use the parking brakes to stop the machine during normal operating conditions. Using the parking brake while the machine is moving may damage the drive motors.


Only use the parking brakes to stop the machine during an emergency condition. For example:

- During failure of the main hydraulic braking system (no braking action when the forward/reverse lever is moved to the neutral position)
- During a runaway condition traveling down a slope

7.18 Using the Manual Parking Brake—RD 12 / 12A

Background To hold the machine in a stopped position (parked), there is a mechanical parking brake on the rear drive motor. The engine will automatically shut off when the operator leaves the seat, but the parking brake must be set manually.

Engaging and releasing To set the parking brake pull the brake lever **(a)** up until the brake pad engages the rear drum. Always set the parking brake before leaving the machine. To release the parking brake, lower the brake lever. The forward/reverse control should be in the NEUTRAL position when the parking brake is released.



wc_gr012266

The parking brake is connected to the brake pads and can be adjusted by turning the knob on the end of the handle. See section *Parking Brake Adjustment*.

Emergency use

NOTICE: Under normal operating conditions, do not use the parking brake when the machine is moving. Using the parking brake while the machine is moving may cause damage to the drive motor.

Only use the parking brake to stop the machine when the machine is moving during an emergency condition. For example:


- During failure of the main hydraulic braking system (no braking action when the forward/reverse control is moved to the neutral position)
- In a runaway condition traveling down a slope.

7.19 Parking Brake Adjustment — RD 12 / 12A

The parking brake is located on the rear drive motor drum support, and is used to prevent the roller from moving when the engine is turned off.

Adjust brake for proper holding force as follows:


1. Unscrew brake lever knob (42) until brake can be applied with moderate force (approx. 30 lbs.).
2. Start roller on level ground and try to travel forward and reverse with brake applied. If roller drives through brake, stop machine, tighten lever knob one turn and repeat process.
3. When machine no longer moves with brake set, stop machine, turn knob one more turn and brake is properly set.



7.20 Avoiding the Danger Zone

Description A “danger zone” is an area near a machine where a person can be seriously injured if struck by, or caught between, moving parts of the machine.

On this machine, the danger zone specifically refers to the area near the articulated joint between the front and rear frames (**a**). The danger zone is identified with safety labels (**b**) on both sides of the front frame.



wc_gr010701

Avoiding injury

Obey the instructions below to avoid injury within the danger zone.

- ▶ Make sure that the safety labels are present and clearly visible on both sides of the articulated joint.
- ▶ Before operating the machine, instruct all personnel in the vicinity to stay away from the machine while it is being operated.
- ▶ While operating the machine, remain aware of people moving in the work area. Be ready to react to these movements if necessary.
- ▶ Lock the articulated joint before servicing the machine. See topic *Locking and Unlocking the Articulated Joint*.


7.21 Adding Ballast to Rear Drum — RD 12 / 12A only

The rear drum can be filled with ballast to provide weight. Add ballast through plug opening (26).

Drum Capacity: 114 liters (30.2 gal.)

Added Weight (water ballast): 113 Kg (250 lbs.)

If water is used as ballast in areas where temperatures are below freezing, add antifreeze or drain drum after use.



wc_gr002961

7.22 Preliminary Checks

Requirements Machine on a flat, level surface

Before starting

Before starting the machine, check the following items:

- Engine coolant level
- Engine oil level
- Hydraulic oil level
- Fuel level
- Condition of oil cooler and radiator cooling fins
- Water level in tank

NOTICE: Top off the lubricating and hydraulic oil levels using products with the grades and specifications shown in the “Lubricants” table found in the *Technical Data* chapter of this Operator’s Manual. When doing so, use clean containers, funnels, etc., to avoid contamination.

Before operating

Before operating the machine:

- Check the machine for fluid leaks. Repair them before operating.
- Unlock the articulated joint.
- Adjust drum scraper position.
- Check the work area for obstructions. Remove all obstructions.
- Check that all handles, steps, and platforms are free of dirt, snow, grease, fuel, or anything else which might endanger operator safety.
- Allow the engine to warm up according to the following schedule:

| Ambient Temperature | Time (min.) |
|---------------------|-------------|
| Above 0°C (32°F) | 5 |
| Below 0°C (32°F) | 15* |

* More time may be required if hydraulic controls are sluggish.

7.23 Starting, Operating, and Stopping the Machine—RD 16

- Requirements**
- Machine is in serviceable condition and has been properly maintained
 - There is fuel in the tank



DANGER

Asphyxiation hazard. Exhaust gases contain carbon monoxide and can kill you in minutes.


- Do not start the engine in an enclosed space.

Starting the machine

Perform the procedure below to start the machine.

1. Sit in the operator's seat and fasten the seat belt.
2. Set the forward/reverse control (a) in the NEUTRAL position.

Note: The roller will not start unless the forward/reverse control is in the NEUTRAL position.



wc_gr012263

3. Press the parking brake button (b) to set the parking brake.
4. Turn the start key (d) to the ON position. The glow plug indicator (f) will illuminate signifying the glow plugs are on. The glow plug indicator will stay on approximately 30 seconds at 0°C (32°F). **Do not** start the engine until the glow plug indicator light goes out.

This procedure continues on the next page.

Continued from the previous page.

5. Turn the start key **(d)** to the START position until the engine starts, then release the key.

NOTICE: Do not crank the engine ignition switch for more than 15 seconds at one time. Longer cranking cycles could lead to starter damage.

6. Allow the engine to warm up for a few minutes before operating the roller.

Operating the machine

Perform the procedure below to operate the roller

1. Pull the parking brake button out to disengage the parking brake.
2. Set the engine throttle to the high position **(c)**. This ensures maximum travel speeds and will produce the best compaction results

NOTICE: Operating the machine at slower engine speeds will reduce compaction, slow down machine functions, and damage hydraulic components.



WARNING

High noise levels. Prolonged exposure can damage your hearing.

- Wear appropriate hearing protection while operating this machine.

3. Move the forward/reverse lever into FORWARD. The forward/reverse lever controls both the direction and speed of the roller. The farther forward the control is moved the faster the machine will travel.

Note: Use the control lever, rather than the throttle, to control the speed of the machine while compacting.


4. Press the vibration button on the forward/reverse lever to start vibration.
5. Press the water spray switch to activate the water spray system.
6. Rotate the water spray dial to select the water flow frequency desired.

This procedure continues on the next page.

Continued from the previous page.

Stopping the machine

1. Maneuver the machine to a flat surface that has a suitable load bearing capacity.
2. Set the forward/reverse control (a) to the NEUTRAL position.



wc_gr012263

3. Turn the vibration off.
4. Set the water spray switch (e) to the OFF position.
5. Set the engine throttle to the low position (c) and allow the engine to cool down.
6. Press the parking brake button (b).

Note: On the RD 16, in addition to pressing the parking brake button, the parking brake is automatically engaged when:

- engine is not running
- engine is running and the operator is not on the seat



WARNING

The vehicle constitutes a hazard or obstacle to traffic when parked.

- Mark the vehicle with signs, lights, and other warnings.

7. Turn the start key to the OFF position.
8. Chock the drums.

7.24 Emergency Shut-down Procedure (RD 16)

If a breakdown/accident occurs while the machine is operating, follow the procedure below.

1. Stop the engine.
2. Allow the engine and exhaust system to cool.
3. Using appropriate equipment, return the machine to an upright position if tipped over.
4. Contact rental yard or machine owner.

7.25 Starting, Operating, and Stopping the Machine—RD 12 / 12A

- Requirements**
- Machine is in serviceable condition and has been properly maintained
 - There is fuel in the tank



DANGER

Asphyxiation hazard. Exhaust gases contain carbon monoxide and can kill you in minutes.


- Do not start the engine in an enclosed space.

Starting the machine

Perform the steps below to start the machine.

1. Sit in the operator's seat and fasten the seat belt.
2. Set the parking brake.
3. Set the forward/reverse control **(a)** in the NEUTRAL position.

Note: The roller will not start unless the forward/reverse control is in the NEUTRAL position.



wc_gr012262

4. If the engine is cold, move the choke lever **(b)** to the left into the CLOSED position. If the engine is warm, move the choke control to the right in the OPEN position.

This procedure continues on the next page.

Continued from the previous page.

5. Set the engine throttle **(c)** to the high position.
6. Turn the start key **(d)** to the start position until the engine starts, then release the key. If the vibration indicator light is on, press the vibration control button. This turns off the vibration.

NOTICE: Do not crank the engine starter for more than 15 seconds at one time. Longer cranking cycles could lead to starter damage.

7. Move the choke lever **(b)** to the OPEN position as the engine warms up.
8. Set the engine throttle to the low position.

Note: Allow the engine to warm up for a few minutes before operating the roller.

Operating the machine

Perform the procedure below to operate the roller

1. Before moving the machine, release the parking brake by lowering the brake lever.
2. Set the engine throttle to the high position. This ensures maximum travel speeds and will produce the best compaction results

NOTICE: Operating the machine at slower engine speeds will reduce compaction, slow down machine functions, and damage hydraulic components.



WARNING

High noise levels. Prolonged exposure can damage your hearing.

- Wear appropriate hearing protection while operating this machine.

3. Move the forward/reverse lever into FORWARD. The forward/reverse lever controls both the direction and speed of the roller. The farther forward the control is moved the faster the machine will travel.

Note: Use the control lever, rather than the throttle, to control the speed of the machine while compacting.

4. Press the vibration button on the forward/reverse lever to start vibration.
5. Press the water spray switch to activate the water spray system.
6. Rotate the water spray dial to select the water flow frequency desired.


Stopping the machine

1. Maneuver the machine to a flat surface with a suitable load bearing capacity.
2. Turn the vibration off.
3. Set the water spray switch **(e)** to the OFF position.

This procedure continues on the next page.

Continued from the previous page.

4. Set the forward/reverse control (a) to the NEUTRAL position.



wc_gr012262

5. Set the engine throttle switch (c) to the low position and allow the engine to cool down.
6. Set the parking brake. To set the parking brake, pull the brake lever up until the brake pad engages the drum. To release the brake, lower the brake lever. Always set the parking brake before leaving the machine.

Note: *The parking brake engages the rear drum only.*



WARNING

The vehicle constitutes a hazard or obstacle to traffic when parked.


- Mark the vehicle with signs, lights, and other warnings.

7. Turn the start key to the OFF position.
8. Chock the drums.

7.26 Emergency Shutdown Procedure (RD 12 / 12A)

If a breakdown/accident occurs while the machine is operating, follow the procedure below.

1. Press the emergency stop switch (a).



wc_gr013149

Activate the emergency stop switch by pushing the button. Pushing the emergency stop switch:

- turns off (opens) the main circuit breaker
- cuts power to the fuel solenoid
- stops the engine

The emergency stop switch will remain activated until the switch is pulled out.

Note: Press the emergency stop switch only in the case of an actual emergency where the machine must be stopped immediately.

2. Engage the parking brake.
3. Allow the machine to cool.
4. Using appropriate equipment, return the machine to an upright position if tipped over.
5. Contact the rental yard or machine owner for further instructions.

7.27 Machine Stability



WARNING

Crushing hazards. Certain job site conditions or operating practices may adversely affect machine stability.

- Follow the instructions below to reduce the risk of tipping or falling incidents.

Surface conditions


Pay attention to changing surface conditions while operating the machine. Adjust speed and travel direction as necessary to maintain safe operation.

- Machine stability and traction may be severely reduced when operating on uneven or rough terrain, rocky soils, or wet or loosely packed surface material.
- The machine may suddenly tip, sink, or fall when moved onto surfaces that have been newly filled with earth.

Steering angle

An articulated roller is more likely to tip when moving off an elevated surface if the machine is turned away from the edge.

- As shown in the illustration on the right, always turn the machine toward the edge when moving off an elevated surface.



wc_gr007042

Travel speed

A fast moving machine is more likely to tip or fall over while making turns or changing direction.

- Reduce travel speed before turning the machine.

Drum overhang

The machine can tip suddenly if more than half of the drum width extends beyond the edge of the elevated surface.

- Reduce travel speed and watch the drum position carefully when operating along the edge of an elevated surface.
- Keep as much of the drum on the elevated surface as possible.

Vibrating on a compacted surface

Activating the vibration system on a fully compacted surface may cause the drums to rebound and momentarily lose contact with the ground. If this occurs while the machine is on an incline, the machine may slide.

- If the drums rebound on the compacted surface, reduce vibration speed or stop vibration entirely.

7.28 Operating on Slopes

Background When operating on slopes or hills, special care must be taken to reduce the risk of personal injury or damage to the machine.


Procedure Always operate the machine up and down slopes rather than from side to side. For safe operation and for protection of the engine, continuous duty use should be restricted to slopes of 19° (35% grade) or less.



WARNING

Crushing hazard. Never operate the machine sideways on slopes. The machine may tip or roll over even on stable ground.

► Operate the machine straight up and down slopes.



wc_gr010757

Surface conditions

Pay attention to changing surface conditions while operating the machine. Adjust speed and travel direction as necessary to maintain safe operation.

- Machine stability and traction may be severely reduced when operating on uneven or rough terrain, rocky soils, or wet or loosely packed surface material.
- The machine may suddenly tip, sink, or fall when moved onto surfaces that have been newly filled with earth.

7.29 Anti-Vandalism Protection and Machine Access

Parts of the machine which may be subject to theft or vandalism when the vehicle is parked unattended can be padlocked to prevent unauthorized access or use.

Lockable parts are:

- Engine cover.
 - a. To lock the engine cover, close the cover.
 - b. Attach a padlock to the fastener.
- Control panel.
 - a. To lock the control panel, place the anti-vandalism cover over the controls.
 - b. Attach a padlock to the fastener.
- Fuel cap.
 - a. To lock the fuel cap, close cap completely.
 - b. Push in the locking tab on the cap.
 - c. Attach a padlock.

Note: *Padlocks are not supplied with the machine.*

Notes

8 General Maintenance

**WARNING**

A poorly maintained machine can malfunction, causing injuries or permanent damage to the machine.

- Keep the machine in safe operating condition by performing periodic maintenance and making repairs as needed.

8.1 Maintaining the Emission Control System

For machines sold in North America:

Normal maintenance, replacement, or repair of emission control devices and systems may be performed by any repair establishment or individual; however, warranty repairs must be performed by a dealer/service center authorized by Wacker Neuson. The use of service parts that are not equivalent in performance and durability to authorized parts may impair the effectiveness of the emission control system and may have a bearing on the outcome of a warranty claim.

8.2 Periodic Maintenance Schedule

The table below lists basic machine and engine maintenance. Tasks designated with check marks may be performed by the operator. Tasks designated with square bullet points require special training and equipment.

Refer to the engine owner's manual for additional information.

| | Daily before starting | Every 100 hours | Every 500 hours | Every 1000 hours |
|---|-----------------------------|-----------------------|-----------------------|------------------------|
| Check external hardware. | ✓ | | | |
| Check water filter. | ✓ | | | |
| Check level of hydraulic oil. | ✓ | | | |
| Check condition of hydraulic hoses and connections. | ✓ | | | |
| Check electrical wiring and connections. | ✓ | | | |
| Check operation of parking brake and make sure it engages. (if equipped) | ✓ | | | |
| Check operation of neutral safety switch. | ✓ | | | |
| Check seat belt. | ✓ | | | |
| Grease articulated joint. | | ■ | | |
| Grease rear drum drive bearings. | | ■ | | |
| Grease exciter bearings. | | ■ | | |
| Clean scraper bars. | | ✓ | | |
| Check battery. | | ■ | | |
| Grease steering cylinder ends. | | ■ | | |
| Clean water filter. | | ✓ | | |
| Change hydraulic system return line filter. ¹ | | | ■ | |
| Clean battery terminals. | | | ■ | |
| Change hydraulic oil. | | | | ■ |

¹ Replace hydraulic system return line filter after first month or 100 hours of operation.

8.3 Rear Frame Access

Overview

The operator's platform is hinged and can be tilted to provide access to the water pump, the water filter, the battery, the hydraulic hoses, and the fuel tank. The platform has lifting cylinders and a prop rod that hold the platform in the open position.



WARNING


Pinching/crushing hazard. The lifting cylinders do not have enough force to lift and hold the platform in the open position when the tank is filled with water.

- Drain the water tank before tilting the platform. See *Water Spray System* for instructions.

Raising the platform

Follow the procedure below to tilt the platform and engage the prop rod.

1. Drain the water tank.
2. Remove the two bolts (a) locking the operator's platform to each side of the rear frame.



wc_gr008213

3. Stand on the left side of the machine, facing the rear.
4. Grasp the steering column handle (b) and push firmly up and rearward to tilt the platform.
5. The prop rod (c) will automatically drop into the detent (d) when the platform reaches its highest position. The platform is now supported.
6. Perform necessary maintenance work.

This procedure continues on the next page.

Continued from the previous page.

Lowering the platform

Follow the procedure below to disengage the prop rod and lower the platform.

1. Stand on the left side of the machine, facing the rear.
2. Grasp the steering column handle and push firmly up and rearward. At the same time, lift the prop rod out of the detent and pull it slightly forward into the guide slot **(e)**.
3. Pull the steering column handle down to lower the platform.
4. Replace the two bolts locking the platform to each side of the rear frame.

8.4 Safety-Related Spare Parts

Overview


This machine is equipped with several features to enhance operator safety. These include the ROPS and the seat belt. For your convenience, we have provided the following diagrams and lists of replacement parts for these safety-related features.

For a complete list of spare parts for this machine, contact your Wacker Neuson dealer or visit www.wackerneuson.com.

ROPS diagram

Use the following diagram and parts list as shown in the table below:

| BOM | Revision | BOM | Revision |
|----------------|-----------------|----------------|-----------------|
| 0620060 | Rev. 100 to 235 | 0620799 | Rev. 100 to 234 |
| 0620402 | Rev. 100 to 233 | 0620127 | Rev. 100 to 237 |
| 0620798 | Rev. 100 to 231 | — | — |



wc_gr007046


ROPS parts
list

| Ref. | Part No. | Qty. | Description | Measurement |
|-------------|----------|------|-----------------------------|-------------|
| 224 | 0163264 | 1 | ROPS frame | — |
| 533 | 0162980 | 2 | Red reflector | — |
| 550 | 0163627 | 1 | Bracket | — |
| 551 | 0163224 | 1 | Mount | — |
| 552 | 0162959 | 1 | Beacon group option | — |
| 594 | 0162345 | 1 | Light bulb | — |
| 595 | 0162341 | 1 | Retaining clip | — |
| 675 | 0020378 | 8 | Hex head screw | — |
| 699 | 0163948 | 2 | Hexagonal flange head screw | — |
| 733 | 0031565 | 8 | Lock washer | — |
| 1090 | 0172013 | 2 | Pivot screw | — |
| 1091 | 0172014 | 2 | Pivot nut | — |
| 1092 | 0172015 | 2 | Washer | — |
| 1093 | 0172016 | 2 | Pin | — |
| 1094 | 0172017 | 2 | Cable | — |
| 1095 | 0172018 | 2 | Shockmount | — |
| 1096 | 0172019 | 2 | Nut | — |
| 1097 | 0172020 | 1 | Label | — |

ROPS
diagram

Use the following diagram and parts list as shown in the table below:

| BOM | Revision | BOM | Revision |
|----------------|---------------------|----------------|---------------------|
| 0620060 | Rev. 236 and higher | 0620799 | Rev. 235 and higher |
| 0620402 | Rev. 234 and higher | 0620127 | Rev. 238 and higher |
| 0620798 | Rev. 232 and higher | — | — |




wc_gr012258

ROPS parts
list

| Ref. | Part No. | Qty. | Description | Measurement |
|--------------|----------|------|-----------------------------|-------------|
| 224 | 0163264 | 1 | ROPS frame | — |
| 533 | 0162980 | 2 | Red reflector | — |
| 550 | 0163627 | 1 | Bracket | — |
| 551 | 0163224 | 1 | Mount | — |
| 552 | 0162959 | 1 | Beacon group option | — |
| 594 | 0162345 | 1 | Light bulb | — |
| 595 | 0162341 | 1 | Retaining clip | — |
| 675 | 0020378 | 8 | Hex head screw | — |
| 699 | 0163948 | 2 | Hexagonal flange head screw | — |
| 733 | 0031565 | 8 | Lock washer | — |
| 680 | 0011303 | 2 | Hex head screw | M12 x 60 |
| 642 | 0010366 | 2 | Lock nut | M12 |
| 723 | 0010620 | 2 | Washer | — |
| 1094 | 0172017 | 2 | Cable | — |
| 1095a | 0016009 | 4 | ROPS pin | — |
| 1095b | 0016010 | 4 | ROPS joint washer | — |
| 1096 | 0172019 | 2 | Nut | — |
| 1097 | 0172020 | 1 | Label | — |
| 1098 | 0162243 | 2 | Control lever | — |

Seat assembly diagram



wc_gr007047

**Seat
assembly
parts list**

| Ref. | Part No. | Qty. | Description | Measurement and torque |
|-----------|----------|------|-------------------------|-------------------------------|
| 1 | 0163274 | 1 | Plate | — |
| 2a | 0163324 | 1 | Adjustable seat | — |
| 2b | 0164779 | 1 | Operator present switch | — |
| 3 | 0110972 | 1 | Seat belt | — |
| 4 | 0083220 | 1 | Holder | — |
| 5 | 0030066 | 4 | Lock nut | M8 34 Nm / 25 ft.lbs |
| 6 | 0013002 | 2 | Hex head screw | M12 x 25 86 Nm / 63 ft.lbs |
| 7 | 0010620 | 2 | Flat washer | B13 |
| 8 | 0010366 | 2 | Lock nut | M12 83 Nm / 61 ft.lbs |
| 9 | 0164846 | 1 | Hardware set | — |

8.5 Maintaining the Seat and Seat Belt


Background In order for the seat and seat belt to operate safely and properly over a long period of time, periodic maintenance and occasional repairs are necessary. Poorly maintained equipment can become a safety hazard!

**Maintaining
the seat and
seat belt**

- Keep the seat clean. Dirt, dust, or harsh chemicals can damage the upholstery. Repair holes or tears immediately.
- If necessary, clean the seat belt with a mild soap solution. Do not use chemical cleaners, as they will damage the fabric.
- Replace the seat belt immediately if it becomes worn or damaged. Otherwise, replace the seat belt every three years.
- Periodically test the operation of the seat tension knob and the front-to-back lever. Repair or replace worn or malfunctioning components.
- If the seat does not move smoothly during adjustment, apply a small amount of standard bearing grease (such as Shell Gadus® S2 V100 or equivalent) to the rails.

8.6 Hydraulic Oil Level

A hydraulic oil level sightglass **(29)** is located on the side of the hydraulic fluid reservoir.



wc_gr005895

While the machine is turned off, check that the hydraulic oil level is visible at the middle level or higher in the sightglass. If it is not, add oil through the filler port **(20)** inside the engine compartment. Use only clean hydraulic oil.

Thoroughly clean the top of the filler cap before removing it from the tank. Care should be taken to prevent small dirt particles from entering the system.

If hydraulic oil continually needs to be added, inspect hoses and connections for possible leaks.

8.7 Checking the Water Filter

When Check the water filter daily before operating the machine. Daily checks are especially important if the available water supply is cloudy or dirty.

Location The water filter is located on the right side of the machine beneath the operator's platform. The operator's platform must be lifted to access the water filter.

Requirements

- Engine stopped
- Water tank drained
- Operator's platform lifted (see *Rear Frame Access*).




WARNING

Pinching/crushing hazard. The lifting cylinders do not have enough force to lift and hold the platform in the open position when the tank is filled with water.

► Drain the water tank before lifting the platform. See *Draining the Water Spray System* for instructions.

Procedure Inspect the water filter (a) according to the checklist below.



wc_gr010551

Clean or replace the water filter if any of the following conditions exist:

- ☐ Cup is missing, damaged, cracked, or chipped
- ☐ Strainer is damaged or missing
- ☐ Hose connections are loose or leaking
- ☐ Cup is filled with sediment or dirt

8.8 Cleaning the Water Filter

When Clean the water filter every 100 hours, or more often if the available water supply is cloudy or dirty.

Location The water filter is located on the right side of the machine beneath the operator's platform. The operator's platform must be lifted to access the water filter.

Requirements

- Engine stopped
- Water tank drained
- Operator's platform lifted (see *Rear Frame Access*).




WARNING

Pinching/crushing hazard. The lifting cylinders do not have enough force to lift and hold the platform in the open position when the tank is filled with water.

► Drain the water tank before lifting the platform. See *Draining the Water Spray System* for instructions.

Cleaning the water filter

Perform the steps below to clean the water filter (a).



wc_gr008414

1. Unscrew the cup (b) and remove the strainer (c).
2. Empty the cup.
3. Rinse the cup and strainer thoroughly with clean water to remove sediment and dirt.
4. Re-install the strainer in the cup, making sure that the strainer is properly seated inside the base of the cup.
5. Re-install the cup and hand-tighten.

Result The water filter is now clean.

8.9 Grease Fittings—RD 16

See chapter *Technical Data* for oil quantity and type.

Articulation Joint Lockarm

The articulated joint is equipped with grease fittings **(a)** for lubrication.



WARNING


To avoid being pinched by the machine halves, set the lockarm before greasing the articulating joint!

Exciter

The exciter is grease lubricated. There are two grease fittings **(c)**, one on each side of the machine, located behind the front and rear drum supports.

Steering Cylinder

The steering cylinder is located under the operator's platform. There is a grease fitting near the base and rod ends of the cylinder **(d)**.



8.10 Grease Fittings—RD 12 / 12A

See section *Technical Data* for oil quantity and type.

Articulation Joint Lockarm

The articulated joint is equipped with grease fittings **(a)** for lubrication.



WARNING

Pinching hazard.

- To avoid being pinched by the machine halves, set the lockarm before greasing the articulating joint!

Rear Drum


The rear drum drive bearing is equipped with a grease fitting **(b)** located at the center of the drum behind the right rear drum support.

Exciter

The exciter is grease lubricated. There are two grease fittings **(c)**, one on each side of the machine, located behind the front drum supports.

Steering Cylinder

The steering cylinder is located under the operator's platform. There is a grease fitting near the base and rod ends of the cylinder **(d)**.



wc_gr012254

8.11 Battery

**WARNING**

Explosion hazard. Batteries can emit explosive hydrogen gas.

- Keep all sparks and flames away from the battery.
- Do not short-circuit battery posts.

**WARNING**

Battery fluid is poisonous and corrosive.

- In the event of ingestion or contact with skin or eyes, seek medical attention immediately.

The battery on this machine is equipped with a terminal that allows temporary disconnection of the battery for maintenance work. See topic “Battery Disconnect” in the *Operation* chapter for more information on using this terminal.

Disconnecting To completely disconnect the battery (for example, when removing it):

1. Stop the machine and shut down the engine.
2. Place all electrical switches in the OFF position.
3. Disconnect the negative battery cable from the battery.
4. Disconnect the positive battery cable from the battery.

Connecting To connect the battery:

1. Connect the positive battery cable to the battery.
2. Connect the negative battery cable to the battery.

Maintaining

- Keep battery terminals clean and connections tight.
- When necessary, tighten the cables and grease the cable clamps with petroleum jelly.
- Maintain the battery at full charge to improve cold weather starting.

Precautions Observe the following precautions to prevent serious damage to the electrical system:

- Do not disconnect the battery while the machine is running.
- Do not attempt to run the machine without a battery.
- Do not attempt to jump-start a machine.
- In the event that the machine has a discharged battery, either replace the battery with a fully charged battery or charge the battery using an appropriate battery charger. Use the auxiliary battery positive terminal for this purpose.

Dispose of discharged batteries in accordance with local environmental regulations.

8.12 Hydraulic System Cleanliness

Keeping the hydraulic oil clean is a vital factor affecting the service life of hydraulic components. Oil in hydraulic systems is used not only to transfer power, but also to lubricate the hydraulic components used in the system. Keeping the hydraulic system clean will help avoid costly downtime and repairs.

Major sources of hydraulic system contamination include:

- Particles of dirt introduced when the hydraulic system is opened for maintenance or repair
- Contaminants generated by the mechanical components of the system during operation
- Improper storage and handling of hydraulic oil
- Use of the wrong type of hydraulic oil
- Leakage in lines and fittings

To minimize hydraulic oil contamination:

- Clean hydraulic connections before opening the lines. When adding oil, clean the hydraulic tank filler cap and surrounding area before removing it.
- Avoid opening the pumps, motors, or hose connections unless absolutely necessary.
- Plug or cap all open hydraulic connections while servicing the system.
- Clean and cover the containers, funnels, and spouts used to store and transfer the hydraulic oil.
- Change the hydraulic filters and oils at the recommended service intervals.

8.13 Hydraulic Oil Requirements

Wacker Neuson recommends the use of a good petroleum-based, anti-wear hydraulic oil in the hydraulic system of this equipment. Good anti-wear hydraulic oils contain special additives to reduce oxidation, prevent foaming, and provide for good water separation.

When selecting hydraulic oil for your machine, be sure to specify anti-wear properties. Most hydraulic oil suppliers will provide assistance in finding the correct hydraulic oil for your machine.

Avoid mixing different brands and grades of hydraulic oils.

Most hydraulic oils are available in different viscosities.

The SAE number for an oil is used strictly to identify viscosity—it **does not** indicate the type of oil (engine, hydraulic, gear, etc.).

When selecting a hydraulic oil be sure it matches the specified SAE viscosity rating and is intended to be used as a hydraulic oil. See section *Technical Data—Lubrication*.


8.14 Checking and Cleaning the Hydraulic Tank Breather

- Prerequisites**
- Machine shut down
 - Clean, nonflammable solvent

When Every 1000 hours of service or yearly

Procedure Follow the procedure below to clean the hydraulic tank breather (a).

1. Open the engine compartment.



wc_gr10523

2. Remove the breather from the hydraulic tank.
3. Clean the breather with clean, nonflammable solvent.
4. Dry the breather with compressed air.
5. Re-install the breather.

8.15 Changing the Hydraulic Oil and Filter

Set all controls in neutral, stop the engine, and allow the engine and fluids to cool before performing this procedure.

All oils eventually shear or thin out with use, reducing their lubricating ability. In addition, heat, oxidation, and contamination may cause the formation of sludge, gum, or varnish in the system. For these reasons, it is important to change the hydraulic oil at specified intervals. See *Maintenance Schedule*.

1. Remove the filler cap/filter cartridge from top of the hydraulic tank.
2. Remove the drain plug on the drain hose and allow the hydraulic fluid to drain.

Note: *In the interests of environmental protection, place plastic sheeting and a container under the machine to collect the liquid which drains off. Dispose of this liquid properly.*

3. Unscrew the return line filter and replace the filter cartridge.
4. Install the drain plug on the drain hose.
5. Fill the hydraulic tank through the filler port with clean hydraulic fluid.
6. Bleed the hydraulic system. See section *Bleeding the Hydraulic System*.

8.16 Bleeding the Hydraulic System

Overview Bleeding trapped air from the hydraulic system is necessary each time the drive system or hydraulic system is opened up. Trapped air bubbles can cause equipment malfunctions or erratic performance.

- Procedure** Follow the procedure below to bleed trapped air from the exciter circuit and the drive circuit.
1. Fill the hydraulic system with clean hydraulic oil until it is visible at the middle level or higher in the sightglass. Do not re-use used hydraulic oil.
 2. Disconnect the wire located on the fuel solenoid.
 3. Crank the engine 5–10 seconds. This will allow the oil to fill the inlet lines.
 4. Reconnect the fuel solenoid wire.
 5. Place forward/reverse control in the NEUTRAL position. Start the engine and run the machine at idle for 3–4 minutes.
 6. To bleed air from the exciter circuit,
 - a. Select Single Drum Vibration mode and turn the vibration on.
 - b. Run the machine for 3–4 minutes.
 - c. Turn the vibration off, and switch to dual drum vibration mode.
 - d. While still at idle, turn vibration on again and run for 3–4 minutes in dual drum vibration mode.
 - e. Turn vibration off, increase engine speed to full, and turn vibration on.
 - f. Verify hydraulic oil level and add oil as needed.
 7. To bleed air from the drive circuit,
 - a. Slowly move the travel control lever back and forth, from forward to reverse, for a short time.
 - b. Switch the engine to high idle for 15–20 seconds. Return the engine to low idle for 1 minute. Repeat this process 2–3 times. to bleed the remaining air from the hydraulic lines.
 - c. Check the hydraulic oil level and add oil as required.

NOTICE: If the drive pump chatters or operation is noisy, turn the machine off and check for air leaks in the inlet line of the charge pump.

8.17 Checking the Neutral Switch

Requirement Parking brake engaged

When Every 10 hours of service or daily

Procedure Follow the procedure below to check the neutral switch.



WARNING

Crush hazard. The machine may lurch forward if the neutral switch is out of adjustment while making this test.

► Be sure the area is clear of all personnel and equipment before making this test.

1. Turn off the engine.
2. Engage the parking brake.
3. Move the forward/reverse lever to the FORWARD position.
4. Hold the engine start switch in the START position.
5. Slowly move the forward/reverse lever toward the NEUTRAL position.
 - If the engine starts before the forward/reverse lever reaches the NEUTRAL position, the neutral switch must be adjusted. Refer to the Repair Manual.
 - If the engine starts only when the forward/reverse lever is in the NEUTRAL position, the neutral switch is OK.


8.18 Inspecting the Seat Belt

- Requirements**
- Machine shut down
 - Parking brake engaged

When Daily, before starting the machine.

Procedure Perform the procedure below to inspect the seat belt.

1. Check the seat belt mounting hardware (**a**) for wear and damage. Replace damaged hardware.



wc_gr004781

2. Check the buckle (**b**) for wear and damage. Replace the seat belt if the buckle is damaged.
3. Inspect the seat belt (**c**) for wear and damage. Replace the seat belt if it is damaged.


Note: Replace the seat belt every three years even if none of the components show visible wear or damage.

8.19 Cleaning the Spray Bars

Background Clogged or dirty spray bars can prevent water from spraying onto the drums. If water spray is noticeably reduced or absent even though there is water in the tank, then clean the spray bars.

Procedure Follow the procedure below to clean the spray bars.

1. Locate the plugs **(a)** at the ends of each spray bar **(b)**. Unscrew and remove the plugs.



wc_gr007077

2. Flush the inside of the spray bar with clean water.
3. Reinstall one of the plugs, and again flush the inside of the spray bar with clean water. Check for free flow of water through each spray hole **(c)**.
4. If any of the spray holes are blocked, use a small pointed object (i.e. a stiff piece of wire) to remove the blockage.
5. Reinstall the second plug when all spray holes are clean.

8.20 Testing the Brake System


Prerequisites 15° slope

When Every 500 hours of service or yearly

Precaution Use this test to determine if the parking brake is functioning on the specified slope. This test is not intended to measure the maximum brake holding effort.

Procedure Follow the procedure below to test the braking system.

1. Position the machine on a 15° slope as shown.



wc_gr010525

2. With the engine running, place the throttle control into the LOW IDLE position and the forward/reverse control lever in the NEUTRAL position.
3. Engage the parking brake. The machine should not move.

If the machine moves, consult Wacker Neuson Service.

8.21 Long-Term Storage

| | |
|------------------------------|--|
| Introduction | Extended storage of equipment requires preventive maintenance. Performing these steps helps to preserve machine components and ensures the machine will be ready for future use. While not all of these steps necessarily apply to this machine, the basic procedures remain the same. |
| When | Prepare your machine for extended storage if it will not be operated for 30 days or more. |
| Preparing for storage | <p>Perform the procedures below to prepare your machine for storage.</p> <ul style="list-style-type: none"> ■ Complete any needed repairs. ■ Replenish or change oils (engine, exciter, hydraulic, and gearcase) per the intervals specified in the Scheduled Maintenance table. ■ Grease all fittings and, if applicable, repack bearings. ■ Inspect engine coolant. Replace coolant if it appears cloudy, is more than two seasons old, or does not meet the average lowest temperature for your area. ■ If your machine has an engine equipped with a fuel valve, start the engine, close the fuel valve, and run the engine until it stops. ■ Consult the engine owner's manual for instructions on preparing the engine for storage. |
| Stabilizing the fuel | <p>After completing the procedures listed above, fill the fuel tank completely and add a high-quality stabilizer to the fuel.</p> <ul style="list-style-type: none"> ■ Choose a stabilizer that includes cleaning agents and additives designed to coat/protect the cylinder walls. ■ Make sure the stabilizer you use is compatible with the fuel in your area, fuel type, grade and temperature range. Do not add extra alcohol to fuels which already contain it (for example, E10). ■ For engines with diesel fuel, use a stabilizer with a biocide to restrict or prevent bacteria and fungus growth. ■ Add the correct amount of stabilizer per the manufacturer's recommendations. |
| Storing the machine | <p>Perform these remaining steps to store your machine.</p> <ul style="list-style-type: none"> ■ Wash the machine and allow it to dry. ■ Move the machine to a clean, dry, secure storage location. Block or chock wheels to prevent machine movement. ■ Use touch-up paint as needed to protect exposed metal against rust. ■ If the machine has a battery, either remove or disconnect it. <p>NOTICE: Allowing the battery to freeze or completely discharge is likely to cause permanent damage. Periodically charge the battery while the machine is not in use. In cold climates, store and charge the battery indoors or in a warm location.</p> <ul style="list-style-type: none"> ■ Cover the machine. Tires and other exposed rubber items should be protected from the weather. Either cover them or use a readily available protectant. |

8.22 Machine Disposal and Decommissioning

- Introduction** This machine must be properly decommissioned at the end of its service life. Responsible disposal of recyclable components, such as plastic and metal, ensures that these materials can be reused—conserving landfill space and valuable natural resources.
- Responsible disposal also prevents toxic chemicals and materials from harming the environment. The operating fluids in this machine, including fuel, engine oil, and grease, may be considered hazardous waste in many areas. Before decommissioning this machine, read and follow local safety and environmental regulations pertaining to the disposal of construction equipment.
-
- Preparation** Perform the following tasks to prepare the machine for disposal.
- ☐ Move the machine to a protected location where it will not pose any safety hazards and cannot be accessed by unauthorized individuals.
 - ☐ Ensure that the machine cannot be operated from the time of final shutdown to disposal.
 - ☐ Drain all fluids, including fuel, engine oil, and coolant.
 - ☐ Seal any fluid leaks.
-
- Disposal** Perform the following tasks to dispose of the machine.
- ☐ Disassemble the machine and separate all parts by material type.
 - ☐ Dispose of recyclable parts as specified by local regulations.
 - ☐ Dispose of all non-hazardous components that cannot be recycled.
 - ☐ Dispose of waste fuel, oil, and grease in accordance with local environmental protection regulations.

9 Engine Maintenance: Kohler (T4f)

The information in this chapter comes from copyrighted Kohler material.

The viscosity of the engine oil is an important factor when determining the correct engine oil to use in your machine. Use an engine oil of appropriate viscosity based on the expected outside air temperature. See the table below.



WARNING

Most used liquids from this machine such as oil, gasoline, grease, etc., contain small amounts of materials that can cause cancer and other health problems if inhaled, ingested, or left in contact with skin for prolonged periods of time.

- ▶ Take steps to avoid inhaling or ingesting used liquids.
 - ▶ Wash skin thoroughly after exposure to used liquids.
-

OIL CLASSIFICATIONS API/MIL - SEQUENZE API/MIL - SEQUENCES API/MIL
API/MIL-SEQUENZEN - SECUENCIAS API/MIL - SEQUÊNCIAS API/MIL

| DIESEL | | | | | | | | | | GASOLINE - BENZINA - ESSENCE BENZIN - GASOLINA | | | | | | | | | | |
|--------|------|------|------|----|----|----|----|----|----|---|----|----|----|----|----|--|--|--|--|--|
| API | CH-4 | CG-4 | CF-4 | CF | CE | CD | CC | SC | SD | SE | SF | SG | SH | SJ | SL | | | | | |
| MIL | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | |

The engine maintenance schedule(s) in this chapter are reproduced from the engine owner's manual. For additional information, see the engine owner's manual.

KOHLER®

ORDINARY MAINTENANCE - MANUTENZIONE ORDINARIA
ENTRETIEN ORDINAIRE - ORDENTLICHE WARTUNG
MANUTENCION ORDINARIA - MANUTENÇÃO NORMAL

CHECK - CONTROLLO - CONTRÔLE - KONTROLLE - COMPROBACION - CONTRÔLE

| OPERATION DESCRIPTION - DESCRIZIONE OPERAZIONE DESCRIPTION DE L'OPERATION - BESCHREIBUNG DES ARBEITSVORGANGS DESCRIPCION DE LA OPERACION - DESCRIÇÃO DA OPERAÇÃO | FREQUENCY x HOURS - PERIODICITA' x ORE FREQUENCE x HEURES - WARTUNGSPERIODEN x STUNDEN PERIODO x HORAS - FREQUÊNCIA x HORAS | | | | | |
|---|---|-----|-----|-----|------|-------|
| | 10 | 250 | 300 | 500 | 1000 | 10000 |
| Oil Level - Livello Olio Motore - Niveau huile Moteur - Ölstanddaten - Nivel Aceite Del Motor - Nivel Óleo do Motor | | | | | | |
| Coolant Level - Livello Liquido di Raffreddamento - Niveau Liquide Réfrigérant - Kühlflüssigkeitsstands - Nivel Liquido para Refrigeración - Nivel Liquido Esfriamento. | | | | | | |
| Radiator Core - Superficie di Scambio Radiatore - Surface d'Échange radiateur - Austauschfläche des Kühlers - Superficie de Intercambio del Radiador - Superficie de Troca do Radiador | | | | | | |
| Panel Air Filter (Dry-Type) - Filtro Aria a Pannello (a Secco) - Filtre à Air à Pannau (à Sec) - Plattenluftfilter (Trocken) - Filtro de Aire de Panel (a Seco) - Filtro de Ar de Painei (a Seco) | (**) | | | | | |
| Remote Air Filter (Dry-Type) - Filtro Aria a Distanza (a Secco) - Filtre à Air à Distance (à Sec) - Luftfilter Mit Abstand (Trocken) - Filtro de Aire Remoto (a. Seco) - Filtro de ar a Distância (a Seco) | (**) | | | | | |
| Fuel Lines - Tubi Carburante - Tuyaux Combustible - Kraftstoffleitungen - Tubos de Combustible - Tubos Combustíveis | | | | | | |
| Fan/Alternator Belt Tension - Tensione Cinghia Ventola/Alternatore - Tension Courroie Ventilateur/Alternateur Keilriemens Lüfter - Tensión Correa Ventilador/Alternador - Tensão Cincha Ventilador/Alternador | (*) | | | | | |

- (***) - Check paper element for dirty, loose, or damaged parts, in accordance with the maintenance schedule. Depending on the environment the engine is used in, clean and replace filter more often, especially in dusty, dirty conditions.
- Il periodo di tempo che deve intercorrere prima di pulire o sostituire l'elemento filtrante è subordinato all'ambiente in cui opera il motore. In condizioni ambientali molto polverose il filtro dell'aria deve essere pulito e sostituito più spesso.
 - Le temps qui doit s'écouler avant de nettoyer ou de remplacer l'élément filtrant dépend des conditions dans lesquelles le moteur tourne. Nettoyer et remplacer plus souvent le filtre à air doit quand le milieu est très poussiéreux.
 - Das Zeitintervall zwischen den Reinigungen oder dem Auswechseln des Filterelements hängt von der Umgebung ab, in der der Motor verwendet wird. In sehr staubiger Umgebung muss der Luftfilter öfter gereinigt und ausgetauscht werden.
 - El intervalo de tiempo que debe transcurrir antes de limpiar o sustituir el elemento filtrante depende del ambiente de funcionamiento del motor. En ambientes muy polvorientos el filtro de aire debe ser limpio y debe sustituirse más a menudo.
 - O período de tempo que há de passar antes de limpar ou substituir o elemento filtrante está subordinado ao ambiente em que o motor trabalha. Em condições ambientais muito poeirentas o filtro do ar deve ser limpo e substituído muitas vezes.

770002

| CHECK - CONTROLLO - CONTRÔLE - KONTROLLE - COMPROBACIÓN - CONTRÔLE | | | | | | | | | |
|---|---|-----|-----|-----|------|------|-------|--|--|
| OPERATION DESCRIPTION - DESCRIZIONE OPERAZIONE DESCRIPTION DE L'OPÉRATION - BESCHREIBUNG DES ARBEITSVORGANGS DESCRIÇÃO DA OPERAÇÃO | FREQUENCY x HOURS - PERIODICITA' x ORE FREQUENCE x HEURES - WARTUNGSPERIODEN x STUNDEN PERIODO x HORAS - FREQUÊNCIA x HORAS | | | | | | | | |
| | 10 | 250 | 300 | 500 | 1000 | 5000 | 10000 | | |
| Cooling Hoses - Manicotti Liquido di Raffreddamento - Manchons de Liquide de Refroidissement - Muffen des Kühlmittels - Manguitos de Liquido de Refrogeración - Casquilhos para Liquido de Arrefecimento | | (*) | | | | | | | |
| Rubber Intake Hose (Air Filter and Intake Manifold) for Engines with Remote Air Filter - Tubo in Gomma Asp. (Filtro Aria Coll. Asp.) Per Mot. Con Filtro Aria a Dist. - Tuyau d'Aspiration en Caoutchouc (Filtre à Air du Collecteur d'Admission) Pour Mot. Avec Système de Filtrage d'Air à Distance - Gummiansaugschlauch (Luftfilter Ansaugkrümmer) Für Mot. Mit Luftfilter Mit Abstand - Tubo de Goma de Dimensión (Filtro de Aire Colector de Admisión) Para Mot. Con Filtro de Aire Remoto - Tubo de Borracha de Aspiração (Filtro ar Colector de Aspiração) Para Mot. com Filtro de ar a Distância | | | | | | | | | |
| Valve Clearance - Registro Gioco Valvole - Réglage Jeu Soupapes - Einstellen des Ventilspiels Ajuste da Tolarância - Registro Juego de Válvulas - Apuramento válvula | | | | | | | | | |
| Injector Cleaning and Adjustment - Taratura e Pulizia Iniettori - Tarage et Nettoyage Injecteur Einspritzdüsen Überprüfen - Ajuste y Limpieza Inyectores - Taradura e Limpeza Injectores | | | | | | | | | |
| Flush Radiator - Pulizia Interna Radiatore - Nettoyage Intérieur du Radiateur - Innenreinigung des Kühlers - Limpeza del Interior del Radiador - Limpeza Interna do Radiador | | | | | | | | | |
| Clean Fuel Tank - Pulizia Serbatoio Combustibile - Nettoyage du Réservoir à Combustible - Reinigung Kraftstofftank - Limpeza Depósito Combustível - Limpeza do Depósito do Combustível | | | | | | | | | |

770003



| REPLACEMENT - SOSTITUZIONE - REMPLACEMENT - AUSWECHSELN - SUSTITUCIÓN - SUBSTITUIÇÃO | | FREQUENCY x HOURS - PERIODICITA' x ORE FREQUENCIA x HEURES - WARTUNGSPERIODEN x STUNDEN PERÍODO x HORAS - FREQUÊNCIA x HORAS | | | | | | |
|--|--|--|-----|-----|-----|------|------|-------|
| OPERATION DESCRIPTION - DESCRIZIONE OPERAZIONE DESCRIPTION DE L'OPERATION - BESCHREIBUNG DES ARBEITSVORGANGS DESCRIPCION DE LA OPERACION - DESCRIÇÃO DA OPERAÇÃO | | 10 | 250 | 300 | 500 | 1000 | 5000 | 10000 |
| Engine Oil (*) - Olio Motore (*) - Huile Moteur (*) - Öldaten (*) - Aceite del Motor (*) - Óleo do Motor (*) | | (*) | | | | | | |
| Oil Filter - Filtro Olio - Filtre a Huile - Öl Filter - Filtro Aceite - Filtro Óleo | | (*) | | | | | | |
| Fuel Filter - Filtro Combustibile - Filtre a Combustible - Brennstofffilter - Filtro Combustível | | (*) | | | | | | |
| Alternator Belt - Cinghia Alternatore - Courroie Alternateur - Drehstromgenerator Riemen - Correa Alternador - Cincha Alternador | | (**) | | | | | | |
| Coolant - Liquido di Raffreddamento - Liquide Refrigerant - Kühlfüssigkeit - Liquido de Refrigeración - Líquido Esfriamento | | (**) | | | | | | |
| Fuel Lines - Tubi Carburante - Tuyaux Combustible - Kraftstoffleitungen - Tubos de Combustible - Tubos Combustíveis | | (**) | | | | | | |
| Rubber Intake Hose (Air Filter and Intake Manifold) - Tubo in Gomma Asp. (Filtro Aria Coll. Asp.) - Tuyau d'aspir. en Caoutchouc (Filtre à Air du Coll. d'Admiss.) - Gummiansaugschlauch (Luftfilter Ansaugkrümmer) - Tubo de Goma de Admis. (Filtro de Aire Col. De Admis.) - Tubo de Borracha de Aspir. (Filtro ar Col. de Aspir.) | | (**) | | | | | | |
| Coolant Hoses - Manicotti Liquido di Raffredd. - Manchons de Liquide de Refroid. - Muffen des Kühlmittels - Manguitos de Líquido de Refrig. - Casquilhos para Líquido de Arrefecimento | | (**) | | | | | | |
| Timing Belt - Cinghia Distribuzione - Courroie de Distribution - Verteilerriemen Correa de Distribución - Correia de Distribuição | | (***) | | | | | | |
| Dry Air Cleaner, External Cartridge - Cartuccia Esterna Filtro Aria a Secco - Cartouche Extérieure Filtre a Air Desséchée - Ausserer Trockenluftfiltereinsatz - Cartucho Externo del Filtro de Aire Seco - Cartucho Externo Filtro ar A Seco | | (****) | | | | | | |
| Filter Element, Panel Air Filter - Massa Filtrante Filtro Aria a Pannello - Masse Filtrante de Filtre à Air à Panneau Filterelement Plattenluftfilter - Masa Filtrante del Filtro de Aire de Panel - Massa Filtrante do Filtro de ar de | | | | | | | | |

- (°) - If you are using oil of a quality lower than the prescribed one then you will have to replace it every 125 hours for the standard sump and every 150 hours for the enhanced sump.
- Se si utilizza olio di qualità inferiore a quello prescritto sostituirlo ogni 125 ore per la coppa standard e 150 ore per la coppa maggiorata.
 - Si l'huile utilisée est de qualité inférieure à celle indiquée, la vindanger toutes les 125 heures s'il s'agit d'un carter standard et toutes les 150 heures s'il s'agit d'un carter surdimensionné.
 - Wenn Öl einer niedrigeren Qualität als vorgeschrieben verwendet wird, sollte es bei Standardölwannen alle 125 Betriebsstunden, bei vergrößerten Ölwannen alle 150 Stunden gewechselt werden.
 - Si se utiliza un aceite de calidad inferior al que recomendado deberá sustituirse cada 125 horas en caso de cárter estándar o cada 150 en caso de cárter sobredimensionado.
 - Se utilizar óleo de qualidade inferior à queles prescrito, substitua-o a cada 125 horas para o cárter padrao e 150 para o cárter aumentado.

770004

Engine Maintenance—Wacker Neuson/Robin

10 Engine Maintenance—Wacker Neuson/Robin

The viscosity of the engine oil is an important factor when determining the correct engine oil to use in your machine. Use an engine oil of appropriate viscosity based on the expected outside air temperature. See the table below.



WARNING

Most used liquids from this machine such as oil, gasoline, grease, etc., contain small amounts of materials that can cause cancer and other health problems if inhaled, ingested, or left in contact with skin for prolonged periods of time.

- Take steps to avoid inhaling or ingesting used liquids.
- Wash skin thoroughly after exposure to used liquids.

| | | | | | | | |
|---------------------|--------|-----|-----|-----|----|----|-------|
| Single grade | 5W | | | | | | |
| | 10W | | | | | | |
| | | 20W | | | | | |
| | | #20 | | | | | |
| | | | #30 | | | | |
| | | | | #40 | | | |
| Multi grade | 10W-30 | | | | | | |
| | 10W-40 | | | | | | |
| Ambient temperature | -20 | -10 | 0 | 10 | 20 | 30 | 40°C |
| | -4 | 14 | 32 | 50 | 68 | 86 | 104°F |

- Use 4-stroke automotive detergent oil of API service class SE or higher grade (SG, SH or SJ is recommended).

- If multi-grade oil is used, oil consumption tends to increase when the ambient temperature is high.

770042



**WACKER
NEUSON**

Engine Maintenance—Wacker Neuson/Robin

The engine maintenance schedule(s) in this chapter are reproduced from the engine owner's manual. For additional information, see the engine owner's manual.

Periodic Maintenance Schedule table

| Maintenance Items | Every 8 hours (Daily) | Every 50 hours | Every 200 hours | Every 500 hours | Every 1000 hours |
|--|------------------------------------|---------------------|-----------------|-----------------|----------------------|
| Clean engine and check bolts and nuts | ● (Daily) | | | | |
| Check for leakage from hoses and fitting | ● (Daily) | | | | |
| Check and refill engine oil | ● (Refill daily up to upper level) | | | | |
| Change engine oil (*Note : 1) | ● (Initial 20 hours) | ● (Every 100 hours) | | | |
| Replace engine oil filter (*Note 1) | ● (Initial 20 hours) | | ● | | |
| Check battery electrolyte fluid level | | ● | | | |
| Clean spark plug | | ● | | | |
| Clean air cleaner | | ● | | | |
| Spark arrester (Optional part) | | ● (Every 100 hours) | | | |
| Replace air cleaner element | | | ● | | |
| Clean fuel strainer | | | ● | | |
| Clean and adjust spark plug and electrodes | | | ● | | |
| Replace spark plug | | | | ● | |
| Remove carbon from cylinder head | | | | ● | |
| Clean carburetor | | | | ● | |
| Clean engine base (oil pan) | | | | ● | |
| Check and adjust valve clearance | | | | ● | |
| Replace fuel lines | | | | | ● (Every 2 years) |
| Overhaul engine (*Note : 2) | | | | | ● |

*Note : 1. Initial oil change and oil filter replacement should be performed after 20 hours of operation. Thereafter change oil every hundred (100) hours and replace oil filter 200 hours. Before changing oil, check for a suitable way to dispose of old oil. Do not pour it down into sewage drains, onto garden soil or into open streams. Your local zoning or environmental regulations will give you more detailed instructions on proper disposal.

*Note : 2. As to the procedures, please refer to the Service Manual or consult your nearest ROBIN service dealer.

*Note : 3. More frequent oil changing, oil filter replacement and air cleaner service on replacement may be necessary depending on operating conditions. This would include dusty environment, high ambient temperature, heavy engine loading.

770043

11 Engine Maintenance—Honda GX630

The viscosity of the engine oil is an important factor when determining the correct engine oil to use in your machine. Use an engine oil of appropriate viscosity based on the expected outside air temperature. See the table below.




WARNING

Most used liquids from this machine such as oil, gasoline, grease, etc., contain small amounts of materials that can cause cancer and other health problems if inhaled, ingested, or left in contact with skin for prolonged periods of time.

- Take steps to avoid inhaling or ingesting used liquids.
- Wash skin thoroughly after exposure to used liquids.

Recommended Oil

Use 4-stroke motor oil that meets or exceeds the requirements for API service category SJ or later (or equivalent). Always check the API service label on the oil container to be sure it includes the letters SJ or later (or equivalent).



SAE 10W-30 or 5W-30 is recommended for general use. Use a full synthetic 5W-30 for starting/operating temperatures between 5°F (—15°C) and —13°F (—25°C). Other viscosities shown in the chart may be used when the average temperature in your area is within the indicated range.

770044

Engine Maintenance—Honda GX630

The engine maintenance schedule(s) in this chapter are reproduced from the engine owner's manual. For additional information, see the engine owner's manual.

MAINTENANCE SCHEDULE

| REGULAR SERVICE PERIOD (3) Perform at every indicated month or operating hour interval, whichever comes first. | | Each use | First month or 10 hrs | Every 6 months or 50 hrs | Every year or 100 hrs | Every 2 years or 300 hrs | Refer to Page |
|---|--------------|----------|--|--------------------------|-----------------------|--------------------------|---------------|
| ITEM | | | | | | | |
| Engine oil | Check level | ○ | | | | | 8 |
| | Change | | ○ | ○ | | | 8 |
| Engine oil filter | Replace | | Every 200 Hrs. | | | | 9 |
| Air cleaner | Check | ○ | | | | | 9 |
| | Clean | | | ○ (1) | | | 9 |
| | Replace | | | | | ○ * | |
| Spark plug | Check-adjust | | | ○ | | | 10 |
| | Replace | | | | ○ | | |
| Spark arrester (Applicable types) | Clean | | | ○ (4) | | | 11 |
| Idle speed | Check-adjust | | | | ○ (2) | | * * |
| Valve clearance | Check-adjust | | | | ○ (2) | | * * |
| Combustion chamber | Clean | | After every 1000 Hrs. (2) | | | | * * |
| Fuel filter | Replace | | | | ○ (2) | | * * |
| Fuel tube | Check | | Every 2 years (Replace if necessary) (2) | | | | * * |

* Replace the paper filter element only.

* Refer to the Shop Manual.

(1) Service more frequently when used in dusty areas.

(2) These items should be serviced by your Honda servicing dealer, unless you have the proper tools and are mechanically proficient. Refer to Honda shop manual for service procedures.

(3) For commercial use, log hours of operation to determine proper maintenance intervals.

Failure to follow this maintenance schedule could result in non-warrantable failures.

770045

12 Troubleshooting

| Problem / Symptom | Reason | Remedy |
|------------------------|---|--|
| Engine does not start | Fuel tank is empty | Refill fuel tank. |
| | Wrong type of fuel | Drain tank, change fuel filter, and refill with the proper fuel. |
| | Old fuel | Drain tank, change fuel filter, and refill with fresh fuel. |
| | Fuel system not primed | Prime the fuel system. |
| | Fuel filter is restricted or clogged | Replace fuel filter. |
| | Battery connections are loose or corroded, or battery is dead | Check battery connections or replace battery as needed. |
| | Plugged air cleaner or filter elements | Clean air cleaner or replace filter elements. |
| | Defective starter motor | Repair or replace. |
| | Inoperative fuel solenoids on engine | Repair or replace. |
| | Inoperative starter relay | Repair or replace. |
| | Loose or broken electrical connections | Check connections and tighten or repair as needed. |
| Engine stops by itself | Fuel tank is empty | Refill fuel tank. |
| | Fuel filter is restricted or clogged | Clean or replace. |
| | Loose or broken fuel lines | Check connections and tighten or repair as needed. |
| No vibration | Defective vibration switch or poor connection | Check components and tighten or repair as needed. |
| | Damaged or disconnected solenoid on vibration valve | Reconnect or repair solenoid. |
| | Damaged exciter assembly | Repair the assembly. |
| | Damaged or broken exciter motor coupling | Repair or replace. |
| | Damaged exciter motor | Repair or replace. |
| | Damaged exciter pump | Repair or replace. |
| | Damaged exciter bearings | Repair or replace. |

| Problem / Symptom | Reason | Remedy |
|---|--|--|
| No travel, or travel only in one direction | Parking brake is on | Release parking brake. |
| | Sheared pin on forward/reverse control | Replace pin. |
| | Loose or broken control cable | Tighten or replace. |
| | Damaged drive motor | Repair or replace. |
| | Damaged drive pump | Repair or replace. |
| | Defective relief valve(s) | Repair or replace. |
| No steering | Damaged steering cylinder | Repair or replace. |
| | Damaged steering unit | Repair or replace. |
| | Stuck or damaged steering relief valve | Repair or replace. |
| | Articulating joint pin is in the LOCKED position. | Set the articulating joint pin to the UNLOCKED position. |
| Water leaking from spray nozzles when machine is shut off | One or both of the diaphragm valves is not completely closed | Close the diaphragm valve(s) completely. |
| | The diaphragm is worn | Replace the diaphragm. |

13 Technical Data—RD 16
13.1 Engine

| Item no. | | RD 16 / RD 16 IRH |
|---|------------------------------------|--|
| Engine | | |
| Engine type | | 3-cylinder, 4-cycle, liquid-cooled, diesel engine |
| Engine make | | Kohler |
| Engine model | | KDW 1003 |
| Max. rated power @ rated speed ¹ | kW (hp) | 16.8 (22.5) @ 2,850 rpm |
| Displacement | cm ³ (in ³) | 1,028 (62.7) |
| Engine speed - operating | rpm | 2,850 |
| Engine speed - idle | rpm | 1,300 |
| Valve clearance (cold) intake: exhaust: | mm (in.) | 0.15 (0.006) 0.20 (0.008) |
| Battery | V | 12V DC |
| Air cleaner | type | Dry pleated paper elements |
| Fuel | type | Diesel Low sulfur fuel or ultra low sulfur fuel only |
| Fuel tank capacity | L (gal) | 23 (6.1) |
| Fuel consumption | L (gal)/hr | 3.6 (0.96) |
| Engine oil | type L (qt) | SAE 15W40 Class CF rated 2.4 (2.5) |
| Coolant capacity | L (gal) | 4.75 (1.25) |

¹Net power rating per ISO 3046/1-IFN. Actual power output may vary due to conditions of specific use.



13.2 Roller

| Item No. | | RD 16/16 IRH |
|----------------------------------|--------------|--------------------------|
| Roller | | |
| Dry Weight | kg (lb) | 1,356 (2,990) |
| Curb Clearance: Right Left | mm (in.) | 400 (15.7) 400 (15.7) |
| Water Tank Capacity | L (gal) | 100 (26.4) |
| Outside Turning Radius | m (ft) | 2.87 (9.4) |
| Forward / Reverse Speed | kph (mph) | 0-9.3 (0-5.8) |
| Gradeability | | 30% |
| Vibration Frequency | vpm | 4,200 |

13.3 Lubrication

| Item No. | | RD 16 / RD 16 IRH |
|--------------------------|-----------------|--|
| Lubrication | | |
| Engine Lubrication | type L (pt) | SAE 15W40 Class SJ rated 2.4 (2.5) |
| Hydraulic System | type L (gal) | Premium grade, anti-wear hydraulic fluid 10W30 21.6 (5.7) |
| Exciter | type | Mobil SHC 220 grease |
| Rear Drum Drive Bearing | type | Sealed Bearings—No lubrication required |
| Front Drum Drive Bearing | type | |
| Articulated Joint | type qty. | Mobil SHC 220 grease as required |

13.4 Hydraulic Pressures

| System | Operating Pressure | | Relief Pressure | |
|---|--------------------|-------------|-----------------|---------|
| | bar | psi | bar | psi |
| Drive** | 55–76 | 800–1,100 | 300 | 4,350 |
| Steering* —normal —while turning | 41–55 | 600–800 | 45–51 | 650–725 |
| | 90–103 | 1,300–1,500 | | |
| Vibration —single drum —dual drum | 103–131 | 1,500–1,900 | 290 | 4,200 |
| | 138–165 | 2,000–2,400 | | |

* Values for hard-packed surfaces. Values may differ depending on surface.

** Charge pressure: 29.3 – 30.7 bar (425–445 psi).

13.5 Sound Measurements

Products are tested for sound pressure level in accordance with EN 500-4:2011.

Sound power level is tested in accordance with European Directive 2000/14/EC - Noise Emission in the Environment by Equipment for use outdoors.

| Machine | Sound Pressure at Operator's Location dB(A) | Guaranteed Sound Power dB(A) |
|---------|---|------------------------------|
| RD 16 | 88 | 106 |

13.6 Measurements of Operator Exposure to Vibration

The operator of this machine should expect to be exposed to vibration levels listed below when using the machine in performance of its normally intended function:

Maximum hand/arm vibration levels are:

- 2.2 m/s^2 (7.2 ft/s^2)

These are the representative values of the weighted root mean square (**rms**) acceleration to which the hands and arms are subjected. These weighted **rms** values are measured according to ISO 5349-1.

Whole body vibration levels do not exceed:

- 0.3 m/s^2 (1 ft/s^2)

These are the representative values of the weighted root mean square (**rms**) acceleration to which the whole body is subjected. These weighted **rms** values are measured according to ISO 2631-1.





The results are compliant to the limit and action vibration values (hand/arm and whole body) as specified in European directive 2002/44/EC.

HAV Uncertainties

Hand-transmitted vibration was measured per ISO 5349-1. This measurement includes an uncertainty of 1.5 m/s^2 .

13.7 Dimensions

mm (in.)



wc_gr005906

14 Technical Data—RD12

14.1 Engine

| Item no. | | RD 12 | |
|---|----------------|----------------------------------|-----------------------------------|
| Engine | | | |
| Engine type | | 4-stroke, 2-cylinder, air cooled | 4-stroke, 2-cylinder, air cooled |
| Engine make | | Wacker Neuson | Subaru Robin |
| Engine model | | WM 650 | EH640 |
| Spec number | | EH650DB4210 | EH650DB4221 |
| Max. rated power @ rated speed ¹ | kW (hp) | 15.3 (20.5) @ 3,600 rpm | 15.3 (20.5) @ 3,600 rpm |
| Displacement | cm³ (in.³) | 653 (39.9) | 653 (39.9) |
| Spark plug | | NGK-BP6ES | NGK-BPR4ES |
| Electrode gap | mm (in.) | 0.6-0.7 (0.024-0.0276) | 0.7-0.8 (0.0276-0.0315) |
| Engine speed - operating | rpm | 3,100 | 3,100 |
| Engine speed - idle | rpm | 2,000 | 2,200 |
| Valve clearance (cold) intake: | mm (in.) | 0.08-0.115 (0.0031-0.0045) | 0.1 ± 0.02 (0.0039 ± 0.0008) |
| exhaust: | | 0.08-0.115 (0.0031-0.0045) | 0.1 ± 0.02 (0.0039 ± 0.0008) |
| Battery | V | 12VDC | 12VDC |
| Air cleaner | type | Dual element | Dual element |
| Fuel | type | Regular unleaded gasoline | Regular unleaded gasoline |
| Fuel tank capacity | L (gal) | 23 (6.1) | 23 (6.1) |
| Fuel consumption | L (gal)/hr | 6.0 (1.35) | 6.0 (1.35) |
| Engine oil | type L (qt) | 10W30 SG, SF/CC, CD 1.2 (1.3) | 10W30 SG, SF/CC, CD 1.55 (1.6) |
| Coolant capacity | L (gal) | — | — |

¹Gross power rating per SAE J1995. Actual power output may vary due to conditions of specific use.

14.2 Roller

| Item No. | | RD 12 |
|----------------------------------|-----------------|-------------------------|
| Roller | | |
| Dry Weight | kg (lb.) | 1,002 (2,171) |
| Curb Clearance: Right Left | mm (in.) | 400 (15.7) 208 (8.2) |
| Water Tank Capacity | l (gal.) | 100 (26.4) |
| Outside Turning Radius | m (ft.) | 2.44 (8.0) |
| Forward / Reverse Speed | km/hr. (mph) | 0-8.7 (0-5.4) |
| Gradeability | | 30% |
| Vibration Frequency | vpm | 4,200 |

14.3 Lubrication

| Item No. | | RD 12 |
|--------------------------|------------------|---|
| Lubrication | | |
| Engine Lubrication | type L (qt) | SAE 10W30 Class SG, SF, or SE rated 1.2 (1.3) |
| Hydraulic System | type L (gal.) | Premium grade, anti-wear hydraulic fluid 10W30 20.8 (5.5) |
| Exciter | type | Mobil SHC 220 grease |
| Rear Drum Drive Bearing | type qty. | Mobil SHC 220 grease as required |
| Front Drum Drive Bearing | type | Sealed Bearings — No lubrication required |
| Articulated Joint | type qty. | Mobil SHC 220 grease as required |

14.4 Hydraulic Pressures

| System | Operating Pressure | | Relief Pressure | |
|-----------------------------|--------------------|-----------|-----------------|---------|
| | bar | psi | bar | psi |
| Drive** | 55–69 | 800–1,000 | 200 | 2,900 |
| Steering* —while turning | 0–41 | 0–725 | 45–51 | 650–725 |
| Vibration —single drum | 55–76 | 800–1,100 | 200 | 2,900 |

* Values for hard-packed surface shown. Values may differ depending on surface.

** Charge pressure: 11.4 – 12.8 bar (165–185 psi).

14.5 Sound Measurements

The operating sound level, measured per the requirements of Appendix 1, Paragraph 1.7.4.f of the EC-Machine Regulations, is:

the guaranteed sound power level (L_{WA}):

- RD 12 = 102 dB(A)

the sound pressure level at operator's location (L_{pA}):

- RD 12 = 85.6 dB(A)

This sound value was determined according to ISO 3744 for the sound power level (L_{WA}).

14.6 Measurements of Operator Exposure to Vibration

The operator of this machine should expect to be exposed to vibration levels listed below when using the machine in performance of its normally intended function:

Maximum hand/arm vibration levels are:

- RD 12 = 1.4 m/s² (4.6 ft/s²)

These are the representative values of the weighted root mean square (**rms**) acceleration to which the hands and arms are subjected. These weighted **rms** values are measured according to ISO 5349-1.

Whole body vibration levels do not exceed:


- RD 12 = 0.22 m/s² (0.7 ft/s²)

These are the representative values of the weighted root mean square (**rms**) acceleration to which the whole body is subjected. These weighted **rms** values are measured according to ISO 2631-1.

The results are compliant to the limit and action vibration values (hand/arm and whole body) as specified in European directive 2002/44/EC.

14.7 Dimensions

mm (in.)



wc_gr005905

15 Technical Data—RD 12A

15.1 Engine

| Item no. | | RD 12A |
|---|------------------------------------|--|
| Engine | | |
| Engine type | | 4-stroke, 2 cylinder, air cooled |
| Engine make | | Honda |
| Engine model | | GX 630 |
| Max. rated power @ rated speed ¹ | kW (hp) | 15.1 (20.3) @ 3,600 rpm |
| Displacement | cm ³ (in ³) | 688 (42) |
| Spark plug | | (NGK) ZFR5F |
| Electrode gap | mm (in.) | 0.71-0.79 (0.028-0.031) |
| Engine speed - operating | rpm | 3,100 |
| Valve clearance (cold) intake: exhaust: | mm (in.) | 0.10-0.16 (0.004-0.006) 0.10-0.16 (0.004-0.006) |
| Battery | | U1 12VDC 30AH 350A |
| Air cleaner | type | Dual element |
| Fuel | type | Regular unleaded gasoline |
| Fuel tank capacity | L (gal) | 23 (6.1) |
| Fuel consumption | L (gal)/hr | Up to 6.0 (1.59) |
| Engine oil | type L (qt) | 10W30 SJ or higher 1.9 (2.0) |

¹Net power rating per SAE J1349. Actual power output may vary due to conditions of specific use.

15.2 Roller

| Item No. | | RD 12A |
|----------------------------------|-----------------|-------------------------|
| Roller | | |
| Dry Weight | kg (lb.) | 985 (2,171) |
| Curb Clearance: Right Left | mm (in.) | 399 (15.7) 208 (8.2) |
| Water Tank Capacity | l (gal.) | 100 (26.4) |
| Outside Turning Radius | m (ft.) | 2.45 (8.0) |
| Forward / Reverse Speed | km/hr. (mph) | 0-8.7 (0-5.4) |
| Gradeability | | 30% |
| Vibration Frequency | vpm | 4,200 |

15.3 Lubrication

| Item No. | | RD 12A |
|--------------------------|----------------------|---|
| Lubrication | | |
| Hydraulic System | type L (gal.) | Premium grade, anti-wear hydraulic fluid 10W30 20.8 (5.5) |
| Exciter | type | Mobil SHC 220 grease |
| Rear Drum Drive Bearing | type qty. | Mobil SHC 220 grease as required |
| Front Drum Drive Bearing | type | Sealed Bearings — No lubrication required |
| Articulated Joint | type qty. | Mobil SHC 220 grease as required |

15.4 Hydraulic Pressures

| System | Operating Pressure | | Relief Pressure | |
|-----------------------------|--------------------|-----------|-----------------|---------|
| | bar | psi | bar | psi |
| Drive** | 55–69 | 800–1,000 | 200 | 2,900 |
| Steering* —while turning | 0–41 | 0–725 | 45–51 | 650–725 |
| Vibration —single drum | 55–76 | 800–1,100 | 200 | 2,900 |

* Values for hard-packed surface shown. Values may differ depending on surface.

** Charge pressure: 11.4 – 12.8 bar (165–185 psi).

15.5 Sound Measurements

The operating sound level, measured per the requirements of Appendix 1, Paragraph 1.7.4.f of the EC-Machine Regulations, is:

the guaranteed sound power level (L_{WA}):

- RD 12 = 102 dB(A)

the sound pressure level at operator's location (L_{pA}):

- RD 12 = 85.6 dB(A)

This sound value was determined according to ISO 3744 for the sound power level (L_{WA}).

15.6 Measurements of Operator Exposure to Vibration

The operator of this machine should expect to be exposed to vibration levels listed below when using the machine in performance of its normally intended function:

Maximum hand/arm vibration levels are:

- 1.4 m/s^2 (4.6 ft/s^2)

These are the representative values of the weighted root mean square (**rms**) acceleration to which the hands and arms are subjected. These weighted **rms** values are measured according to ISO 5349-1.

Whole body vibration levels do not exceed:


- 0.22 m/s^2 (0.7 ft/s^2)

These are the representative values of the weighted root mean square (**rms**) acceleration to which the whole body is subjected. These weighted **rms** values are measured according to ISO 2631-1.

The results are compliant to the limit and action vibration values (hand/arm and whole body) as specified in European directive 2002/44/EC.

15.7 Dimensions

mm (in.)



wc_gr005905

16 Emission Control Systems Information and Warranty—Gasoline

The Emission Control Warranty and associated information is valid only for the U.S.A., its territories, and Canada.

16.1 Emission Control System Background Information

Introduction

Wacker Neuson spark-ignited engines/equipment must conform with applicable Environmental Protection Agency (EPA) and the State of California emissions regulations. There are two types of emissions that fall under these regulations: 1) exhaust, and 2) evaporative. These regulations require that manufacturers warrant the emission control systems for defects in materials and workmanship.

Furthermore, EPA and California regulations require all manufacturers to furnish written instructions describing how to operate and maintain the engines/equipment including the emission control systems. This information is provided with all Wacker Neuson engines/equipment at the time of purchase.

Exhaust Emissions

The combustion process produces carbon monoxide, oxides of nitrogen, and hydrocarbons. Control of hydrocarbons and oxides of nitrogen is very important because, under certain conditions, they react to form photochemical smog when subjected to sunlight. Carbon monoxide does not react in the same way, but it is toxic.

Wacker Neuson utilizes lean carburetor settings and other systems to reduce the emissions of carbon monoxide, oxides of nitrogen, and hydrocarbons.

Evaporative Emissions

Evaporative emissions are fuel emissions and generally include emissions that result from permeation of fuel through the fuel-system materials or from ventilation of the fuel system.

Wacker Neuson utilizes low-permeation fuel lines and fuel tanks where applicable to reduce evaporative emissions.

Problems that may affect Emissions

If any of the following symptoms arise, have the engine/equipment inspected and repaired by a Wacker Neuson dealer/service center.

- Hard starting or stalling after starting
- Rough idling
- Misfiring or backfiring under load
- Afterburning (backfiring)
- Presence of black exhaust smoke during operation
- High fuel consumption

Tampering and Altering

Tampering with or altering the emission control system may increase emissions beyond the legal limit. If evidence of tampering is found, Wacker Neuson may deny a warranty claim. Among those acts that constitute tampering are:

- Removing or altering of any part of the air intake, fuel, or exhaust systems.
- Altering or defeating the speed-adjusting mechanism causing the engine to operate outside its design parameters.

16.2 Limited Defect Warranty for Exhaust Emission Control System

See the supplied engine owner's manual for the applicable emission warranty statement.

16.3 Limited Defect Warranty for Wacker Neuson Evaporative Emission Control Systems

The Emission Control Warranty is valid only for the U.S.A., its territories, and Canada.

Wacker Neuson Sales Americas, LLC, N92 W15000 Anthony Avenue, Menomonee Falls, WI 53051, (hereinafter "Wacker Neuson") warrants to the initial retail purchaser and each subsequent owner, that this engine/equipment, including all parts of its evaporative emission control system, have been designed, built, and equipped to conform at the time of initial sale to all applicable evaporative emission regulations of the U.S. Environmental Protection Agency (EPA), and that the engine/equipment is free of defects in materials and workmanship which would cause this engine/equipment to fail to conform to EPA regulations during its warranty period.

Wacker Neuson is also liable for damages to other engine/equipment components caused by a failure of any warranted parts during the warranty period.

Limited Defect Warranty Period for Wacker Neuson Evaporative Emission Control Systems

The warranty period for this engine/equipment begins on the date of sale to the initial purchaser and continues for a minimum of two (2) years. For the warranty terms for your specific engine/equipment, visit wackerneuson.com.

Any implied warranties are limited to the duration of this written warranty.

What is covered

Wacker Neuson recommends the use of genuine Wacker Neuson parts, or the equivalent, whenever maintenance is performed. The use of replacement parts not equivalent to the original parts may impair the effectiveness of the engine/equipment emission controls systems. If such a replacement part is used in the repair or maintenance of the engine/equipment, assure yourself that such part is warranted by its manufacturer to be equivalent to the parts offered by Wacker

Emission Control Systems Information and Warranty—Gasoline

Neuson in performance and durability. Furthermore, if such a replacement part is used in the repair or maintenance of the engine/equipment, and an authorized Wacker Neuson dealer/service center determines it is defective or causes a failure of a warranted part, the claim for repair of the engine/equipment may be denied. If the part in question is not related to the reason the engine/equipment requires repair, the claim will not be denied.

For the components listed in the following table, an authorized Wacker Neuson dealer/service center will, at no cost to you, make the necessary diagnosis, repair, or replacement necessary to ensure that the engine/equipment complies with the applicable EPA regulations. All defective parts replaced under this warranty become property of Wacker Neuson.

| System Covered | Components |
|---|--------------------------------------|
| Evaporative emissions | Fuel tank (if applicable) |
| | Fuel tank cap (if applicable) |
| | Fuel line (if applicable) |
| | Fuel line fittings (if applicable) |
| | Clamps (if applicable) |
| | Carbon canister (if applicable) |
| | Purge port connector (if applicable) |
| Miscellaneous parts associated with the evaporative emission control system | Clamps |
| | Gaskets |
| | Mounting brackets |

What is not covered

- Failures other than those resulting from defects in material or workmanship.
- Any systems or parts which are affected or damaged by owner abuse, tampering, neglect, improper maintenance, misuse, improper fueling, improper storage, accident and/or collision; the incorporation of, or any use of, add-on or modified parts, or unsuitable attachments, or the alteration of any part.
- Replacement of expendable maintenance items made in connection with required maintenance services after the item's first scheduled replacement as listed in the maintenance section of the engine/equipment operator's manual, such as spark plugs and filters.
- Incidental or consequential damages such as loss of time or the use of the engine/equipment, or any commercial loss due to the failure of the engine/equipment.
- Diagnosis and inspection charges that do not result in warranty-eligible service being performed.
- Any non-authorized replacement part, or malfunction of authorized parts due to use of non-authorized parts.

Owner's Warranty Responsibility



Emission Control Systems Information and Warranty—Gasoline

The engine/equipment owner, is responsible for the performance of the required maintenance listed in the Wacker Neuson engine/equipment operator's manual. Wacker Neuson recommends that all receipts covering maintenance on the engine/equipment be retained, but Wacker Neuson cannot deny warranty coverage solely for the lack of receipts or for the failure to ensure the performance of all scheduled maintenance.

Normal maintenance, replacement, or repair of emission control devices and systems may be performed by any repair establishment or individual; however, warranty repairs must be performed by an authorized Wacker Neuson dealer/service center.

The engine/equipment must be presented to an authorized Wacker Neuson dealer/service center as soon as a problem exists. Contact Wacker Neuson Product Support Department (1-800-770-0957) or visit wackerneuson.com to find a dealer/service center in your area, or to answer questions regarding warranty rights and responsibilities.

How to Make a Claim

In the event that any emission-related part is found to be defective during the warranty period, you shall notify Wacker Neuson Product Support Department (1-800-770-0957, or technical.support@wackerneuson.com, or wackerneuson.com), and you will be advised of the appropriate dealer/service center where warranty repair can be performed. All repairs qualifying under this limited warranty must be performed by an authorized Wacker Neuson dealer/service center.

You must take your Wacker Neuson engine/equipment along with proof of original purchase date, at your expense, to the authorized Wacker Neuson dealer/service center during their normal business hours.

For owners located more than 100 miles from an authorized dealer/service center (excluding the states with high-altitude areas as identified in 40 CFR Part 1068, Appendix III), Wacker Neuson will pay for pre-approved shipping costs to and from an authorized Wacker Neuson dealer/service center.

Claims for repair or adjustment found to be caused solely by defects in material or workmanship will not be denied because the engine/equipment was not properly maintained and used.

The warranty repairs should be completed in a reasonable amount of time, not to exceed 30 days.

17 Emission Control Systems Information and Warranty—Diesel

The Emission Control Warranty and associated information is valid only for the U.S.A., its territories, and Canada.

17.1 Emission Control System Background Information

Introduction

Wacker Neuson engines/equipment must conform with applicable Environmental Protection Agency (EPA) and California Air Resource Board (CARB) emissions regulations. These regulations require that manufacturers warrant the emission control systems for defects in materials and workmanship.

Furthermore, EPA and CARB regulations require all manufacturers to furnish written instructions describing how to operate and maintain the engines/equipment including the emission control systems. This information is provided with all Wacker Neuson engines/equipment at the time of purchase.

Exhaust Emissions

The combustion process produces carbon monoxide, oxides of nitrogen, and hydrocarbons. Control of hydrocarbons and oxides of nitrogen is very important because, under certain conditions, they react to form photochemical smog when subjected to sunlight. Carbon monoxide does not react in the same way, but it is toxic.

Problems that may affect Emissions

If any of the following symptoms arise, have the engine/equipment inspected and repaired by a Wacker Neuson dealer/service center.

- Hard starting or stalling after starting
 - Rough idling
 - Misfiring or backfiring under load
 - Afterburning (backfiring)
 - Presence of black exhaust smoke during operation
 - High fuel consumption
-

Tampering and Altering

Tampering with or altering the emission control system may increase emissions beyond the legal limit. If evidence of tampering is found, Wacker Neuson may deny a warranty claim. Among those acts that constitute tampering are:

- Removing or altering of any part of the air intake, fuel, or exhaust systems.
- Altering or defeating the speed-adjusting mechanism causing the engine to operate outside its design parameters.

17.2 Limited Defect Warranty for Exhaust Emission Control System

See the supplied engine owner's manual for the applicable emission warranty statement.

17.3 Limited Defect Warranty for Wacker Neuson Emission Control Systems

The Emission Control Warranty is valid only for the U.S.A., its territories, and Canada.

Wacker Neuson Sales Americas, LLC, N92 W15000 Anthony Avenue, Menomonee Falls, WI 53051, (hereinafter "Wacker Neuson") warrants to the initial retail purchaser and each subsequent owner, that this engine/equipment, including all parts of its emission control system, have been designed, built, and equipped to conform at the time of initial sale to all applicable evaporative emission regulations of the U.S. Environmental Protection Agency (EPA), and that the engine/equipment is free of defects in materials and workmanship which would cause this engine/equipment to fail to conform to EPA regulations during its warranty period.

Wacker Neuson is also liable for damages to other engine/equipment components caused by a failure of any warranted parts during the warranty period.

What is covered

Wacker Neuson recommends the use of genuine Wacker Neuson parts, or the equivalent, whenever maintenance is performed. The use of replacement parts not equivalent to the original parts may impair the effectiveness of the engine/equipment emission controls systems. If such a replacement part is used in the repair or maintenance of the engine/equipment, assure yourself that such part is warranted by its manufacturer to be equivalent to the parts offered by Wacker Neuson in performance and durability. Furthermore, if such a replacement part is used in the repair or maintenance of the engine/equipment, and an authorized Wacker Neuson dealer/service center determines it is defective or causes a failure of a warranted part, the claim for repair of the engine/equipment may be denied. If the part in question is not related to the reason the engine/equipment requires repair, the claim will not be denied.

Emission Control Systems Information and Warranty—Diesel

For the components listed in the following table, an authorized Wacker Neuson dealer/service center will, at no cost to you, make the necessary diagnosis, repair, or replacement necessary to ensure that the engine/equipment complies with the applicable EPA regulations. All defective parts replaced under this warranty become property of Wacker Neuson.

| System Covered | Components |
|--|--|
| Air filter system and associated plumbing (Before engine intake) | Air filter |
| | Air filter plumbing |
| Exhaust system connected after the Exhaust Manifold | Exhaust gas piping and muffler connected to the Exhaust Manifold |

What is not covered

- Failures other than those resulting from defects in material or workmanship.
- Any systems or parts which are affected or damaged by owner abuse, tampering, neglect, improper maintenance, misuse, improper fueling, improper storage, accident and/or collision; the incorporation of, or any use of, add-on or modified parts, or unsuitable attachments, or the alteration of any part.
- Replacement of expendable maintenance items made in connection with required maintenance services after the item's first scheduled replacement as listed in the maintenance section of the engine/equipment operator's manual, such as spark plugs and filters.
- Incidental or consequential damages such as loss of time or the use of the engine/equipment, or any commercial loss due to the failure of the engine/equipment.
- Diagnosis and inspection charges that do not result in warranty-eligible service being performed.
- Any non-authorized replacement part, or malfunction of authorized parts due to use of non-authorized parts.

Owner's Warranty Responsibility

The engine/equipment owner, is responsible for the performance of the required maintenance listed in the Wacker Neuson engine/equipment operator's manual. Wacker Neuson recommends that all receipts covering maintenance on the engine/equipment be retained, but Wacker Neuson cannot deny warranty coverage solely for the lack of receipts or for the failure to ensure the performance of all scheduled maintenance.

Normal maintenance, replacement, or repair of emission control devices and systems may be performed by any repair establishment or individual; however, warranty repairs must be performed by an authorized Wacker Neuson dealer/service center.

The engine/equipment must be presented to an authorized Wacker Neuson dealer/service center as soon as a problem exists. Contact Wacker Neuson Product Support Department (1-800-770-0957) or visit wackerneuson.com to find a dealer/service center in your area, or to answer questions regarding warranty rights and responsibilities.



How to Make a Claim

In the event that any emission-related part is found to be defective during the warranty period, you shall notify Wacker Neuson Product Support Department (1-800-770-0957, or technical.support@wackerneuson.com, or wackerneuson.com), and you will be advised of the appropriate dealer/service center where warranty repair can be performed. All repairs qualifying under this limited warranty must be performed by an authorized Wacker Neuson dealer/service center.

You must take your Wacker Neuson engine/equipment along with proof of original purchase date, at your expense, to the authorized Wacker Neuson dealer/service center during their normal business hours.

For owners located more than 100 miles from an authorized dealer/service center (excluding the states with high-altitude areas as identified in 40 CFR Part 1068, Appendix III), Wacker Neuson will pay for pre-approved shipping costs to and from an authorized Wacker Neuson dealer/service center.

Claims for repair or adjustment found to be caused solely by defects in material or workmanship will not be denied because the engine/equipment was not properly maintained and used.

The warranty repairs should be completed in a reasonable amount of time, not to exceed 30 days.





SAFETY MANUAL

FOR OPERATING AND MAINTENANCE PERSONNEL




Table of Contents

| | |
|-----------------------------------|----|
| Acknowledgment..... | 2 |
| Foreword | 3 |
| Safety Alerts..... | 4 |
| A Word to the User/Operator | 5 |
| Types of Roller Compactors..... | 6 |
| Follow a Safety Program..... | 7 |
| Prepare for Safe Operation..... | 12 |
| Start Safely..... | 17 |
| Operate Safely | 20 |
| Shut Down Safely | 30 |
| Perform Maintenance Safely | 31 |
| Final Word to the User | 43 |

Acknowledgment

We wish to thank the members of the Association of Equipment Manufacturers for their invaluable contributions in preparing this Safety Manual.

NOTICE OF COPYRIGHT PROTECTION


Copyright 2014, by the Association of Equipment Manufacturers. All rights reserved. This work may not be reproduced or disseminated in whole or in part by any means without the prior written permission of the Association of Equipment Manufacturers.

Foreword

This safety manual is intended to point out some of the basic safety situations that may be encountered during the normal operation and maintenance of your machine and to instruct you in safety practices for dealing with these conditions. This manual is **NOT** a substitute for the manufacturer's operator's manual(s).

Additional precautions may be necessary, or some instructions may not apply, depending on equipment, attachments and conditions at the jobsite or in the service area. The manufacturer has no direct control over equipment application, operation, inspection or maintenance. Therefore, it is **YOUR** responsibility to use good safety practices in these areas.

The information provided in this manual supplements the specific information about your machine that is contained in the manufacturer's operator's manual(s). Other information that may affect the safe operation of your machine may be contained on safety signs or in insurance requirements, employer's safety and training programs, safety codes, local, state/provincial and federal laws, rules and regulations.



**Read and understand
manuals before
operating**

IMPORTANT! Before you operate this machine, make sure you have the manufacturer's manual(s) for this machine and all attachments. If the manufacturer's manuals are missing, obtain replacements from your employer, equipment dealer or directly from the manufacturer. Keep this safety manual and the manufacturer's manuals with the machine at all times. Read and understand all manuals.

Safety videos and other training resources are available from some manufacturers and dealers. Operators are encouraged to periodically review these resources.

3

Safety Alerts

Safety Alert Symbol

This Safety Alert Symbol means: **"ATTENTION! STAY ALERT! YOUR SAFETY IS INVOLVED!"**



The Safety Alert Symbol identifies important safety messages on equipment, safety signs, in manuals or elsewhere. When you see this symbol, be alert to the possibility of death or personal injury. Carefully read the message that follows and inform other operators. Follow instructions in the safety message.

Signal Words

Signal words are distinctive words that will typically be found on safety signs on the roller compactor and other jobsite equipment. These words may also be found in this manual and the manufacturer's manuals. These words are intended to alert the operator to a hazard and the degree of severity of the hazard.



DANGER indicates a hazardous situation that, if not avoided, will result in death or serious injury.



WARNING indicates a hazardous situation that, if not avoided, could result in death or serious injury.



CAUTION indicates a hazardous situation that, if not avoided, could result in minor or moderate injury.



NOTICE indicates a property damage message.

A Word to the User/Operator

It is **YOUR** responsibility to read and understand this safety manual and the manufacturer's manuals before operating this equipment. This safety manual takes you step by step through the working day.

Graphics have been provided to help you understand the text.

Hazard recognition and accident prevention depend upon you being alert, careful and properly trained in the inspection, operation, transport, maintenance and storage of this equipment.



Read and understand all safety signs – replace damaged signs

Remember that **YOU** are the key to safety. Good safety practices not only protect you but also protect the people around you. Study this manual and the manufacturer's manuals for the specific machine. Make them a working part of your safety program. Keep in mind that this safety manual is written only for the types of roller compactors covered.

After studying the manufacturer's manuals and this safety manual, please contact the equipment manufacturer with any remaining questions.

Practice all usual and customary safe working precautions and remember:


SAFE OPERATION IS UP TO YOU!

YOU CAN PREVENT DEATH OR SERIOUS INJURY CAUSED BY UNSAFE WORK PRACTICES!

5


Types of Roller Compactors

This safety manual covers many different types of roller compactors including: steel wheel rollers, vibratory rollers, rubber-tired rollers, segmented pad/sheepsfoot soil compactors and landfill compactors. These may be either ride-on, walk-behind, or towed rollers. They may be used for the compaction of asphalt, soil, landfill or other materials. Excluded from coverage are vibratory plates and hand rammers.



Ride-on

Regardless of which machine you operate, it is your responsibility to study and understand this safety manual, and to see that a copy remains with your machine. Manufacturers produce machines with many built-in safety features. Employers provide accident prevention programs. Yet, the ultimate responsibility to operate and maintain your machine with the skill, care and knowledge essential for safety is yours.



Walk-behind

Follow a Safety Program

For Safe Operation

You must be a qualified and authorized operator for safe operation of this machine. You must clearly understand the written instructions supplied by the manufacturer, be trained — including actual operation — and know the safety rules and regulations for the jobsite. It is a good safety practice to point out and explain safety signs and practices to others, and to make sure they understand the importance of following these instructions.



Never operate while impaired by alcohol or drugs

⚠ WARNING! Drugs and alcohol affect operator alertness and coordination, and the ability to safely operate the equipment. **Never operate the machine while impaired by use of alcohol or drugs. Never knowingly allow anyone to operate the machine when their alertness or coordination is impaired.**

An operator taking prescription or over-the-counter medication must consult a medical professional regarding any side effects of the medication that would hinder their ability to safely operate this equipment.

Be Alert!

Know where to get assistance. Keep emergency numbers for doctors, ambulance service, hospital and fire department near your telephone. Know how to use a first aid kit and fire extinguisher/fire suppression system; know their location and practice getting to them. Ensure they have been properly tested and maintained.

Let others know where you will be working, and what time you will be returning. In case of an emergency, you want others to know where to find you.

Be Aware!

Take advantage of training programs offered.

Know the proper response to a fire or chemical spill on your machine.

7

Follow a Safety Program

Be Careful!

Human error is the result of many factors: carelessness, fatigue, sensory overload, preoccupation, unfamiliarity with the machine or attachments, or drugs and alcohol, to name a few. You can avoid death or serious injury caused by these and other unsafe work practices. Be careful; never assume accidents cannot happen to you.



For your safety and the safety of others, act safely and encourage your fellow workers to act safely as well.

Protect Yourself

Wear all the personal protective clothing and Personal Protective Equipment (PPE) issued to you or called for by job conditions.

You may need:

- Hard hat.
- Safety shoes.
- Safety glasses, goggles or face shield.
- Heavy duty gloves.
- Hearing protection.
- Reflective clothing.
- Wet weather gear.
- Respirator or filter mask.



Wear whatever is needed to protect yourself — don't take chances.

⚠ WARNING! Avoid death or serious injury from entanglement. **Do not wear loose clothing or accessories that could catch on moving parts or controls.** Examples of items to avoid include flopping cuffs, dangling neckties and scarves, wallets attached to chains, jewelry and wrist watches.

Follow a Safety Program

Know the Rules

Most job sites have rules governing equipment use and maintenance. Before you start work at a new location, check with the supervisor or safety coordinator. Ask about the rules you will be expected to obey.

OSHA enforces federal laws within the United States that apply to the safe operation, application and maintenance of equipment on some jobsites. It is the employer's responsibility to comply with these laws. A federal representative may periodically inspect a jobsite to see that these laws are being followed.

There may be other local, state/provincial, federal laws or international organizations that regulate the use of this equipment, along with specific jobsite or employer rules. It is important that you know and comply with all applicable laws and rules, **including those requiring operator training and certification.**

These are some of the rules you must work by:

- Only qualified and authorized individuals may operate this equipment.
- Inspect your machine and attachments before each use as specified by the manufacturer and your employer.

- Know the capacity and operating characteristics of your equipment. Do not misuse it.
- Wear proper clothing and PPE. Check that others are also wearing appropriate clothing.
- All shields, guards, air filters, access panels and doors must be properly installed before each use.
- Know the rules regarding traffic at your jobsite. Know what all signs, flags, and markings mean. Know hand, flag, horn, whistle, siren, or bell signals, if used.
- Never modify or remove any part of the machine (except for service; then make sure the part is re-installed or replaced if defective or worn out).



Know and understand
rules of operation



Understand
jobsite
signals


9

Follow a Safety Program

- **Never allow children to play near, ride on, or operate the equipment.**
- Keep bystanders well clear of the operation.
- Know the work area before you use the equipment. Be aware of possible hazards, including those overhead and underground.
- Only use attachments and parts that are approved by the manufacturer.
- Do not allow riders.
- Fasten seat belt or operator restraint before starting.
- Drive forward whenever possible.
- Always look in the direction of travel.
- Check correct mirror settings, if available.
- Look before backing up.
- Never leave the operator's seat without stopping the engine and removing the ignition key, if equipped. (See page 30, **Safe Shutdown.**)
- Use three-point contact (handholds and steps) and face the equipment when mounting or dismounting. (See page 17, **Mount and Dismount Properly.**)



Fasten seat belt
or operator restraint



Keep bystanders
away

Follow a Safety Program


Know the Equipment

Read and understand the DANGER, WARNING, CAUTION and NOTICE safety labels and other informational signs on the machine and the attachments, and in the manufacturer's operating manuals. Ask your supervisor or dealer to explain any information you do not understand. Failure to obey safety instructions could result in death or serious injury.


Know the following about your equipment:

- Function, purpose and use of all controls.
- Correct operation speeds.
- Slope and uneven terrain capabilities and proper operation under all conditions.
- Braking and steering characteristics.
- Turning radius and clearances.
- How to quickly stop equipment in an emergency.
- Rated operating capacity.

Keep in mind that rain, snow, ice, loose gravel, soft ground, slopes, and other site conditions can affect your machine's operating capabilities. Make sure you are thoroughly familiar with your machine's stability, braking, traction, and other handling characteristics under any conditions you are likely to encounter.



Know machine capacity and operating characteristics



Read and understand manuals before operating

11

Prepare for Safe Operation

Check and Use All Available Safety Devices

To protect you and others around you, your machine may be equipped with the safety equipment listed below. Additional equipment may be required or some items may not apply, depending on attachments used, jobsite conditions or applicable jobsite rules. Check that each required item is securely in place and in operating condition:

- Falling Object Protective Structure (FOPS).
- Rollover Protective Structure (ROPS).
- Safety Guards.
- Seat Belt.
- Operator seat/restraint bar(s)/interlock control system.
- Cab side-screens or windows.
- Special enclosures or accessories required for specific applications or jobsite conditions.
- Alternate exit (window).
- Grab handles.
- Guard Rails.
- Articulated joint locks.
- Lights.
- Mirrors.

- Anti-skid tread/steps.
- Safety signs.
- Horn.
- Guards.
- Back-up alarm.
- Emergency stop control.
- Fire extinguisher.
- First aid kit.
- Rotating beacon.
- Windshield wiper/defroster.

Use them! Never remove or disconnect any safety device. Replace any damaged, missing, or non-functional safety devices before resuming machine operation.

⚠ WARNING! Never remove or modify a ROPS or FOPS. Serious injury or death could result.



Fasten your seat belt

Prepare for Safe Operation

Check the Machine

Before beginning your work day, inspect the machine and have all systems in good operational condition.

- Perform daily and periodic service procedures as instructed by the equipment manufacturer.
- Check for broken, missing, loose, or damaged parts. Make necessary repairs.
- Check that all drum mounting bushes are pliable and free from damage.
- Check the water sprinkler system. Open the valve and make sure water flows through every hole in each spray bar.
- Check the tires for cuts, missing lugs, bulges, and correct pressure.
- Keep the steps and handholds clean and free of grease, oil, dirt, snow or ice.
- Check the parking brake for proper operation.
- Check condition and operation of any attachments.
- Ensure shielding is properly installed and in good condition. Repair or replace if damaged or missing.
- Ensure work lights (if equipped) are kept clean. Check that all lights work properly.
- Ensure the horn and back-up alarm (if equipped) are operating correctly. Repair or replace if damaged.

- Ensure any Slow Moving Vehicle (SMV) signs, reflectors and warning lights are in good condition and can be clearly seen. Repair or replace if damaged.
- Ensure all tools or loose objects are removed or securely fastened while operating the machine.
- Check for damaged or leaky hydraulic systems. Repair or adjust as needed.



Inspect
the machine before
each work shift

Hydraulic Fluid Injection Hazard

⚠ WARNING! Accidental injection of high-pressure oil into the hands or body is dangerous and could result in death or serious injury. **Use caution when checking hydraulic leaks as pressurized hydraulic fluid has enough force to penetrate skin, causing serious personal injury.**

13

Prepare for Safe Operation

If a leak is discovered:

- Ensure engine is turned off; relieve pressure in hydraulic circuit.
- Wear proper hand and eye protection.
- Visually examine the hydraulic hose or fluid lines in the vicinity of the leak for breaks or cracks. **Do not** use your hand to check for leaks.
- Repair or replace hydraulic lines per manufacturer's recommendation.


Fluid injection injuries are not always obvious. Victims have reported such injuries feel like a bee sting or splinter under the skin. If you suspect you have a fluid injection injury, do not take chances. Seek proper medical care immediately. If any fluid is injected into the skin, it must be surgically removed within a few hours by a doctor familiar with this type of injury.

Check the Cooling System

When checking the cooling system, make sure the engine is turned off and is cool. Remove the key to prevent fans from unexpectedly starting. Ensure the coolers and engine compartment are clean and free from debris, which could ignite and cause a fire.

If the machine is air-cooled, be sure the cooling unit has an unobstructed air flow. If it is liquid-cooled, check coolant level (at overflow tank, if provided).

⚠ WARNING! Allow the radiator to cool before checking the level. Hot radiator fluids could escape as steam and burn you. (See page 36, **Engine Coolant Hazards.**)



Wear
eye protection



High pressure
fluid can inject
into the body

Prepare for Safe Operation

Clean Up

Clean windows, lights, mirrors, and safety signs.

Make sure the operator's area, steering levers, pedals, joysticks, steps, and grab handles are clean. Oil, grease, snow, ice, mud, or debris in these areas could cause you to slip and fall, or lose control of the machine. Clean your boots of excess mud before entering the machine.

Remove all personal items or other objects from the operator's area. Secure these items in a toolbox or remove them from the machine.

Use Caution When Fueling

⚠ WARNING! Avoid injury from fire or explosion.

Never fill the fuel tank in poorly ventilated areas, with the engine running, while smoking, or when near an open flame.

Never overfill the tank or spill fuel. If fuel is spilled, clean it up immediately.


Be sure to use the correct type and grade of fuel.

Ground the fuel funnel or nozzle against the filler neck to prevent sparks that could ignite fuel vapors. Be sure to replace the fuel fill cap (if equipped) when you are done.

Ultra-Low Sulfur Diesel (ULSD) Fuel Hazard

Avoid Static Electricity Risk When Fueling

⚠ WARNING! Ultra-Low Sulfur Diesel (ULSD) poses a greater static ignition hazard than earlier diesel formulations with higher sulfur content. Avoid death or serious injury from fire or explosion; **consult with your fuel or fuel system supplier to ensure the delivery system is in compliance with fueling standards for proper grounding and bonding practices.**



Static discharge during fueling can cause explosion

15

Prepare for Safe Operation

Know the Working Area

Learn as much about your working area as possible.

Check at Ground or Floor Level

Inspect the surface over which you will travel. Look for holes, drop-offs and obstacles. Look for rough spots or hidden obstacles on surfaces which could cause a collision or loss of control. Look for weak spots on docks, ramps or floors. Look for oil spills, wet spots, and slippery surfaces. Look for soft soil, deep mud or standing water. Watch for anything that might make you lose control or cause the machine to roll over.

When operating inside a building, make certain you are within weight limitations of floors and ramps. Be aware of overhead clearances, doorways, aisles, etc. Plan travel routes ahead of time, in order to make sure you can see and protect bystanders. Pick up debris that can puncture tires.

Be observant of other workers, bystanders, and other machines in the area.

Remember, the danger of sliding and/or tipping on steep slopes is always present, regardless of how heavy or stable your machine may appear to be. Always use seat belts if a ROPS is equipped.

Check Overhead

Check the clearances of doorways, canopies, and overheads. Know exactly how much clearance you have under power and telephone cables.

⚠ DANGER! Contact with energized power lines will cause serious injury or death. **Never approach overhead power lines with any part of your machine unless all local, state/provincial and national (OSHA) required safety precautions have been taken.** Always use extreme caution around power lines.

Know your margin of safety. If possible, have power to lines disconnected. If not possible, request a signal person for guidance.

⚠ DANGER! Electrocution will result from touching or being near a machine that is in contact with, or near, an electrical source. **Stay away from any machine in contact with electrical wires until you are told it is safe to approach.**

Start Safely

Mount and Dismount Properly

Always use three-point contact when mounting or dismounting the machine. Three-point contact means one hand and two feet, or two hands and one foot, in contact with the machine at all times.

Never mount or dismount while carrying tools or objects that prevent three-point contact. Put parts or tools down. Maintain proper contact, climb or dismount, and then pick up the object.

Face the machine when you enter or leave the machine.

Clean shoes and wipe hands. Clean steps and handholds of chemical residue, snow, ice, mud or oil.

During mounting and dismounting:

- Use handholds and step plates.
- Never use steering wheels, joysticks or controls as handholds.
- Never jump on or off the machine.
- Never mount or dismount from a moving machine.

Warn Personnel Before Starting

Before starting, walk completely around the machine.

Make sure no one is under the machine, on it, or close to it. Let others know you are starting up and don't start until everyone is completely clear of the machine. As the equipment operator, you are responsible for the safe use of the machine, so always make sure you have communicated your work plans to others on the site.



Use three points of contact when mounting or dismounting



Avoid falls, clean up slippery areas

17

Start Safely

Starting the Engine


⚠ WARNING! Start the engine from the operator's seat only. **Never attempt to start the engine by shorting across starter terminals.** The machine may move unexpectedly, which could cause serious injury or death to anyone in its path.

Before starting, walk completely around compactor.


Know the exact starting procedure for your machine. See the manufacturer's operating manual(s) for starting.

- Sit in the operator's seat and adjust the seat so you can operate all the controls properly.
- Fasten the seat belt/operator restraint.
- Familiarize yourself with warning devices, gauges and operating controls.
- Make sure controls are in the neutral/locked position.
- Clear the area of all persons.
- Start the engine following the instructions in the manufacturer's operating manual(s).
- If necessary to run the engine or operate the machine within an enclosed area, be sure there is adequate ventilation.

⚠ WARNING! Exhaust fumes can kill. **Do not breathe exhaust fumes!**



Never start engine by shorting across starter terminals



Before starting, walk completely around compactor

Starting Aids

Ether/cold start fluid is **HIGHLY FLAMMABLE**. Before using it, always read the instructions on the ether/cold start fluid container and the instructions in the manufacturer's operating manual(s).


⚠ WARNING! Avoid injury from explosion or fire. If the engine is equipped with a glow plug pre-heater or other intake manifold type pre-heater, follow manufacturer's instructions before using ether/cold start fluid.

If you have trouble starting the engine and need to use jumper cables, follow the instructions in manufacturer's

Start Safely

operating manual(s). **Jump-starting is a two-person operation.** The operator must be in the operator's seat when jump-starting so the machine will be under control when the engine starts. Wear appropriate PPE before attempting to jump-start your machine.

⚠ WARNING! A battery explosion or a run-away machine could result from improper jump-starting procedures. (See page 38, **Battery Hazards.**)



To avoid explosion,
follow proper jump-
starting procedures

After Starting Engine

Observe gauges, instruments, and warning lights to assure that they are functioning and their readings are within the operating range.

Run an Operating Check

Do not use a machine that is not in proper operating condition. It is your responsibility to check the condition of all systems and to run the check in a safe area.

Test Controls

Roller compactors come equipped with various control configurations, patterns and operating modes, each with their own handling characteristics. Some have selectable or configurable controls, to suit personal preferences or specific applications. Make sure that you know which control pattern you have selected and that you understand how the machine will handle when using that control pattern.

Make sure the machine is operating properly by doing the following:

- With the control levers or joysticks in neutral, test engine speed control.
- Operate each pedal, lever or joystick to make sure all functions are correct.
- Operate the travel control lever(s) or joysticks to ensure correct operation in forward and reverse. Test steering to the right and to the left, while moving slowly in a clear, safe area.

⚠ WARNING! Before operating the machine under working conditions, **be certain you can control both the speed and direction of the machine.** Any loss of control could result in death or serious injury.

19

Operate Safely

Masked Visibility Areas

Machines have areas where the operator's visibility of the job site can be affected by the machine itself. ROPS posts, attachments, a drum, even items in the cab, could limit your view of the surrounding area and possibly mask hazards or people around you. These masked visibility areas vary from machine to machine, and it is very important you be aware of these areas before operating your machine.

Follow these safety precautions to reduce the hazards posed by masked visibility areas:

- Look around the machine before operating. Objects near the machine and close to the ground can be difficult to see from the cab.
- Always look in the direction of travel, including reverse. A back-up alarm is no substitute for looking behind you when operating the machine in reverse.
- Keep bystanders away, even if your machine is equipped with a back-up alarm.

Remember These Rules

Never allow untrained, unqualified, or unauthorized personnel to operate your machine.


Never allow other personnel to ride on your machine unless appropriate seating is provided, and then, only if authorized to do so.

Never abuse your machine. Misuse or abuse can cause an accident.

Articulated Machines

Never enter or place any part of your body in the "hitch area" or "pinch areas" of an articulated machine while the engine is running, or when there is any chance another person could start the machine.

If available, use the articulated joint lock during maintenance work, transportation, etc.



Keep body parts away
from pinch area

Operate Safely

Work on Slopes Safely

When working on slopes, avoid side-hill travel whenever possible. It is generally safer to operate up and down the slope. Remember the danger of sliding and/or tipping on steep slopes is always present, regardless of how heavy or stable your machine may appear to be.

Always use seat belts if your machine is equipped with a ROPS. If equipped, make sure foldable ROPS is upright. Keep your hands and feet inside the cab at all times.

When climbing or descending steep grades, select the proper gear before starting on the slope, to assure adequate power or engine breaking.

If your machine has a gear shift, select a low gear. If your machine has a hydrostatic drive, the speed control should be in the slow travel position, close to neutral, not in the fully displaced position.

On machines that have a gear shift and a hydrostatic control, both controls must be in their slow travel position.

Always be sure that manually operated gear type transmissions are fully engaged before starting onto a grade. Do not attempt to change the gear selection while traveling on a grade. See the manufacturer's manual for specific instructions.

Watch Out for Hazardous Working Conditions

Be alert for hazards. Know where you are at all times. Watch for overhead obstacles. Look up as well as down.

Avoid operating your machine too close to an overhang, deep ditch or hole. If your machine inadvertently gets close to a tipping condition or drop-off, STOP and get off the machine after applying the parking brake. Plan your moves carefully before proceeding. Reversal is often the best move.

⚠ WARNING! Never operate the machine close to the edge of an overhang or gully. The edges could collapse or a slide could occur causing serious injury or death.

Stay Alert! Rough Terrain Can be Hazardous!

Be alert to obstacles and excessively rough terrain. Back away from them and go around.

Always travel slowly over rough terrain and hillsides. Maintain a speed consistent with the working conditions.


21

Operate Safely

Follow Safe Operating Practices

Make these safe practices part of your daily routine:

- Keep your seat belt/operator restraint fastened.
- Never leave the operator's seat without having the unit come to a complete stop and applying the breaks.
- Operate the controls smoothly — don't jerk the steering levers or joysticks.
- Avoid sudden stops, starts or turns.
- Use care and good judgment.
- Never attempt to operate the controls unless properly seated in the cab.
- To shut down the machine, stop the engine and remove the ignition key, if equipped. (See page 30, **Safe Shutdown.**)



Operate
instruments
and controls
smoothly

⚠ WARNING! Avoid Serious injury or death! Keep your entire body inside the operator's cab while operating the machine. Never work with your head, arms, feet or legs beyond the operator's compartment.

Traveling on Jobsite

Take it slow and easy when traveling through congested areas. Traffic courtesy pays off.

Give the right-of-way to loaded machines. Maintain a safe distance from other machines. Pass cautiously.

Don't obstruct your vision when traveling or working. (See page 20, **Masked Visibility Areas.**) Operate at speeds slow enough so you have complete control at all times. If possible, avoid travel over rough, slippery or uneven terrain, and on hillsides.

Travel Safely

When roading the machine, know your approximate stopping distance at any given speed.

Travel at controlled speeds, especially around corners.

Look in all directions before reversing your direction of travel.


Never coast in neutral.

Operate Safely


Avoid steep slopes or unstable surfaces. If you must drive on a slope, travel at an appropriate speed and with extreme caution. Do not drive across an excessively steep slope under any circumstances. Travel straight up and down the slope. Before operating on slopes, check the surface conditions for adequate traction. Loss of traction can cause the machine to slide and tip.

⚠ WARNING! Avoid death or serious injury. **Travel up and down slopes with the heavy end of the machine pointed uphill.**

Check machine manufacturer's recommendations.



Operate perpendicular to banks – stay back from the edge



Use caution – stay safely away from bank or excavation edge

Rules of the Road

When traveling on public roads or streets, obey all traffic regulations applicable to machine use and classification.

Make sure lights and warning signs are in place and visible. Make sure a SMV emblem is installed and visible to any vehicle approaching from the rear.

Find out if you must use an escort vehicle. Approach intersections with caution; observe speed and traffic control signs. Avoid panic stops and sharp turns.

Like any responsible operator, be considerate of other drivers. If traffic backs up behind you, it is a good idea to pull over periodically and allow traffic to pass when it is safe to do so.

Stop at all railroad crossings and look both ways before proceeding. Never park in traffic areas. If it is necessary to stop at night, pull off the road and set up flares or reflectors. When driving at night, use appropriate lights.

Watch Out for Obstacles

Adjust your speed to conditions. Avoid crossing ditches, curbs or exposed railroad tracks. If obstacles are unavoidable, reduce speed and cross at an angle.

23

Operate Safely

Keep your machine under control. Keep speed to a minimum when visibility is poor.

Before entering underpasses, tunnels or bunkers, check for oncoming traffic or obstructions.



Obey traffic regulations

Work at Night Safely

Night operations require additional precautions to stay safe. Pay close attention and stay alert. Others passing through the work site may not be aware of hazards.

Plan the job, communicate the plan and inspect the work area during daylight. Mark obstacles ahead of time with reflective material.

Wear appropriate reflective apparel at all times – for operators and crew on night operations.

Ensure visibility of gauges and controls.

Ensure adequate lighting to illuminate work zone in compliance with state and local regulations and requirements.

Ensure adequate hazard lights (strobe or flashing/rotating lights) in compliance with state and local regulations and requirements.

Utilize direct line of sight, not mirrors, when working at night. Use spotters when direct line of sight is not possible. Lights can reflect in mirrors, causing a hazard to be unseen, or a masked visibility area.

Lack of natural light will impact visibility and may increase the risk of being backed over by vehicles or equipment.

Adjust work lights to minimize glare for traffic and workers.

Know where the other workers are at all times. Tell others where you are going.

Beware of fatigue. Check on crew members.

Stay in assigned work zones.

Enter and exit machine on side away from traffic, if possible.

Operate Safely

Exhaust Fumes in a Closed Space Can Kill


Vent exhaust and assure a flow of fresh air when an internal combustion engine is used in a closed space.

⚠ WARNING! Exhaust fumes can kill. **Do not breath exhaust fumes from any kind of engine.**



Operating in Flammable/Explosive Atmospheres

⚠ WARNING! A roller compactor cannot be operated in flammable or explosive atmospheres. Use in explosive atmospheres can result in fires and/or explosions which could cause serious injury or death.



Loading and Unloading Safely

Always wear your seat belt/operator restraint when loading or unloading your machine from a transport device, such as a flatbed truck.

When transporting a compactor, follow the manufacturer's recommended loading and unloading procedures.

Extreme care should be exercised when loading or unloading a walk-behind roller. It is generally best to stand behind and off to one side rather than directly behind a machine moving up or down a ramp.

Several precautions are applicable to all machines:

- Never load or unload a machine by yourself.
- Keep bystanders away.
- Load and unload on a level surface.
- Maintain proper visibility by loading or unloading in well-lit areas, and away from other vehicles, equipment or buildings.
- Block transport vehicle with wheel chocks so it cannot move.
- Ensure trailer bed and ramps are in good condition.
- Use ramps of adequate size and strength, with a low angle and proper height.

25

Operate Safely

- Rear of trailer must be blocked or supported.
- Keep trailer bed and ramps free of clay, oil, ice, snow, and other materials which could become slippery.
- Chain and block the machine securely for transport. Use tie-down points as marked on the machine by the manufacturer. Follow the manufacturer's instructions in the operator's manual for tying down.
- Cover or remove rear-facing SMV sign on the roller compactor, if equipped, to avoid confusing drivers following the transport vehicle.
- Unload the machine by driving off in the opposite direction; do not turn the machine around.

Transporting Safety Tips

General

When towing a machine on a trailer, or a machine equipped with "portability or transport wheels," always use a hauling vehicle of sufficient weight, horsepower and braking capacity to maintain proper control.

Never attempt to tow a trailer or machine if the hitching devices are of insufficient or questionable capacity, improperly matched in size or shape, or positioned at improper heights.

When towing a machine equipped with portability or transport wheels, always follow the manufacturer's towing instructions.

Before Towing

When connecting a trailer to a hauling vehicle, block under the trailer's tongue before attempting to make the connection. Never attempt to lift heavy tongues or move heavy trailers by hand. Never get any part of your body under the tongues when hitching or unhitching.

Make sure the hitch pin is of the proper size and securely locked in place before towing.

If the roller is designed to hang from the tailgate of a vehicle when being transported, be certain the hook brackets meet the roller manufacturer's specifications.

Use tow bars between the hauling vehicle and trailer or towed machine. Be sure the chains are properly and securely connected at both ends. Cross the chains under the tongues when connecting to the hauling vehicle.


Make sure electrical and other connections between the hauling vehicle and trailer or towed machine are properly and securely made. After connecting, check the lights for proper operation. If the towed trailer or

Operate Safely

machine is equipped with brakes operable from the hauling vehicle, check to make sure they are operating properly.

Always be sure the portability or transport wheels, on machines so equipped, are locked in the lowered position.

Check all tires for proper pressure, excessive or abnormal wear, and potentially dangerous cuts, bruises or bulges. Have any problems corrected before proceeding.



**Chain and block
compactor securely
for transport**

Towing

Use care when towing a trailer or machine when:

- Maneuvering in tight places
- Backing (visibility is reduced, and jackknifing must be avoided)
- Towing on steep grades.

Know and obey all local, state and federal laws and regulations.

Do not travel at speeds above those recommended by the manufacturer.

Do not allow anyone to ride on a trailer or towed machine.

When necessary to disconnect and park a trailer or towed machine, select a location that is level and, if possible, where children are unlikely to be present. Before disconnecting a trailer, block the front AND rear of the wheels and block under the tongues.

27

Operate Safely

Walk-Behind Rollers

Start-up

Only operate a walk-behind roller if you are thoroughly familiar with the manufacturer's operating instructions. If you have any questions or uncertainty, consult the manufacturer or dealer before attempting to operate it.

Always follow the manufacturer's instructions for starting the engine. All controls must be in the correct position before attempting to start the engine.

Starting fluid is not recommended when hand starting an engine, because the engine may kick back, causing injury.

Operation

When operating a walk-behind roller, exercise extreme care to avoid having your feet or clothing caught under the dolly wheels or roller. When possible, stand behind and off to one side of the machine, rather than directly behind it.


Particular care must be exercised when operating near obstructions and on slippery surfaces, grades and side slopes. Wear slip-resistant safety shoes or boots.

Do not ride on a walk-behind roller unless it is designed to accommodate riders and an appropriate seat is provided.

Do not attempt to shift on a grade if the roller has a mechanical transmission.

Do not operate a walk-behind roller in unshored trenches or near steep, unsupported banks. The vibrations could cause a cave-in.

Uneven grades can cause the handle to raise or lower unexpectedly, striking the unwary operator.



**Set all controls to
correct position
before starting the
engine**

Operate Safely

Towed Rollers

Most general safety precautions covered earlier in this manual are also applicable to towed roller operation. There are many precautions specific to towed rollers that must be taken. Study your manufacturer's manual for instructions on your specific towed roller. Consult the manufacturer or dealer with any concerns.

Use a tow tractor of sufficient weight, drawbar horsepower and braking capacity to properly control the towed roller. Proper weight balance and distribution is also essential.

Block under the tongues of the towed roller before attempting to connect it to the towing vehicles or machine. Do not attempt to lift heavy tongues or move towed rollers by hand. Do not get any part of your body under the tongues when hitching or unhitching.

Make sure the hitch pin is of the proper size, and is securely locked in place before towing. If safety chains are provided, make sure they are properly and securely connected at both ends. Cross the chains under the tongues when connecting to the towing vehicle. Make sure all electrical or hydraulic connections are made properly and securely.

Landfill Compactors

Operators of landfill compactors should carefully handle materials that could be picked up and thrown by the wheels, become lodged in the machine, or that are highly flammable.

Frequent checks should be made for wire, cable or other material wound around the axle members. Remove them immediately.

Travel with the blade as low as possible.

Maintain good operator visibility. Keep all mesh and windows free of accumulated materials.

When parking the machine, always lower the blade.

29

Shut Down Safely

Select a Proper Parking Site

Park in an off the road area, out of traffic, or as instructed. If necessary to park in a traffic lane, use the appropriate flags, barriers, flares, lights and warning signals. Provide advance warning signals in the traffic lane to warn approaching traffic.

Park on level ground whenever possible. When that's not possible, position the machine at right angles to the slope. Make sure the machine is on a firm footing, and that there is no danger of sliding. Do not leave your machine until you are sure it is safely blocked in both directions and parking brakes are firmly applied.

⚠ WARNING! Avoid death or serious injury. **Never leave the compactor unattended with the engine running.**

Safe Shutdown


Know the proper shutdown procedure for your machine. As with the starting procedure, this varies with the type and model of machine.

If equipped, always lower the dozer blade when parking.

Follow the manufacturer's operation manual for your machine. Remove the key(s) to prevent unauthorized starting and movement, and position and lock any antivandalism devices.

Dismount Properly

Make sure your machine is fully stopped and shut off before dismounting. When you leave the compactor, always maintain three-point contact with the steps and grab handles. Face the compactor as you dismount. Never jump off a machine.



Shut engine off,
remove key



Use three points
of contact when
mounting or
dismounting

Perform Maintenance Safely


Know What You're Doing

Maintenance on this type of machine is not for inexperienced or untrained personnel. It can be hazardous unless performed properly. Be sure you have the necessary skill, information, correct tools and proper equipment to do the job safely.

Be sure to maintain the equipment according to the manufacturer's instructions. Regularly check the operation of the protective and safety devices.

Do not perform any work on a machine unless you are authorized and qualified to do so.

If you have been authorized to perform maintenance, **read the manufacturer's operating and service manuals**. Study the instructions. Check the lubrication charts and examine all the instruction messages on the machine.



Maintain equipment

Protect Yourself

Wear all the personal protective clothing and PPE issued to you or called for by job conditions or your supervisor.

You may need:

- Hard hat.
- Safety shoes.
- Safety glasses, goggles or face shield.
- Heavy duty gloves.
- Hearing protection.
- Reflective clothing.
- Wet weather gear.
- Respirator or filter mask.

Wear whatever is needed to protect yourself. Do not take chances.

31

Perform Maintenance Safely

⚠ WARNING! Avoid death or serious injury from entanglement. **Do not wear loose clothing or accessories. Stay away from all rotating components when the engine is running.** Contact, wrapping or entanglement with rotating or moving parts could result in death or serious injury.

Wear a rubber apron and rubber gloves when working with corrosives. Wear gloves and safety shoes when handling wooden blocks or sharp-edged metal.


Always use safety glasses, goggles or a face shield. They provide eye protection from fluids under pressure, during grinding and while servicing batteries. Protection is also needed from flying debris, liquids and loose material produced by equipment, tools and pressurized air/water.

Wear a face shield and follow manufacturer's instructions when you disassemble spring-loaded components or work with battery acids. Keep pockets free of all objects that could fall out and drop into machinery.

Handle tools and heavy parts sensibly, with regard for the safety of yourself and others. Lower items; don't drop them.



Avoid rotating parts



Wear eye protection



Do not
loosen
radiator cap
until cool

Perform Maintenance Safely

Prepare the Work Area

- Position the machine on a level area out of the way of other working equipment.
- Make sure there is adequate light, ventilation and clearance.
- Remove oil, grease or water and dry slippery surfaces.
- Clean around the area to be serviced to minimize contamination.

Prepare the Machine

Stored energy sources (electrical, mechanical, hydraulic, pneumatic, chemical, thermal, etc.) must be controlled or reduced to a practical minimum before performing any maintenance, repair, or service procedures.

Safety practices to prevent potential injuries from energy-releasing sources include:

- Place controls in NEUTRAL or LOCKED position before shutting off engine.
- Set parking brake or block wheels.
- Allow all moving parts to stop.
- Shut off engine.
- Relieve hydraulic system pressure by moving controls several times in all directions or per manufacturer's instructions.



Avoid falls, clean slippery surfaces

- Lock out the unit according to the manufacturer's manual.
- Attach a "DO NOT OPERATE" warning tag to the control levers.
- Lock ignition, remove key (if equipped) and take it with you.
- Look and listen for evidence of moving parts before dismounting.
- Shut off master electrical switch (if equipped).
- Disable the battery switch (if equipped).
- Securely support or block up machine or other components with approved locking devices before working underneath them.
- Relieve pressure before disconnecting or disassembling any pressurized system.
- Block or relieve spring pressure before disassembling any spring-loaded mechanism.
- Avoid flames, sparks, or smoking near any fuel, hydraulic fluid or other flammable material such as spraying debris.

33

Perform Maintenance Safely

⚠ WARNING! Unsupported raised machines or other equipment may drop unexpectedly. **Never go under equipment when raised unless supported by an approved support device(s).** Death or serious crushing injury could result from falling equipment.

Remove only guards or covers that provide access to the area being serviced. Replace all broken or missing guards and covers when work is complete.

⚠ WARNING! Avoid injury or death. **Never work on machinery with the engine running unless instructed by the manufacturer's manuals for specific service.**



Use a "DO NOT OPERATE" tag

Common Maintenance Safety Practices

Use Proper Ventilation

If it is necessary to run an engine in an enclosed area, remove the exhaust fumes from the area with an exhaust pipe extension.

If you do not have an exhaust pipe extension, make sure you open doors and windows to get plenty of outside air into the area.



Ventilate work area

⚠ WARNING! Exhaust fumes contain carbon monoxide which could be deadly if inhaled. **Never operate any type of engine without proper ventilation. EXHAUST FUMES CAN KILL.**

Perform Maintenance Safely

Use Jacks and Hoists Carefully

Safety stands or blocks must be located on a rigid part of the machine. Do not position stands under axles or wheel supports that may rotate. Refer to manufacturer's manual.

⚠ WARNING! Prevent crushing injury. **Never use concrete blocks for supports. They could collapse under even light loads.**

If you must work beneath raised equipment, always use wood blocks, jack-stands or other rigid and stable supports. When using jacks or hoists, always be sure they are adequately supported.

Make sure the hoists or jacks you use are in good repair. Never use jacks with cracked, bent, or twisted parts. Never use frayed, twisted or pinched cables. Never use bent or distorted hooks.



**Avoid crushing,
use proper support for
raised equipment**

Fuel Hazards

⚠ WARNING! Avoid serious injury or death. **Always use approved fuel containers and/or fuel dispensing equipment to reduce the risk of explosion or fire.**



**No smoking and no
open flames**

Always observe these practices to reduce the possibility of a serious accident:

- Shut off engine and ignition during refueling.
- Always ground the fuel nozzle against the filler neck to avoid sparks.
- Keep sparks and open flames away from fuel.
- Do not smoke while refueling or when handling fuel containers.
- Do not cut or weld on or near fuel lines, tanks or containers.
- Do not overfill the tank or spill fuel. Clean up spilled fuel immediately.

35

Perform Maintenance Safely

Ultra-Low Sulfur Diesel (ULSD) Hazard

⚠ WARNING! Ultra-Low Sulfur Diesel (ULSD) poses a greater static ignition hazard than earlier diesel formulations. Avoid death or serious injury from fire or explosion; **consult with your fuel or fuel system supplier to ensure the delivery system is in compliance with fueling standards for proper grounding and bonding practices.**

Engine Coolant Hazards

⚠ WARNING! Avoid serious injury or death. Liquid cooling systems build up pressure as the engine gets hot, so **use extreme caution before removing the radiator cap.**

- Stop the engine and wait for the system to cool.
- Wear protective clothing and safety glasses.
- Turn the radiator cap slowly to the first stop to allow the pressure to escape before removing completely.



**Remove radiator
cap slowly**

Hydraulic System Hazards

Be sure to follow manufacturer's instructions for relieving fluid pressure before performing any maintenance. The hydraulic system is pressurized whenever the engine is on and may hold pressure even after the engine is shut off. Cycle hydraulic controls, including auxiliary hydraulic control (if equipped), after the engine is shut off.



**Check for
leaks and inspect
hoses**

During inspection of the hydraulic system:

- Wait for fluid to cool before disconnecting the lines. Hot hydraulic fluid can cause SEVERE BURNS.
- Wear appropriate eye protection. Hydraulic fluid can cause permanent eye injury.
- When venting or filling the hydraulic system, loosen the filler cap slowly and remove it gradually.
- **Never** reset any relief valve in the hydraulic system to a pressure higher than recommended by the manufacturer.

Perform Maintenance Safely

Hydraulic Fluid Injection Hazard



High pressure fluid
can inject into
the body

⚠ WARNING! Accidental injection of high-pressure oil into the hands or body is dangerous and could result in death or serious injury. **Use caution when checking hydraulic leaks as pressurized hydraulic fluid has enough force to penetrate skin, causing serious personal injury.**

If you discover a leak:

- Ensure engine is turned off; relieve pressure in hydraulic circuit.
- Wear proper hand and eye protection.
- Visually examine the hydraulic hoses or fluid lines in the vicinity of the leak for breaks or cracks. **Do not** use your hand to check for leaks.
- Repair or replace hydraulic lines according to the manufacturer's recommendations.

Fluid injection injuries are not always obvious. Victims have reported such injuries feel like a bee sting or splinter under the skin. If you suspect you have a fluid injection injury, do not take chances. Seek proper medical care immediately. If any fluid is injected into the skin, it must be surgically removed within a few hours by a doctor familiar with this type of injury.

Diesel Particulate Filter Hazard

You may need to run an active regeneration on some machines with a diesel particulate filter (DPF). Running an active regeneration to clean a DPF can create extremely high temperatures. Consult your operator's manual for the proper procedure for running an active regeneration.

⚠ WARNING! Extremely high temperatures can cause a fire or explosion, so **do not run an active regeneration in an explosive or flammable atmosphere.**



Do not operate in
explosive/flammable
atmosphere

37

Perform Maintenance Safely

Electrical System Hazards

Light Bulbs and Illumination

Some machines are equipped with High-Intensity Discharge (HID) Xenon light bulbs which operate at very high voltage. Do not begin installation of HID-Xenon lamps unless the lamps are turned off, the engine is turned off, the key is removed (if equipped), and you are wearing appropriate eye protection.

⚠ WARNING! Do not look directly into HID-Xenon lamps. Eye damage could occur.


Wear gloves and safety glasses when handling bulbs. Dangerous voltage sparks may occur and cause injury or damage to the connector. See manufacturer's warnings packaged with replacement bulbs.

Before working on the electrical system, either hit the main power disconnect switch, if equipped, or disconnect the battery cable(s).

- Remove the battery negative (-) cable(s) first.
- When reconnecting the battery, connect the battery negative (-) cable(s) last.

Battery Hazards

The liquid in batteries contains acid, which is a POISON and could cause SEVERE CHEMICAL BURNS.



Wear face
protection

Avoid injury:

- Wear a face shield to prevent contact with your eyes.
- Wear chemical-resistant gloves and clothing to keep liquid off your skin and regular clothing.

⚠ WARNING! Liquids in batteries will damage eyes or skin on contact. **Always wear a face shield to avoid getting liquid in your eyes.**

If liquid from the battery contacts your eyes, flush immediately with clean water and get medical attention.

Wear chemical-resistant gloves and protective clothing to keep liquid off your skin. If liquid contacts skin or clothing, wash off immediately with clean water. **If liquid is ingested,** drink large quantities of water or milk. **DO NOT** induce vomiting. Seek medical attention immediately.

Perform Maintenance Safely

Avoid Explosion

⚠ WARNING! Avoid serious injury from explosion. Lead-acid batteries produce extremely explosive gases especially when being charged. **Keep arcs, sparks, flames and lighted tobacco away.**

- **Do not** smoke near batteries.
- Keep them away from arcs, sparks and open flames.
- Provide adequate ventilation.

Never check the battery by placing a metal object across the battery posts. The resulting spark could cause an explosion.


⚠ WARNING! Avoid serious injury from battery explosion. **Do not charge a battery or jump-start the engine if the battery is frozen.**

Warm to 60°F (15.5°C) or the battery may explode and could cause serious injury.


Safety rules during battery jump-starting:

- Follow the instructions for proper battery jump-starting, as specified in the manufacturer's manual.
- Be sure the machines are not touching.
- Observe the polarity of the batteries and connections.

- Make the final cable connection to the engine or the furthest ground point away from the battery. Never make the final connection at the starter or dead battery. Sparks may ignite the explosive gases present at the battery.
- When disconnecting cables, remove the cables in reverse order of connection (e.g., final connection first).



Avoid sparks and open flames near batteries



When jump-starting, observe polarity and make final connection at ground point

Toxic Chemical Disposal

For the safety of others and the environment, consult with your operator's manual or site supervisor for proper disposal of batteries and any chemicals or fluids.

39

Perform Maintenance Safely

Tire and Wheel Maintenance

Check your tires and wheels daily, if equipped, because the stability of the machine can be dramatically affected by tire pressure or damage to tires or wheels.

Check tires for:


- Correct pressure.
- Cuts and bulges.
- Nails or other punctures.
- Uneven or excessive wear.
- Condition of valve stems and caps.

Check wheels for:

- Damage to the rims.
- Missing or loose lug nuts or bolts.
- Misalignment.

All tire service should be performed by a qualified tire service center or by an authorized service person who has been properly trained in the procedures and use of safety equipment designed for tire servicing.

⚠ WARNING! The types of wheels and tires usually found on this equipment require special care when servicing to prevent death or serious injury. **Do not inflate the tires above the recommended pressure.**



Check tires and wheels for damage



Maintain proper tire pressure

Perform Maintenance Safely

Keep wheel lug nuts tightened to manufacturer's recommendations.

An increase in tire pressure during operation is normal, and should NOT be reduced.

Never reinflate a tire that has been run flat or seriously under-inflated without removing the tire from the wheel. Have the tire and wheel closely inspected for damage before remounting.



Avoid tire explosion

When adding air to a tire, do so from a distance. Always use a long hose with a self-attaching chuck; stand away from the tire sidewall and to one side as far as possible.

Do not inflate tires with flammable gases or from systems using an alcohol injector.


Never cut or weld on a wheel with an inflated tire mounted on it. This could cause explosive decompression.

Check that the tire size and wheel are correctly matched.

When replacing the tires, ensure the tires are of the appropriate rating specified by the manufacturer.

⚠ WARNING! Avoid death or serious injury. **Always use a safety cage or cable restraints when reinflating a repaired tire.**

Tires should not be operated at speeds higher than their rated speed.



Use safety devices when reinflating tires

41

Perform Maintenance Safely

Roll-Over Protective Structure (ROPS) and Falling Object Protective Structure (FOPS) Safety Precautions

Do not remove the ROPS/FOPS except for service. Reinstall them correctly before allowing the machine back into service.

Do not modify ROPS/FOPS in any manner. Unauthorized modifications such as welding, drilling, cutting or adding attachments could weaken the structure and reduce your protection. Replace ROPS/FOPS if subjected to rollover or damage. Do NOT attempt to repair them. See the manufacturer's manual(s) for complete instructions and inspection requirements.

If your machine is equipped with a foldable ROPS, make sure it is upright whenever the machine is in use.

Complete Service and Repairs Before Machine is Released

Tighten all bolts, fittings, and connections to torques specified by the manufacturer.

Are there any missing cotter pins, washers, locknuts, etc.? Are there any parts left over?

Start the engine and check for leaks. (See page 36, **Hydraulic System Hazards**.) Operate all controls to make sure the machine is functioning properly. Test the machine if necessary. After testing, shut down and check the work you performed.

Recheck all fluid levels before releasing the equipment for operation.

All parts should be inspected during repair and replaced if worn, cracked or damaged. Excessively worn or damaged parts could fail and cause injury or death.

Install all guards, covers, and shields after servicing. Refill and recharge pressure systems only with manufacturer-approved or recommended fluids.



Verify service work when completed

Final Word to the User

You have just finished reading the AEM Roller Compactor Safety Manual. It is impossible for this manual to cover every safety situation that you may encounter on a daily basis. Your knowledge of these safety precautions and your application to the basic rules of safety will help to build good judgment in all situations. Our objective is to help you develop, establish and maintain good safety habits to make operating a roller compactor easier and safer for you.

Many pictorials in this safety manual can be downloaded at <http://pictorials.aem.org>.

For additional publications, visit our website at www.safetymaterials.org.

43



ASSOCIATION OF
EQUIPMENT MANUFACTURERS




e-mail safetymaterials@aem.org
www.aem.org

This manual is one in a series on the safe operation of machinery, published by AEM.




To order AEM safety materials
visit www.safetymaterials.org.










| Description | Ref. | Description |
|--|------|--|
| Start switch (optional) | 31 | Brake and bypass solenoid |
| Reverse switch | 32 | Reverse alarm |
| Ignition signal switch | 33 | Fuel solenoid |
| Ignition start switch | 34 | Horn |
| Ignition turn signal light | 35 | Spray bar pump |
| Ignition turn signal light | 36 | Neutral relay |
| Ignition charge regulator | 37 | Crank relay |
| Ignition glow plug solenoid | 38 | Glow plug relay |
| Ignition starter | 39 | Throttle relay |
| Ignition emergency | 40 | Parking brake switch |
| Ignition all-function sensor | 41 | Rear light (left) |
| Ignition pressure sensor | 42 | Head light (left) |
| Ignition filter sensor | 43 | Head light (right) |
| Ignition level sensor | 44 | Front parking light (left) (optional) |
| Ignition fuse (throttle pull) | 45 | Front turn light (left) (optional) |
| Ignition fuse (main) | 46 | Front parking light (right) (optional) |
| Ignition fuse (lights) | 47 | Front turn light (right) (optional) |
| Ignition horn switch | 48 | Rear parking light (left) (optional) |
| Ignition operation mode switch | 49 | Rear turn light (left) (optional) |
| Ignition switch | 50 | Rear parking light (right) (optional) |
| Ignition over relay | 51 | Rear turn light (right) (optional) |
| Ignition horn switch | 52 | Beacon |
| Ignition bottle switch | 53 | License light (optional) |
| Ignition work light switch | 54 | Seat switch |
| Ignition display module | 55 | Neutral switch |
| Ignition horn timer module | 56 | Vibration switch |
| Ignition bottle solenoid | 57 | Backup switch |
| Ignition glow plug engine | 58 | 12V accessory outlet |
| Ignition operation solenoid (front only) | 59 | Turn / tail light harness (optional) |
| Ignition operation solenoid (front & rear) | 60 | — |





| Description | Ref. | Description |
|---------------------------------------|------|--|
| Start switch (optional) | 31 | Brake and bypass solenoid |
| Reverse switch | 32 | Reverse alarm |
| Ignition signal switch | 33 | Fuel solenoid |
| Ignition start switch | 34 | Horn |
| Ignition stop signal light | 35 | Spray bar pump |
| Ignition stop turn signal light | 36 | Neutral relay |
| Ignition stop engine speed regulator | 37 | Crank relay |
| Ignition stop glow plug solenoid | 38 | Glow plug relay |
| Ignition stop throttle | 39 | Throttle relay |
| Ignition stop emergency | 40 | Parking brake switch |
| Ignition stop oil-function sensor | 41 | Rear light (left) |
| Ignition stop air pressure sensor | 42 | Head light (left) |
| Ignition stop air filter sensor | 43 | Head light (right) |
| Ignition stop oil level sensor | 44 | Front parking light (left) (optional) |
| Ignition stop fuse (throttle pull) | 45 | Front turn light (left) (optional) |
| Ignition stop fuse (main) | 46 | Front parking light (right) (optional) |
| Ignition stop fuse (lights) | 47 | Front turn light (right) (optional) |
| Ignition stop horn switch | 48 | Rear parking light (left) (optional) |
| Ignition stop vibration mode switch | 49 | Rear turn light (left) (optional) |
| Ignition stop switch | 50 | Rear parking light (right) (optional) |
| Ignition stop over relay | 51 | Rear turn light (right) (optional) |
| Ignition stop horn switch | 52 | Beacon |
| Ignition stop bottle switch | 53 | License light (optional) |
| Ignition stop work light switch | 54 | Seat switch |
| Ignition stop display module | 55 | Neutral switch |
| Ignition stop horn timer module | 56 | Vibration switch |
| Ignition stop bottle solenoid | 57 | Backup switch |
| Ignition stop glow plug engine | 58 | 12V accessory outlet |
| Ignition stop solenoid (front only) | 59 | Turn / tail light harness (optional) |
| Ignition stop solenoid (front & rear) | 60 | — |



| Description | Ref. | Description |
|--|------|--|
| Start switch (optional) | 31 | Brake and bypass solenoid |
| Reverse switch | 32 | Reverse alarm |
| Ignition signal switch | 33 | Fuel solenoid |
| Ignition start switch | 34 | Horn |
| Ignition turn signal light | 35 | Spray bar pump |
| Ignition turn signal light | 36 | Neutral relay |
| Ignition charge regulator | 37 | Crank relay |
| Ignition glow plug solenoid | 38 | Glow plug relay |
| Ignition throttle switch | 39 | Throttle relay |
| Ignition emergency stop switch | 40 | Parking brake switch |
| Ignition oil-function sensor | 41 | Rear light (left) |
| Ignition oil pressure sensor | 42 | Head light (left) |
| Ignition oil filter sensor | 43 | Head light (right) |
| Ignition oil level sensor | 44 | Front parking light (left) (optional) |
| Ignition oil fuse (throttle pull) | 45 | Front turn light (left) (optional) |
| Ignition oil fuse (main) | 46 | Front parking light (right) (optional) |
| Ignition oil fuse (lights) | 47 | Front turn light (right) (optional) |
| Ignition oil on switch | 48 | Rear parking light (left) (optional) |
| Ignition oil operation mode switch | 49 | Rear turn light (left) (optional) |
| Ignition oil switch | 50 | Rear parking light (right) (optional) |
| Ignition oil over relay | 51 | Rear turn light (right) (optional) |
| Ignition oil pump switch | 52 | Beacon |
| Ignition oil bottle switch | 53 | License light (optional) |
| Ignition oil work light switch | 54 | Seat switch |
| Ignition oil display module | 55 | Neutral switch |
| Ignition oil pump timer module | 56 | Vibration switch |
| Ignition oil bottle solenoid | 57 | Backup switch |
| Ignition oil glow plug engine | 58 | 12V accessory outlet |
| Ignition oil operation solenoid (front only) | 59 | Turn / tail light harness (optional) |
| Ignition oil operation solenoid (front & rear) | 60 | — |




OPTIONAL TURN AND TAIL LIGHT HARNESS




D


| Description | Ref. | Description |
|--|------|--|
| Start switch (optional) | 31 | Brake and bypass solenoid |
| Reverse alarm | 32 | Reverse alarm |
| Ignition signal switch | 33 | Fuel solenoid |
| Ignition start switch | 34 | Horn |
| Ignition start signal light | 35 | Spray bar pump |
| Ignition start turn signal light | 36 | Neutral relay |
| Ignition start throttle regulator | 37 | Crank relay |
| Ignition start crank solenoid | 38 | Glow plug relay |
| Ignition start throttle | 39 | Throttle relay |
| Ignition start emergency | 40 | Parking brake switch |
| Ignition start dual-function sensor | 41 | Rear light (left) |
| Ignition start pressure sensor | 42 | Head light (left) |
| Ignition start filter sensor | 43 | Head light (right) |
| Ignition start level sensor | 44 | Front parking light (left) (optional) |
| Ignition start fuse (throttle pull) | 45 | Front turn light (left) (optional) |
| Ignition start fuse (main) | 46 | Front parking light (right) (optional) |
| Ignition start fuse (lights) | 47 | Front turn light (right) (optional) |
| Ignition start horn switch | 48 | Rear parking light (left) (optional) |
| Ignition start vibration mode switch | 49 | Rear turn light (left) (optional) |
| Ignition start switch | 50 | Rear parking light (right) (optional) |
| Ignition start over relay | 51 | Rear turn light (right) (optional) |
| Ignition start horn switch | 52 | Beacon |
| Ignition start bottle switch | 53 | License light (optional) |
| Ignition start back light switch | 54 | Seat switch |
| Ignition start display module | 55 | Neutral switch |
| Ignition start horn timer module | 56 | Vibration switch |
| Ignition start bottle solenoid | 57 | Backup switch |
| Ignition start glow plug engine | 58 | 12V accessory outlet |
| Ignition start solenoid (front only) | 59 | Turn / tail light harness (optional) |
| Ignition start solenoid (front & rear) | 60 | — |



| Description | Ref. | Description |
|---|------|--|
| Start switch (optional) | 31 | Brake and bypass solenoid |
| Reverse switch | 32 | Reverse alarm |
| Ignition signal switch | 33 | Fuel solenoid |
| Ignition start switch | 34 | Horn |
| Ignition stop signal light | 35 | Spray bar pump |
| Ignition stop turn signal light | 36 | Neutral relay |
| Ignition stop engine speed regulator | 37 | Crank relay |
| Ignition stop glow plug solenoid | 38 | Glow plug relay |
| Ignition stop throttle | 39 | Throttle relay |
| Ignition stop emergency | 40 | Parking brake switch |
| Ignition stop oil-function sensor | 41 | Rear light (left) |
| Ignition stop oil pressure sensor | 42 | Head light (left) |
| Ignition stop oil filter sensor | 43 | Head light (right) |
| Ignition stop oil level sensor | 44 | Front parking light (left) (optional) |
| Ignition stop fuse (throttle pull) | 45 | Front turn light (left) (optional) |
| Ignition stop fuse (main) | 46 | Front parking light (right) (optional) |
| Ignition stop fuse (lights) | 47 | Front turn light (right) (optional) |
| Ignition stop horn switch | 48 | Rear parking light (left) (optional) |
| Ignition stop vibration mode switch | 49 | Rear turn light (left) (optional) |
| Ignition stop switch | 50 | Rear parking light (right) (optional) |
| Ignition stop over relay | 51 | Rear turn light (right) (optional) |
| Ignition stop horn switch | 52 | Beacon |
| Ignition stop bottle switch | 53 | License light (optional) |
| Ignition stop work light switch | 54 | Seat switch |
| Ignition stop display module | 55 | Neutral switch |
| Ignition stop horn timer module | 56 | Vibration switch |
| Ignition stop bottle solenoid | 57 | Backup switch |
| Ignition stop glow plug engine | 58 | 12V accessory outlet |
| Ignition stop vibration solenoid (front only) | 59 | Turn / tail light harness (optional) |
| Ignition stop vibration solenoid (front & rear) | 60 | — |












| Description | Ref. | Description |
|------------------------------------|------|--|
| Start switch (optional) | 32 | Reverse alarm |
| Thermostat | 33 | Fuel solenoid |
| Ignition signal switch | 34 | Horn |
| Ignition start switch | 35 | Spray bar pump |
| Ignition turn signal light | 36 | Neutral relay |
| Ignition turn signal light | 37 | Crank relay |
| Ignition regulator | 38 | Glowplug relay |
| Ignition crank solenoid | 39 | Throttle relay |
| Ignition starter | 40 | Parking brake switch |
| Ignition relay | 41 | Rear light (left) |
| Ignition function sensor | 42 | Head light (left) |
| Ignition pressure sensor | 43 | Head light (right) |
| Ignition filter sensor | 44 | Front parking light (left) (optional) |
| Ignition level sensor | 45 | Front turn light (left) (optional) |
| Ignition fuse | 46 | Front parking light (right) (optional) |
| Ignition fuse (main) | 47 | Front turn light (right) (optional) |
| Ignition fuse (lights) | 48 | Rear parking light (left) (optional) |
| Ignition switch | 49 | Rear turn light (left) (optional) |
| Ignition mode switch | 50 | Rear parking light (right) (optional) |
| Ignition switch | 51 | Rear turn light (right) (optional) |
| Ignition relay | 52 | Beacon |
| Ignition pump switch | 53 | License light (optional) |
| Ignition bottle switch | 54 | Seat switch |
| Ignition park light switch | 55 | Neutral switch |
| Ignition play module | 56 | Vibration switch |
| Ignition timer module | 57 | Brake light |
| Ignition bottle solenoid | 58 | Brake light relay |
| Ignition glow plug engine | 59 | Turn signal indicator |
| Ignition solenoid (front only) | 60 | Turn / tail light harness (optional) |
| Ignition solenoid (front & rear) | 61 | 12V accessory outlet |
| Ignition brake and bypass solenoid | — | — |







| Description | Ref. | Description |
|------------------------------------|------|--|
| Start switch (optional) | 32 | Reverse alarm |
| Thermostat | 33 | Fuel solenoid |
| Ignition signal switch | 34 | Horn |
| Ignition start switch | 35 | Spray bar pump |
| Ignition turn signal light | 36 | Neutral relay |
| Ignition turn signal light | 37 | Crank relay |
| Ignition regulator | 38 | Glowplug relay |
| Ignition crank solenoid | 39 | Throttle relay |
| Ignition starter | 40 | Parking brake switch |
| Ignition relay | 41 | Rear light (left) |
| Ignition function sensor | 42 | Head light (left) |
| Ignition pressure sensor | 43 | Head light (right) |
| Ignition filter sensor | 44 | Front parking light (left) (optional) |
| Ignition level sensor | 45 | Front turn light (left) (optional) |
| Ignition fuse | 46 | Front parking light (right) (optional) |
| Ignition fuse (main) | 47 | Front turn light (right) (optional) |
| Ignition fuse (lights) | 48 | Rear parking light (left) (optional) |
| Ignition switch | 49 | Rear turn light (left) (optional) |
| Ignition mode switch | 50 | Rear parking light (right) (optional) |
| Ignition switch | 51 | Rear turn light (right) (optional) |
| Ignition relay | 52 | Beacon |
| Ignition pump switch | 53 | License light (optional) |
| Ignition bottle switch | 54 | Seat switch |
| Ignition park light switch | 55 | Neutral switch |
| Ignition play module | 56 | Vibration switch |
| Ignition timer module | 57 | Brake light |
| Ignition bottle solenoid | 58 | Brake light relay |
| Ignition glow plug engine | 59 | Turn signal indicator |
| Ignition solenoid (front only) | 60 | Turn / tail light harness (optional) |
| Ignition solenoid (front & rear) | 61 | 12V accessory outlet |
| Ignition brake and bypass solenoid | — | — |


| Description | Ref. | Description |
|----------------------------------|------|--|
| Start switch (optional) | 32 | Reverse alarm |
| Thermostat | 33 | Fuel solenoid |
| Throttle position signal switch | 34 | Horn |
| Ignition switch | 35 | Spray bar pump |
| Turn signal light | 36 | Neutral relay |
| Front turn signal light | 37 | Crank relay |
| Air charge regulator | 38 | Glowplug relay |
| Injection crank solenoid | 39 | Throttle relay |
| Water pump | 40 | Parking brake switch |
| Rear view mirror | 41 | Rear light (left) |
| Oil-level function sensor | 42 | Head light (left) |
| Air pressure sensor | 43 | Head light (right) |
| Air filter sensor | 44 | Front parking light (left) (optional) |
| Oil level sensor | 45 | Front turn light (left) (optional) |
| Oil level sensor fuse | 46 | Front parking light (right) (optional) |
| Oil level sensor fuse (main) | 47 | Front turn light (right) (optional) |
| Oil level sensor fuse (lights) | 48 | Rear parking light (left) (optional) |
| Ignition switch | 49 | Rear turn light (left) (optional) |
| Ignition mode switch | 50 | Rear parking light (right) (optional) |
| Ignition switch | 51 | Rear turn light (right) (optional) |
| Ignition relay | 52 | Beacon |
| Ignition switch | 53 | License light (optional) |
| Ignition switch | 54 | Seat switch |
| Ignition light switch | 55 | Neutral switch |
| Ignition module | 56 | Vibration switch |
| Ignition timer module | 57 | Brake light |
| Ignition solenoid | 58 | Brake light relay |
| Ignition plug engine | 59 | Turn signal indicator |
| Ignition solenoid (front only) | 60 | Turn / tail light harness (optional) |
| Ignition solenoid (front & rear) | 61 | 12V accessory outlet |
| Ignition and bypass solenoid | — | — |




D




| Description | Ref. | Description |
|------------------------------------|------|--|
| Reverse alarm switch (optional) | 32 | Reverse alarm |
| Fuel shutoff solenoid | 33 | Fuel solenoid |
| Ignition signal switch | 34 | Horn |
| Emergency stop switch | 35 | Spray bar pump |
| Neutral turn signal light | 36 | Neutral relay |
| Left turn signal light | 37 | Crank relay |
| Ignition voltage regulator | 38 | Glowplug relay |
| Ignition crank solenoid | 39 | Throttle relay |
| Brake master cylinder | 40 | Parking brake switch |
| Left rear turn signal light | 41 | Rear light (left) |
| Headlight function sensor | 42 | Head light (left) |
| Headlight pressure sensor | 43 | Head light (right) |
| Front fog light filter sensor | 44 | Front parking light (left) (optional) |
| Left fog light level sensor | 45 | Front turn light (left) (optional) |
| Right fog light fuse | 46 | Front parking light (right) (optional) |
| Left fog light fuse (main) | 47 | Front turn light (right) (optional) |
| Right fog light fuse (lights) | 48 | Rear parking light (left) (optional) |
| Left fog light relay switch | 49 | Rear turn light (left) (optional) |
| Ignition mode switch | 50 | Rear parking light (right) (optional) |
| Left fog light switch | 51 | Rear turn light (right) (optional) |
| Emergency stop relay | 52 | Beacon |
| Ignition pump switch | 53 | License light (optional) |
| Ignition bottle switch | 54 | Seat switch |
| Ignition back light switch | 55 | Neutral switch |
| Ignition play module | 56 | Vibration switch |
| Ignition timer module | 57 | Brake light |
| Ignition bottle solenoid | 58 | Brake light relay |
| Ignition glow plug engine | 59 | Turn signal indicator |
| Ignition solenoid (front only) | 60 | Turn / tail light harness (optional) |
| Ignition solenoid (front & rear) | 61 | 12V accessory outlet |
| Ignition brake and bypass solenoid | — | — |



| Description | Ref. | Description |
|------------------------------------|------|--|
| Start switch (optional) | 32 | Reverse alarm |
| Thermostat | 33 | Fuel solenoid |
| Ignition signal switch | 34 | Horn |
| Ignition start switch | 35 | Spray bar pump |
| Neutral start signal light | 36 | Neutral relay |
| Ignition turn signal light | 37 | Crank relay |
| Ignition regulator | 38 | Glowplug relay |
| Ignition crank solenoid | 39 | Throttle relay |
| Ignition starter | 40 | Parking brake switch |
| Ignition relay | 41 | Rear light (left) |
| Ignition function sensor | 42 | Head light (left) |
| Ignition pressure sensor | 43 | Head light (right) |
| Ignition filter sensor | 44 | Front parking light (left) (optional) |
| Ignition level sensor | 45 | Front turn light (left) (optional) |
| Ignition fuse | 46 | Front parking light (right) (optional) |
| Ignition fuse (main) | 47 | Front turn light (right) (optional) |
| Ignition fuse (lights) | 48 | Rear parking light (left) (optional) |
| Ignition switch | 49 | Rear turn light (left) (optional) |
| Ignition mode switch | 50 | Rear parking light (right) (optional) |
| Ignition switch | 51 | Rear turn light (right) (optional) |
| Ignition relay | 52 | Beacon |
| Ignition pump switch | 53 | License light (optional) |
| Ignition bottle switch | 54 | Seat switch |
| Ignition park light switch | 55 | Neutral switch |
| Ignition play module | 56 | Vibration switch |
| Ignition timer module | 57 | Brake light |
| Ignition bottle solenoid | 58 | Brake light relay |
| Ignition glow plug engine | 59 | Turn signal indicator |
| Ignition solenoid (front only) | 60 | Turn / tail light harness (optional) |
| Ignition solenoid (front & rear) | 61 | 12V accessory outlet |
| Ignition brake and bypass solenoid | — | — |




| Description | Ref. | Description |
|--|------|-------------------------------------|
| Working cylinder relief pressure 650-725 psi) | 8 | Return filter (10 micron) |
| Working unit | 9 | Tank |
| Drive motor | 10 | Suction strainer |
| Mass | 11 | Vibration solenoid valve |
| Large pump relief pressure 435 psi) | 12 | Exciter motor |
| In pump relief pressure 4350 psi) | 13 | Pressure relief valve (4200 psi) |
| Filter pump | 14 | Fan |




| Description | Ref. | Description |
|------------------|------|--------------------------|
| ...ring cylinder | 8 | Return filter |
| ...ring unit | 9 | Tank |
| ...e motor | 10 | Suction strainer |
| ...ass lever | 11 | Vibration solenoid valve |
| ...arge pump | 12 | Exciter motor |
| ...n pump | 13 | Pressure relief valve |
| ...iter pump | — | — |

| Description | Ref. | Description |
|----------------------------------|------|-------------------------|
| Stark light switch | 19 | To magneto kill |
| Throttle switch | 20 | Crank relay |
| Throttle switch | 21 | Neutral relay |
| Throttle switch | 22 | Spray bar pump |
| Throttle indicator light (green) | 23 | Fuel cutoff solenoid |
| Throttle indicator light (amber) | 24 | Reverse switch |
| Throttle indicator (30A) | 25 | Vibration switch |
| Throttle solenoid | 26 | Neutral switch |
| Throttle motor | 27 | Seat switch |
| Throttle | 28 | Strobe light (optional) |
| Throttle level sensor | 29 | Backup alarm (optional) |
| Throttle solenoid (front) | 30 | Throttle relay |
| Throttle solenoid | 31 | Quick shut-off relay |
| Throttle timer module | 32 | Emergency stop switch |
| Throttle | 33 | 20A Fuse, lights |
| Throttle light (optional) | 34 | 20A Fuse, throttle pull |
| Throttle head light (optional) | 35 | 20A Fuse, main |
| Throttle head light (optional) | 36 | Voltage regulator |



| Description | Ref. | Description |
|-----------------------------|------|-------------------------|
| light switch | 19 | To magneto kill |
| idle switch | 20 | Crank relay |
| switch | 21 | Neutral relay |
| switch | 22 | Spray bar pump |
| ion indicator light (green) | 23 | Fuel cutoff solenoid |
| uel indicator light (amber) | 24 | Reverse switch |
| ator (30A) | 25 | Vibration switch |
| r solenoid | 26 | Neutral switch |
| r motor | 27 | Seat switch |
| y | 28 | Strobe light (optional) |
| level sensor | 29 | Backup alarm (optional) |
| ion solenoid (front) | — | — |
| le solenoid | 31 | Telematics connection |
| timer module | 32 | Emergency stop switch |
| meter | 33 | 20A Fuse, lights |
| light (optional) | 34 | 20A Fuse, throttle pull |
| head light (optional) | 35 | 20A Fuse, main |
| head light (optional) | 36 | Voltage regulator |



| Description | Ref. | Description |
|--------------|------|--------------------------|
| ing cylinder | 8 | Return filter |
| ing unit | 9 | Tank |
| motor | 10 | Suction strainer |
| ss lever | 11 | Vibration solenoid valve |
| ge pump | 12 | Exciter motor |
| pump | 13 | Pressure relief valve |
| er pump | — | — |

For spare parts information, please see your Wacker Neuson Dealer, or visit the Wacker Neuson website at <http://www.wackerneuson.com/>.

Informationen über Ersatzteile erhalten Sie von Ihrem Wacker Neuson Händler oder besuchen Sie die Wacker Neuson Website unter <http://www.wackerneuson.com/>.

: Pour des informations sur les pièces détachées, merci de consulter votre distributeur Wacker Neuson, ou de visiter le site Internet de Wacker Neuson sur <http://www.wackerneuson.com/>.

: Para saber más sobre las piezas de repuesto, póngase en contacto con su distribuidor de Wacker Neuson o acceda al sitio web de Wacker Neuson en <http://www.wackerneuson.com/>.

: Per informazioni sui pezzi di ricambio, contattare il rivenditore Wacker Neuson o visitare il sito di Wacker Neuson all'indirizzo www.wackerneuson.com.

: För information om reservdelar, kontakta din Wacker Neuson-leverantör eller besök Wacker Neusons webbplats på <http://www.wackerneuson.com/>.

: Pyydä varaosatieitoja Wacker Neusonin jälleenmyyjältä tai vieraile Wacker Neusonin web-sivustolla osoitteessa <http://www.wackerneuson.com/>

: For informasjon om reservedeler, vennligst kontakt din Wacker Neuson-forhandler, eller besøk Wacker Neusons nettside på <http://www.wackerneuson.com/>.

: Hvis du ønsker oplysninger om reservedele, bedes du kontakte din Wacker Neuson forhandler eller besøg Wacker Neuson websiden på <http://www.wackerneuson.com/>.

B Neem contact op met uw Wacker Neuson dealer of bezoek de website van Wacker Neuson op <http://www.wackerneuson.com/> voor meer informatie over reserveonderdelen.

: Para obter informações sobre as peças sobresselentes, consulte o seu fornecedor da Wacker Neuson ou acesse ao site Web da Wacker Neuson em http://www.wackerneuson.com

ž : W celu uzyskania informacji na temat części zamiennych skontaktuj się z przedstawicielem firmy Wacker Neuson lub skorzystaj z witryny internetowej <http://www.wackerneuson.com/>.

Dů ě Pro informace o náhradních dílech, prosím, kontaktujte svého Wacker Neuson dealera, nebo navštivte webové stránky <http://www.wackerneuson.com/>.

A póttalkatárszekre vonatkozó információért kérjük, forduljon Wacker Neuson kereskedőjéhez vagy látogasson el a Wacker Neuson weboldallára a következő címen: <http://www.wackerneuson.com/>.

Важно Для ознакомления с информацией о запасных частях, пожалуйста, обратитесь к местному торговому представителю компании Wacker Neuson или посетите веб-сайт <http://www.wackerneuson.com/>.

Σημαντικό : Για πληροφορίες σχετικά με τα ανταλλακτικά, μιλήστε με τον αντιπρόσωπό σας της Wacker Neuson, ή επισκεφθείτε τον ιστότοπο <http://www.wackerneuson.com/>.

: Za rezervne dijelove obratite se svom Wacker Neuson prodavaču ili posjetite mrežne stranice tvrtke Wacker Neuson: <http://www.wackerneuson.com/>.

: Yedek parça bilgileri için Wacker Neuson Bayinize bakın veya Wacker Neuson web sitesini ziyaret edin. <http://www.wackerneuson.com/>

重要 交換部品の情報については、ワッカーノイソンディーラーにお問い合わせ頂くか、ワッカーノイソンウェブサイト <http://www.wackerneuson.com/> をご覧ください。

重要 有关备件信息，请咨询您的威克诺森经销商或访问威克诺森网站：
<http://www.wackerneuson.com/>。

: Pentru informații referitoare la piesele de schimb, vă rugăm să vă adresați distribuitorului Wacker Neuson sau să vizitați site-ul web Wacker Neuson la adresa <http://www.wackerneuson.com/>.

Важно : За информация относно резервни части, моля, обърнете се към местния дилър на Wacker Neuson или посетете уебсайта на Wacker Neuson на адрес <http://www.wackerneuson.com/>.

Wacker Neuson Produktion GmbH & Co. KG, Preußenstraße 41, D-80809 München,

Tel.: +49-(0)89-3 54 02-0 Fax: +49 - (0)89-3 54 02-390

Wacker Neuson Production Americas LLC, N92W15000 Anthony Ave., Menomonee Falls, WI. 53051

Tel.: (262) 255-0500 Fax: (262) 255-0550 Tel.: (800) 770-0957

Wacker Neuson Limited - Room 1701-03 & 1717-20, 17/F. Tower 1, Grand Century Place, 193 Prince Edward Road West, Mongkok, Kowloon, Hongkong. Tel: (852) 3605 5360, Fax: (852) 2758 0032