



## Power Consumption Chart

Item	Starting Wattage (W)	Running Wattage (W)
Circular Saw	2400	1200
Drill	1800	720
Electric Chainsaw	2400	960
Electric Lawn Mower	2400	1200
Electric Pressure Washer	4320	1440
Electric String Trimmer	3600	1200
Jig Saw	1500	600
Miter Saw	1800	720
Orbital Sander	2100	840
Paint Sprayer	1800	600
Planer	2400	960
Router	1500	600
Water Pump	3000	1000
Wet/Dry Vacuum	2500	888
Winch	5400	1800
Furnace fan, gas/fuel oil furnace		
1/8 Horsepower (hp)	500	300
1/6 Horsepower (hp)	750	500
1/4 Horsepower (hp)	1000	600
2/5 Horsepower (hp)	1400	700