




nifty

SD120T **SD34T**



niftylift.com

M50350/06



Issue 6
(January 2019)

illustrated parts manual

Manuel illustré de pièces détachées

Illustrierte Stückliste

Manual de piezas ilustrado

Please Note, at the time of going to press, all information, illustrations details and descriptions contained herein are valid. Niftylift reserves the right to change, alter, modify or improve its products without any obligation to install them on previously manufactured machines.

Readers of this manual requiring further information should contact us at:

Niftylift Ltd.
Fingle Drive
Stonebridge
Milton Keynes
MK13 OER
United Kingdom

Niftylift Inc.
1525 S.Buncombe Road
Greer
SC 29651
USA

Tel +44 (0)1908 857899
 Fax +44 (0)1908 227460

1 864 968 8881
 1 864 968 8836

Ordering of Parts

When ordering a replacement part for your Niftylift product, please state the following:

- Machine Model and Serial number Niftylift Part number
- Full description of the part Quantity required
- Purchase Order number Destination address

Machine Information

Model number. Date of Purchase

Serial number

Veuillez noter qu'au moment de la mise sous presse, l'ensemble des informations, illustrations, détails et descriptions, contenus dans le présent document, sont valides. Niftylift se réserve le droit de changer ou d'améliorer ses produits sans obligation de montage sur les anciennes machines.

Pour toutes informations supplémentaires, veuillez nous contacter à:

Niftylift Ltd.
Fingle Drive
Stonebridge
Milton Keynes
MK13 OER
United Kingdom

Niftylift Inc.
1525 S.Buncombe Road
Greer
SC 29651
USA

Tel +44 (0)1908 857899
 Fax +44 (0)1908 227460

1 864 968 8881
 1 864 968 8836

Commande de pièces

Lors de la commande de pièces de rechange pour votre machine Niftylift, veuillez indiquer ce qui suit:

- Modèle et numéro de série de la machine Référence de la pièce Niftylift
- Description complète de la pièce Quantité requise
- Numéro de commande Adresse de destination

Informations relatives à la machine

Numéro de modèle Date d'achat

Numéro de série



Bitte nehmen Sie zur Kenntnis, dass alle hierin enthaltenen Informationen, Illustrationen und Beschreibungen zum Zeitpunkt des Drucks gültig sind. Niftylift behält sich das Recht vor, Produkte zu wechseln, ändern, modifizieren und zu verbessern, ohne verpflichtet zu sein, sie an früher gefertigten Maschinen zu installieren.

Wenn Leser dieser Anleitung weitere Informationen benötigen, wenden sie sich bitte an uns unter:

Niftylift Ltd.
Fingle Drive
Stonebridge
Milton Keynes
MK13 OER
Großbritannien

Niftylift Inc.
1525 S.Buncombe Road
Greer
SC 29651
USA

Tel +44 (0)1908 857899
 Fax +44 (0)1908 227460

1 864 968 8881
 1 864 968 8836

Bestellen von Ersatzteilen

Bei der Bestellung eines Ersatzteils für Ihr Produkt von Niftylift geben Sie bitte folgende Einzelheiten an:

- | | |
|---------------------------------------|---------------------|
| • Maschinenmodell und Seriennummer | Niftylift Art.-Nr. |
| • Ausführliche Beschreibung des Teils | Erforderliche Menge |
| • Bestellnummer | Bestimmungsadresse |

Maschineninformationen

Modellnummer Kaufdatum.
 Seriennummer.

Por favor, observe que en el momento de pasar a imprenta, toda la información, ilustraciones y descripciones contenidas en el presente documento eran válidas. Niftylift se reserva el derecho de cambiar, alterar, modificar o mejorar sus productos, sin obligación alguna de instalar dichos cambios en máquinas fabricadas anteriormente.

Los usuarios de este manual que requieran más información, deberán ponerse en contacto con nosotros en:

Niftylift Ltd.
Fingle Drive
Stonebridge
Milton Keynes
MK13 OER
United Kingdom

Niftylift Inc.
1525 S.Buncombe Road
Greer
SC 29651
USA

Tel +44 (0)1908 857899
 Fax +44 (0)1908 227460

1 864 968 8881
 1 864 968 8836

Pedido de piezas

Al realizar el pedido de una pieza de recambio para su producto Niftylift, sírvase especificar lo siguiente:

- | | |
|--|---------------------------|
| • Modelo y número de serie de la máquina | Número de pieza Niftylift |
| • Descripción completa de la pieza | Cantidad requerida |
| • Número de orden de compra | Dirección de destino |

Información de la máquina

Número de modelo Fecha de compra
 Número de serie



Parts Order Form (make copies for use)

niftylift**Bon de commande de pièces** (Faire des photocopies pour vos commandes ultérieures)

tel/ +44 (0)1908 857899

Bestellformular für Ersatzteile (bitte Kopien zur zukünftigen Verwendung machen)

fax +44 (0)1908 227460

Impreso de pedido de piezas (haga copias para el uso)

www.niftylift.com

name nom name nombre**date** date datum fecha**address** adresse adresse dirección

delivery address

adresse de livraison

lieferadresse

dirección de entrega

telephone téléphone tel.-Nr. teléfono**fax** fax-Nr.**email** e-mail**purchase order number**

numéro de commande

bestellnummer

número de orden de compra

Part Number Référence pièce Art.-Nr. Número de pieza	description description beschreibung descripción	quantity quantité menge cantidad	price prix preis precio
P			
P			
P			
P			
P			
P			
P			
P			

Note: If items have decals/labels attached, these are **not included** (unless stated otherwise), they must be ordered separately using the part (P) number printed on the decal.

Remarque : si les composants sont dotés d'autocollants/étiquettes, ceux-ci **ne sont pas inclus** (sauf avis contraire). Ils doivent être commandés séparément en indiquant le numéro de référence (P) imprimé sur l'autocollant.

Anmerkung: Wenn an Gegenständen Klebebilder/Etiketten angebracht sind, sind diese (sofern nicht anders angegeben) **nicht enthalten** und müssen separat mit Hilfe der auf den Klebebildern abgedruckten Teilenummern (P) bestellt werden.

Nota: Si los artículos llevan acopladas calcomanías/etiquetas, éstas **no se incluirán** (a menos que se indique lo contrario); deberán pedirse por separado utilizando el número de pieza (P) impreso en la calcomanía.

Alternatively, details of your order can be emailed to **service@niftylift.com**

Alternativement, le détail de votre commande peut nous être envoyé par email à **service@niftylift.com**

Als Alternative können Sie Ihre Bestellung auch an **service@niftylift.com** senden

Alternativamente, los detalles de su pedido pueden enviarse por e-mail a **service@niftylift.com**

1

chassis

page

1.1	Base assembly	1-2
1.2	Stabiliser assembly	1-4
1.3	Steering assembly	1-6
1.4	Anderson connector	1-8

2

superstructure

page

2.1	Superstructure	2-2
2.2	Diesel engine - Part 1	2-6
2.3	Diesel engine - Part 2	2-8
2.4	DC Power pack	2-10
2.5	Control valve assembly (4 spool)	2-12
2.6	Button box assembly	2-14
2.7	Electrical box assembly	2-16
2.8	Slew assembly	2-18

3

boom assemblies

page

3.1	Booms assembly	3-2
3.2	Lift cylinder	3-6
3.3	Levelling cylinders	3-8
3.4	Telescope cylinder	3-10
3.5	Energy Chain	3-12
3.6	Drive/Jacks control station	3-14

4

cage

page

4.1	Cage assembly	4-2
4.2	Cage weigh assembly	4-4
4.3	Control box assembly	4-6
4.4	Control valve assembly (6 spool)	4-8

5

labelling

page

5.1	Label locations SD120T	5-2
-----	------------------------------	-----

Figures

page

1.1	Base assembly	1-3
1.2	Stabiliser assembly	1-5
1.3	Steering assembly.....	1-7
1.4	Anderson connector	1-8
2.1	Superstructure	2-3
2.2	Diesel engine (1)	2-7
2.3	Diesel engine (2)	2-9
2.4	DC Power pack	2-11
2.5	Control valve assembly (4 spool).....	2-13
2.6	Button box assembly	2-15
2.7	Electrical box assembly	2-17
2.8	Slew assembly	2-19
3.1	Booms assembly.....	3-3
3.2	Lift cylinder	3-7
3.3	Levelling cylinder.....	3-9
3.4	Telescope cylinder	3-11
3.5	Energy Chain	3-13
3.6	Drive/Jacks control station	3-15
4.1	Cage assembly.....	4-3
4.2	Cage weigh assembly	4-5
4.3	Control box assembly	4-7
4.4	Control valve assembly	4-9
5.1	Label locations SD120T	5-3
5.2	Labels (1-35).....	5-12
5.3	Labels (36-52).....	5-13

table des matières
inhaltsverzeichnis
tabla del contenido


contents

vii

Issue Records

Chapter	Pages	Issue	Date	Comments/Changes
Introduction	8	6	01/2019	Sixth issue
1	10	3	02/2016	Third issue
2	20	5	02/2017	Fifth issue
3	16	2	09/2015	Second issue
4	10	4	01/2019	Revision on pages 4-2/3
5	14	4	01/2019	Fourth issue

* When ordering parts for machines other than the stated serial number, it is advisable to contact the Parts Department;

United Kingdom

USA

Tel +44 (0)1908 857899

1 864 968 8881

Fax +44 (0)1908 227460

1 864 968 8836

Email service@niftylift.com

niftyusa@niftylift.com



nifty




SD120T (SD34T)

illustrated parts manual

Manuel illustré de pièces détachées

Illustrierte Stückliste

Manual de piezas ilustrado



1

chassis assembly

french
german
spanish


1.1 Base assembly

Item	Description	Part Number			
1	Slew ring				P16817
2	Slew stop				P20046
3	Base assembly				P28730
4	Cover - Centre				P21572
5	Fuse holder & cover				P23422
6	Fuse - 225A				P23423
7	Anderson connector See "Anderson connector" on page 1-8.				N/A
8	Cover - Front				P21267
9	PRV - 100 Bar				P22470
10	Valve - 6/2				P21319
11	Bush				P12863
12	Battery				P27917
13	Battery carrier				P10786
14	Handle				P10241
15	Battery cover				P10822
16	Wheel & Tyre *LH RH *Non-marking LH RH				P21242 P21243 P21685 P21686
17	Wheel gearbox *Seal kit				P15698 P18126
18	Axle				P16124
19	Spirit level				P10228
20	Boom rest - Rubber				P10611

* Not illustrated

french
german
spanish

chassis assembly



french
german
spanish

chassis assembly


1.2 Stabiliser assembly

Item	Description				Part Number
1	Cylinder * Seal kit				P22013 P23812
2	Check valve				P17317
3	Washer				P10035
4	Load valve				P11956
5	Banjo bolt				P14181
6	Pivot pin - 127mm				P12952
7	Bush 3025				P12863
8	Pivot pin - 166mm				P17355
9	Swing bolt				P15966
10	Stabiliser (Outrigger)				P22012
11	Limit switch				P18937
12	Bush - Nylon				P12298
13	Spring				P12297
14	Foot plate (Includes Item 15)				P17345
15	Spring clip				P18113
16	Rocker arm				P21622
17	Pin - 146mm				P12955
18	Foot assembly (Items 14, 15 & 16)				P21639

* Not illustrated

french
german
spanish

chassis assembly



french
german
spanish

chassis assembly


1.3 Steering assembly

Item	Description				Part Number
1	Pin -				P16220
2	Wheel & Tyre LH Non-marking LH				P21242 P21685
3	Gearbox				P15698
4 *	Seal kit for item 3				P18126
5	Washer				P16062
6	Bush - DU3040				P10508
7	Bush				P12320
8	Steer hub LH				P15811
9	Washer - plastic				P10511
10	Track rod				P20930
11	Steer cylinder				P12781
12 *	Seal kit for item 11				P13047
13	Steer hub RH				P15812
14	Wheel bolt (86Nm torque)				P22001
15	Wheel & Tyre RH Non-marking RH				P21243 P21686

* Not illustrated

french
german
spanish

chassis assembly



french
german
spanish

chassis assembly


1-7

1.4 Anderson connector

Item	Description				Part Number
1	Handle				P17084
2	Mounting plate				P15271
3	Connector - 24v				P17083
4	Connector - 12v				P17085
5	Handle				P16942

french
german
spanish

chassis assembly



french
german
spanish

chassis assembly

1-9



nifty




SD120T (SD34T)

illustrated parts manual

Manuel illustré de pièces détachées

Illustrierte Stückliste

Manual de piezas ilustrado



2

superstructure

french
german
spanish

2.1 Superstructure

Item Description Part Number

1	Boom 1 assembly				P20613
2	Battery Charger				P24282
3	Manifold valve See "Diesel engine - Part 2" on page 2-8.				P28153
4	Tank - 28 litre Bi-energy *Diesel only				P16500 P12868
5	Filler cap Dipstick				P10136 P11643
6	Oil Filter assembly Cartridge ONLY				P10137 P10766
7	Solenoid valve assy. Coil ONLY				P10132 P70354
8	Power pack - 1.2cc See "DC Power pack" on page 2-10.				P25868
9	Power Pack - 2.2cc See "DC Power pack" on page 2-10.				P25869
10	Valve assembly				P26939
11	Engine cover				P21266
12	Fuse - 125A Fuse holder				P12696 P24708
13	Battery				P11975
14	Battery clamp				P12295
15	Engine assembly See "Diesel engine - Part 1" on page 2-6. or "Diesel engine - Part 2" on page 2-8				N/A
16	Battery regulator				P27689
17	Tilt sensor (Option) USA/Canada				P16109 P19841
18	Starter switch assy.				P14428
19	Bracket				P16352
20	Siren				P11113
21	Valve block				P20603


* Not illustrated

issue 05

niftylift.com

french
german
spanish

superstructure



french
german
spanish

superstructure


2.1 continued

Item	Description	Part Number			
22	Lock follower				P11444
23	Escutcheon * Tee key				P11784 P11786
24	Access panel				P23899
25	Diverter valve Lever ONLY				P10702 P14397
26	Bracket - Hand pump				P23631
27	Hand pump Seal kit *				P22570 P22605
28	Control valve See "Control valve (4 spool)" on page 2-12.				P21631
29	Door				P23898
30	Electrical box assy. See "Electrical box assembly" on page 2- 16.				P29718
31	Door catch				P12397
32	Handle - Hand pump				P10624
33	Button box assembly See "Button box assem- bly" on page 2-14.				P29716
34	Mounting plate				P21574
35	Diverter Valve				P21610
36	Changeover box				P27297
37	Inlet 110v 230v				P26921 P26922
38	Diesel tank				P20015
39	Level gauge				P13252
40	Filler cap/Breather				P13437
41	Pressure Filter Element ONLY Condition indicator Mounting bracket				P28561 P28924 P24945 P26326

* Not illustrated

french
german
spanish

superstructure



french
german
spanish

superstructure


2.2 Diesel engine - Part 1

Item	Description				Part Number
	Diesel engine - D722				P20580
1	Upper bracket				P19240
2	Radiator assembly				P19494
3	Lower bracket				P21375
4	Bracket - Radiator				P19239
5	Bracket - Bottle				P19247
6	Expansion bottle Filler cap ONLY				P19270 P24941
7	Thermostat and gasket				P14620
8	Rubber ring				P16321
9	Support bracket				P21988
10	Muffler assembly				P16051
11	Muffler gasket				P13282
12	Starter switch assembly				P14428
13	Starter key (Pair)				P11646
14	Engine mount - Bracket				P21240
15	Engine mount - Rubber				P12238
16	Oil filter cartridge				P13285
17	V-belt				P13281
18 *	Fan assembly (5 blade)				P23327

* Not illustrated

french
german
spanish

superstructure



french
german
spanish

superstructure


2.3 Diesel engine - Part 2

Item	Description				Part Number
1	Stop solenoid				P13371
2	Air filter				P17809
3	Bracket - Air filter				P20281
4	Bracket - Solenoid				P12571
5	Throttle solenoid				P12972
6	Swivel				P19279
7	Spring				P19281
8	Eye bolt				P19280
9	In-line fuel filter				P13324
10	Fuel filter				P13339
11	Drive flange				P20282
12	Drive hub				P20283
13	Pump assembly				P25101
14 *	Seal kit for item 13				P30747
15	Pipe				P18727
16	Solenoid cartridge				P29526
17	Coil				P29527
18	Banjo bolt				P11948
19	Check valve				P17946
20	Manifold assembly				P28153

* Not illustrated

french
german
spanish

superstructure



french
german
spanish


superstructure

2.4 DC Power pack

Item	Description				Part Number
	Power pack assembly 1.2cc 2.2cc				P25868 P25869
1	Motor				P28443
2	Contactor plate				P16315
3	Contact solenoid - 12v (Bi-energy) 24v (DC only)				P11877 P12922
4	Fuse - 225A				P11977
5	Fuse holder				P24708
6	Flange - Motor				P28444
7	Relief valve kit				P28448
8	Filter				P28447
9	Pump - 1.2cc 2.2cc				P28445 P28446
10	O-ring				P28449

french
german
spanish

superstructure



french
german
spanish

superstructure


2.5 Control valve (4 spool)

Item	Description	Part Number			
1	Control valve				P15518
2 *	Seal kit for item 1				P70337
3	Lever				P70336
4	Pressure relief valve				P70335
5	Lever cap (complete)				P70338
6	Rubber boot				P12225
7	Spool AS AST				P15510 P15511
8	Spool return spring assembly				P16234

* Not illustrated

french
german
spanish

superstructure



french
german
spanish


superstructure

2.6 Button box assembly

Item	Description				Part Number
1	E-Stop button USA Only				P24317 P28564
2	(A) Pilot light lens (B) Bulb (C) Lamp holder (D) Lamp housing				P11295 P11791 P11790 P14276
3	Green button (includes boot) Rubber boot ONLY				P30711 P24332
4	Key switch, 2 position key removable in upper position Rubber boot				P24337 P24321
5	Button box - 4 hole				P22416
6	Button box - 3 hole				P22415
7	Key				P70187
8	Base, Switch Contact - NC (Used with item 1)				P24322 P24324
9	Base, Switch Contact - NO (Used with item 3)				P24322 P24323
10	Base, Switch Contact - NO Contact - NC (Used with item 4)				P24322 P24323 P24324

french
german
spanish

superstructure



french
german
spanish

superstructure


2.7 Electrical box assembly

Item	Description	Part Number			
1	Box				P12516
2	PCB - Battery management				P11174
3	Relay				P10340
4	Relay - Timer stop				P10664
5	Circuit breaker 15A				P11050
6	Circuit breaker 10A				P11719
7	Circuit breaker 35A				P13529
8	Hour meter				P11410
9	Sounder				P11112
10	Plug - 13-way				P12945
11	PCB - Control				P11175
12	Capacitor * Securing Clip * Diode				P15528 P15529 P11179
13	Capacitor * Diode				P14270 P11158
14	Base, Relay				P25856
15	Safety relay				P29783

* Not illustrated

french
german
spanish

superstructure



french
german
spanish


superstructure

2.8 Slew assembly

Item	Description				Part Number
	Complete assembly (Items 3 to 10)				P19498
1	Slew guard				P20084
2	Slew ring				P16817
3	Worm bracket				P12681
4	Coupling				P12145
5	Spacer				P12143
6	Motor				P14306
7 *	Seal kit for item 6				P13242
8	Bearing				P12703
9	Belleville washer				P12150
10	Worm gear				P14502

french
german
spanish

superstructure



french
german
spanish

superstructure



nifty




SD120T (SD34T)

illustrated parts manual

Manuel illustré de pièces détachées

Illustrierte Stückliste

Manual de piezas ilustrado



3

boom assemblies

french
german
spanish




3.1 Booms assembly

Item Description Part Number

1	Boom 2				P27635
2	Lift cylinder See "Lift cylinder" on page 3-6.				P11255
3	Grommet				P11283
4	Pivot pin - 200mm				P15950
5	Plastic washer				P10035
6	Bush DU2550				P10031
7	Pivot pin - 240mm				P19546
8	Pivot pin - 94mm				P12953
9	Boom 1				P20613
10	Bush DU2520				P10032
11	Levelling rod				P20048
12	Wear pad				P15899
13	Wear pad (Black)				P22653
14	Nut				P16312
15	Nylatron stud				P11436
16	Bush DU2525				P10034
17	Pivot pin - 192mm				P10210
18	Hose hoop				P11118
19	Pivot pin - 95mm				P12899
20	Levelling cylinder See "Levelling cylinders" on page 3-8.				P16872
21	Boom 3				P28544
22	Bracket - Boom latch				P20049
23	Pivot pin - 127mm				P12952
24	Bush DU7050				P12324
25	Nylatron washer				P12733
26	Boom 4				P33589
27	Lift cylinder See "Lift cylinder" on page 3-6.				P16836
28	Pivot pin - 146mm Roll pin				P19548 P17485
29	Bracket - Trunking to Boom 4				P19915

french
german
spanish

boom assemblies



french
german
spanish

boom assemblies


Figure 3.1 Booms Assembly

3.1 continued

Item	Description				Part Number
30	Trunking				P20167
31	Lid - Trunking				P20168
32	Bracket - Trunking to tracking				P12643
33	Lower bracket - Inner				P19228
34	Lower bracket - Outer				P19227
35	Tracking See "Energy chain" on page 3-12.				P27397
36	Tracking link				P28093
37	Tracking bridge				P28094
38	Upper bracket - Outer				P19229
39	Upper bracket - Inner				P19230
40	Roller pin - 126mm				P10682
41	Washer guide				P18771
42	Roller				P10680
43	Roller bracket				P20169
44	Spacer				P10601
45	Wear pad (Red)				P10519
46	Levelling cylinder See "Levelling cylinders" on page 3-8.				P11764
47	Pivot pin - 85mm				P19550
48	Knuckle				P20044
49	Bolt for item 52				P70266
50	Tab washer				P17412
51	Roll pin for item 52				P70267
52	End cap				P10037
53	Hose hoop				P10566
54	Flanged bush				P12719
55	Micro switch				P30387
56	Bracket				P30456
57	Pivot pin - 253mm				P19551
58	Swing bolt (Used with items 4, 7, 8, 23, 28, 47 & 57)				P15966
59	Grommet				P17566

french
german
spanish

boom assemblies



french
german
spanish

boom assemblies


3.2 Lift cylinder

Item	Description	Part Number			
1	Cylinder - A B				P11255 P16836
2 *	Seal kit for item 1				P11369
3	Bush DU2520				P10032
4	Dowty washer				P70126
5	Check valve assy				P21052
6	Banjo bolt for cylinder A				P10267
7	Banjo bolt for cylinder B				P10527
8	Load valve ONLY				P31916
9 *	Seal kit for item 8				P11958

* Not illustrated

french
german
spanish

boom assemblies




french
german
spanish

boom assemblies

3-7

3.3 Levelling cylinders

Item	Description				Part Number
1	Cylinder (slave)				P22974
2 *	Seal kit for items 1 and 4				P11082
3	Bush DU2520				P10032
4	Cylinder				P11764
5	Load valve				P11956
6	Check valve cartridge				P17317



french
german
spanish

boom assemblies

3-9


3.4 Telescope cylinder

Item	Description				Part Number
1	Cylinder				P27494
2 *	Seal kit for item 1				P11756
3	Bush DU2520				P10032
4	Check valve cartridge				P17317
5	Load valve				P11956
6	Bracket				P27465
7	Spacer				P10601

french
german
spanish

boom assemblies

3-10



french
german
spanish


boom assemblies

3.5 Energy chain

Item	Description				Part Number
1	Chain assembly (Items 4 to 7 not included)				P27397
2	Bridge				P28094
3	Link (Includes item 2)				P28093
4	Bracket (Inner, with hole)				P19228
5	Bracket (Outer, with hole)				P19227
6	Bracket (Inner)				P19230
7	Bracket (Outer)				P19229

french
german
spanish

boom assemblies




french
german
spanish

boom assemblies

3.6 Drive/Jacks control station

Item	Description	Part Number			
1	Guard				P22517
2	Mounting bracket				P22518
3	Control valve				P22453
4	Manipulator assy. (complete) a) Nut b) Vertical pin c) Universal joint d) UJ joint & pin				P29223 P12748 P12749 P12750 P19917
5	Lever (200mm)				P70336
6	Bracket				P22649
7	Drive/Steer Rod				P22650
8	Handle				P22637



french
german
spanish

boom assemblies

3-15



nifty




SD120T (SD34T)

illustrated parts manual

Manuel illustré de pièces détachées

Illustrierte Stückliste

Manual de piezas ilustrado



4

cage assembly

french
german
spanish




4.1 Cage assembly

Item	Description				Part Number
1	Cage Non cage weigh * Cage weigh				P32342 P27589
2	Bush				P10840
3	Cage gate				P11610
4	Bush				P18647
5	Hoop (U-bolt)				P10566
6	Wear Pad (Non Cage Weigh)				P15167
7	Bracket - Beacon (OPTIONAL)				P11451
8	Beacon (OPTIONAL)				P10274
9	Guard - Beacon (OPTIONAL)				P10312
10	Cap				P10841
11	Hose hoop				P11118
12	Foot switch Cover ONLY				P26601 P26752
13	Electrical contact				P26751
14	Instruction manual box				P11618
15	Socket - 110v/16A (OPTIONAL)				P25082
16	Mounting bracket				P25281
17	Duty Select assembly Box - 1 hole Selector switch Rubber boot Contact NO NC				P28646 P28427 P24318 P24319 P24323 P24324
18	Mounting bracket				P29138
19	Cover - Hose burst				P28649

* Not illustrated

french
german
spanish

cage assembly



french
german
spanish

cage assembly


4.2 Cage weigh assembly

Item	Description				Part Number
1	Cage assembly				P27589
2	PCB - SiOPS and Cage Weigh				P30731
3	Box assembly (Includes item 2) Box ONLY Drain plug *				P25740 P25739 P23737
4	Pin - 110mm				P13157
5	Washer - plastic				P10035
6	Levelling cylinder See "Levelling cylinder" on page 3-12.				P22974
7	Pin - 146mm				P12955
8	Cage bracket				P27575
9	Load cell 1.1m cable 2.4m cable				P18179 P29179
10	Pin - 166mm				P17355
11	Swing bolt				P15966
12	Calibration unit				T00237

* Not illustrated

french
german
spanish

cage assembly



french
german
spanish

cage assembly

4-5


4.3 Control box assembly

Item Description Part Number

	Complete assembly				P29717
1	Box (Poly Carb)				P12861
2	Base, switch Contact - NC				P24322 P24324
3	Base, switch Contact - NO				P24322 P24323
4	Base, switch Contact - NO Contact - NO				P24322 P24323 P24323
5	Base, switch Contact - NO LED block - Green				P24322 P24323 P24338
6	PCB				P18276
7	Lamp assy. - Red				P11408
8	Bulb				P11409
9	Buzzer				P10341
10	Blue button (Includes boot)				P24345
11	Selector switch				P24318
12	Green button (includes boot) Boot ONLY				P24333 P24332
13	Rubber cover				P24319
14	Selector switch				P24327
15	Key switch - 455 key (3 position)				P24346
16	Rubber cover				P24321
17	E-Stop button USA Only				P24317 P28564
18	Decal ONLY				P18961
19	Battery meter				P11494
20	Base, switch Contact - NO (x2) Contact - NC (x2)				P24322 P24323 P24324
21	Drain plug				P23737

french
german
spanish

cage assembly




french
german
spanish

cage assembly

4-7

4.4 Control valve assembly

Item	Description				Part Number
1	Knob ONLY				P28677
2	Spool AS AST				P15510 P15511
3	Valve seal kit				P10707
4	Spool return spring assembly				P16234
5	Interface seal kit				P10706
6	Lever (150mm)				P70346
7	Valve assembly 5 spool				P21248
8	Pressure relief valve Telescope spool Levelling spool Boom 3 spool				P10879 P10879 P15840
9	Pressure relief valve				P70335
10	Lever cap				P70338
11	Rubber boot				P12225



french
german
spanish

cage assembly

4-9



nifty



SD120T (SD34T)




illustrated parts manual

Manuel illustré de pièces détachées

Illustrierte Stückliste

Manual de piezas ilustrado



5



labelling
french
german
spanish

5.1 Label locations

Item	Description	Part Number
1	Harness point	P32302
	USA/Canada ONLY	P32301
	french	P32302
	german	P32302
	spanish	P32302
	dutch	P32302
	swedish	P32302

2	Cage Controls	Cage Weigh Non-cage weigh	P18961
			P12832
	french		P18961
			P12832
	german		P18961
			P12832
	spanish		P18961
			P12832
	dutch		P18961
			P12832
	swedish		P18961
			P12832

3	Emergency stop switch	P14864
	french	P14865
	german	P14866
	spanish	P14867
	dutch	P16628
	swedish	P19625

4	Cage levelling	P10853
	french	P10853
	german	P10853
	spanish	P10853
	dutch	P10853
	swedish	P10853

5	Tilt alarm sounds	P18842
	french	P18843
	german	P18844
	spanish	P18845
	dutch	P18846
	swedish	P19637

french
german
spanish

labelling

Item	Description	Part Number
6	Overload warning	P18848
	french	P18849
	german	P18850
	spanish	P18851
	dutch	P18852
	swedish	P19638
7	Head Protection	P14921
	french	P14921
	german	P14921
	spanish	P14921
	dutch	P14921
	swedish	P14921
8	Battery Management	P11777
	french	P11811
	german	P11809
	spanish	P13432
	dutch	P16483
	swedish	P19715
9	Control Levers - Cage	P14927
	french	P14927
	german	P14927
	spanish	P14927
	dutch	P14927
	swedish	P14927
10	Booms or Drive/Stabilisers - Switch	P22587
	french	P22587
	german	P22587
	spanish	P22587
	dutch	P22587
	swedish	P22587
11	General warning	P24900
	french	P21971
	german	P21972
	spanish	P21973
	dutch	P21974
	swedish	P21976

french
german
spanish

labelling

5.1 continued

Item	Description	Part Number
12	Cage gate warning	P18432
	french	P18432
	german	P18432
	spanish	P18432
	dutch	P18432
	swedish	P18432

13	Clunk Click	P19961
	french	P19961
	german	P19961
	spanish	P19961
	dutch	P19961
	swedish	P19961

14	Cage Tie-down Warning	P21404
	french	P21404
	german	P21404
	spanish	P21404
	dutch	P21404
	swedish	P21404

15	Footswitch	P14884
	french	P14885
	german	P14886
	spanish	P14887
	dutch	P16629
	swedish	P19626

16	Niftylift.com	P14390
	french	P14390
	german	P14390
	spanish	P14390
	dutch	P14390
	swedish	P14390

17	Safe Entry - Cage (USA/Canada Only)	P18192
	french	P18192
	german	P18192
	spanish	P18192
	dutch	P18192
	swedish	P18192

See Figure 5.1, Page 5-11

issue 04

niftylift.com

french
german
spanish

labelling

Item	Description	Part Number
18	Warning - SWL 200kg	P14801
	USA SD34T	P17328
	french	P14801
	german	P14801
	spanish	P14801
	dutch	P14801
	swedish	P14801
19	Operating instructions	P14892
	french	P14892
	german	P14892
	spanish	P14892
	dutch	P14892
	swedish	P14892
20	General crush	P14782
	french	P14782
	german	P14782
	spanish	P14782
	dutch	P14782
	swedish	P14782
21	Logo	P21330
	SD120T	P21331
	SD34T	P21330
	french	P21330
	german	P21330
	spanish	P21330
	dutch	P21330
	swedish	P21330
22	Serial Plate - Blank	P15383
	french	P15383
	german	P15383
	spanish	P15383
	dutch	P15383
	swedish	P15383

french
german
spanish

labelling

5.1 continued

Item	Description	Part Number
23	Travel direction	P14784
	french	P14784
	german	P14784
	spanish	P14784
	dutch	P14784
	swedish	P14784

24	Charger warning	P21951
	french	P21952
	german	P21953
	spanish	P21954
	dutch	P21955
	swedish	P21957

25	No step	P14785
	french	P14785
	german	P14785
	spanish	P14785
	dutch	P14785
	swedish	P14785

26	Noise warning	P17124
	french	P17124
	german	P17124
	spanish	P17124
	dutch	P17124
	swedish	P17124

27	Engine emissions (USA/Canada Only)	P15334
	french	P15334
	german	P15334
	spanish	P15334
	dutch	P15334
	swedish	P15334

28	Remote charge point	P16367
	french	P16367
	german	P16367
	spanish	P16367
	dutch	P16367
	swedish	P16367

See Figure 5.1, Page 5-11

issue 04

niftylift.com

french
german
spanish

labelling

Item	Description	Part Number
29	Battery isolator	P18610
	french	P18610
	german	P18610
	spanish	P18610
	dutch	P18610
	swedish	P18610
30	Hydraulic outriggers	P14841
	french	P14842
	german	P14843
	spanish	P14844
	dutch	P16262
	swedish	P19624
31	Point load - 13 kN	P14965
	french	P14965
	german	P14965
	spanish	P14965
	dutch	P14965
	swedish	P14965
32	4x4 - Grey	P14697
	french	P14697
	german	P14697
	spanish	P14697
	dutch	P14697
	swedish	P14697
33	Tyre pressure (34 psi)	P21657
	french	P21657
	german	P21657
	spanish	P21657
	dutch	P21657
	swedish	P21657
34	Rotating machinery (USA/Canada Only)	P15010
	french	P15010
	german	P15010
	spanish	P15010
	dutch	P15010
	swedish	P15010

french
german
spanish

labelling

5-7

5.1 continued

Item	Description	Part Number
35	Daily safety check list	P14908
	french	P14909
	german	P14910
	spanish	P14911
	dutch	P16630
	swedish	P19629
36	Emergency Controls Location	P21418
	french	P21418
	german	P21418
	spanish	P21418
	dutch	P21418
	swedish	P21418
37	General notice	P21941
	french	P21942
	german	P21943
	spanish	P21944
	dutch	P21945
	swedish	P21947
38	Outriggers - Identification	P16363
	french	P16363
	german	P16363
	spanish	P16363
	dutch	P16363
	swedish	P16363
39	Drive/Steer	P15637
	french	P15637
	german	P15637
	spanish	P15637
	dutch	P15637
	swedish	P15637
40	Hydraulic Oil	P14415
	french	P14415
	german	P14415
	spanish	P14415
	dutch	P14415
	swedish	P14415

french
german
spanish

labelling

Item	Description	Part Number
41	Base/Cage selector	P19445
	french	P19445
	german	P19445
	spanish	P19445
	dutch	P19445
	swedish	P19445
42	Manual Hand Pump	P19716
	french	P19716
	german	P19716
	spanish	P19716
	dutch	P19716
	swedish	P19716
43	Booms/Brake selector	P19986
	french	P19986
	german	P19986
	spanish	P19986
	dutch	P19986
	swedish	P19986
44	Emergency Controls Location	P21848
	french	P21848
	german	P21848
	spanish	P21848
	dutch	P21848
	swedish	P21848
45	Charger socket	110v 230v P26424 P26863
	french	P26863
	german	P26863
	spanish	P26863
	dutch	P26863
	swedish	P26863
46	Diesel	P14414
	french	P14414
	german	P14414
	spanish	P14414
	dutch	P14414
	swedish	P14414

french
german
spanish

labelling

5-9

5.1 continued

Item	Description	Part Number
47	E-Stop - Background (USA/Canada Only)	P24893
	french	P24893
	german	P24893
	spanish	P24893
	dutch	P24893
	swedish	P24893

48	Control box decal - Base	Cage weigh Non-cage Weigh	P17219 P15881
	french		P17219 P15881
	german		P17219 P15881
	spanish		P17219 P15881
	dutch		P17219 P15881
	swedish		P17219 P15881

49	Control levers - Base	P14937
	french	P14937
	german	P14937
	spanish	P14937
	dutch	P14937
	swedish	P14937

50	Trip - Push to reset (On PCB box)	P19056
	french	P19056
	german	P19056
	spanish	P19056
	dutch	P19056
	swedish	P19056


51	Battery cover check	P32030
	french	P32030
	german	P32030
	spanish	P32030
	dutch	P32030
	swedish	P32030

52	Power to cage (Tool)	110v 230v	P33012 P33011
----	----------------------	--------------	------------------

french
german
spanish

labelling

Please refer to Figure 5.2 & 5.3 for representation of labels



french
german
spanish

labelling





Figure 5.2 Labels (1-35)



french
german
spanish

labelling

